


# Service Manual

## Air Conditioner

**CS-PC18GKF CU-PC18GKF**  
**CS-PC24GKF CU-PC24GKF**



### **⚠ WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.


## TABLE OF CONTENTS


	PAGE		PAGE
<b>1 Safety Precaution</b> .....	<b>2</b>	<b>7 Block Diagram</b> .....	<b>14</b>
<b>2 Specifications</b> .....	<b>4</b>	<b>8 Wiring Connection Diagram</b> .....	<b>15</b>
2.1. CS-PC18GKF CU-PC18GKF .....	4	<b>9 Electronic Circuit Diagram</b> .....	<b>17</b>
2.2. CS-PC24GKF CU-PC24GKF .....	6	<b>10 Printed Circuit Board</b> .....	<b>18</b>
<b>3 Features</b> .....	<b>8</b>	10.1. Main Printed Circuit Board .....	18
<b>4 Location of Controls and Components</b> .....	<b>9</b>	10.2. Power Printed Circuit Board .....	20
4.1. Product Overview .....	9	10.3. Indicator panel .....	21
<b>5 Dimensions</b> .....	<b>10</b>	<b>11 Installation Instruction</b> .....	<b>22</b>
5.1. Indoor Unit .....	10	11.1. CS-PC18GKF CU-PC18GKF .....	22
5.2. Outdoor Unit .....	11	11.2. CS-PC24GKF CU-PC24GKF .....	28
<b>6 Refrigeration Cycle Diagram</b> .....	<b>13</b>	<b>12 Operation and Control</b> .....	<b>34</b>

12.1. Cooling Operation-----	34	<b>14 Troubleshooting Guide -----</b>	<b>44</b>
12.2. Soft Dry Operation -----	35	14.1. Refrigeration Cycle System -----	44
12.3. Automatic Operation-----	36	<b>15 Disassembly and Assembly Instructions -----</b>	<b>46</b>
12.4. Operation Control -----	37	15.1. Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures-----	46
12.5. Indoor Fan Speed Control -----	39	<b>16 Technical Data -----</b>	<b>49</b>
12.6. Outdoor Fan Speed Control -----	40	16.1. Thermostat Characteristics-----	49
12.7. Vertical Airflow Direction Control -----	41	16.2. Operation Characteristics -----	50
12.8. Timer Control-----	41	16.3. Fan Performance -----	54
12.9. Random Auto Restart Control-----	41	16.4. Cooling Capacity Performance Data-----	54
12.10. Remote Control Signal Receiving Sound -----	41	16.5. Sound Data-----	57
<b>13 Servicing Mode -----</b>	<b>42</b>	<b>17 Exploded View and Replacement Parts List-----</b>	<b>59</b>
13.1. Auto OFF/ON Button -----	42	17.1. Indoor Unit-----	59
13.2. Remote Control Button -----	42	17.2. Outdoor Unit -----	61
13.3. Test Mode Timer Table-----	43		


# 1 Safety Precaution

- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work must be installed or serviced by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.


 <b>WARNING</b>	This indication shows the possibility of causing death or serious injury.
--	---




 <b>CAUTION</b>	This indication shows the possibility of causing injury or damage to properties.
--	--

- The items to be followed are classified by the symbols:

	This symbol denotes item that is PROHIBITED from doing.
---	---


- Carry out test running to confirm that no abnormality occurs after the servicing. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

 <b>WARNING</b>
1. Engage dealer or specialist for installation and servicing. If installation or servicing done by the user is defective, it will cause water leakage, electrical shock or fire.
2. Install according to this installation instruction strictly. If installation is defective, it will cause water leakage, electrical shock or fire.
3. Use the attached accessories parts and specified parts for installation and servicing. Otherwise, it will cause the set to fall, water leakage, fire or electrical shock.
4. Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not properly done, the set will drop and cause injury.
5. For electrical work, follow the local national wiring standard, regulation and the installation instruction. An independent circuit and single outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.
6. Use the specified cable and connect tightly for indoor/outdoor connection. Connect tightly and clamp the cable so that no external force will be acted on the terminal. If connection or fixing is not perfect, it will cause heat-up or fire at the connection.
7. Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it will cause heat-up at connection point of terminal, fire or electrical shock.

8. When connecting the piping, do not allow air or any substances other than the specified refrigerant to enter the refrigeration cycle. Otherwise, this may lower the capacity, cause abnormally high pressure in the refrigeration cycle, and possibly result in explosion and injury.	
9. It is desirable that the amount of residual oil is less than 40 mg/10 m.	
10. Do not modify the length of the power supply cord or use of the extension cord, and do not share the single outlet with other electrical appliances. Otherwise, it will cause fire or electrical shock.	



## CAUTION

1. The equipment must be earthed. It may cause electrical shock if grounding is not perfect.	
2. Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	
3. Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage the furniture.	
4. Pb free solder has a higher melting point than standard solder; typically the melting point is 50 - 70°F (30 - 40°C) higher. Please use a high temperature soldering iron. In case of the soldering iron with temperature control, please set it to 700 ± 20°F (370 ± 10°C). Pb free solder will tend to splash when heated too high (about 1100°F/600°C).	

## ATTENTION

1. Selection of the installation location. Select an installation location which is rigid and strong enough to support or hold the unit, and select a location for easy maintenance.
2. Power supply connection to the conditioner. Connect the power supply cord of the air conditioner to the mains using one of the following methods. Power supply point shall be the place where there is ease for access for the power disconnection in case of emergency. In some countries, permanent connection of this room air conditioner to the power supply is prohibited. 1. Power supply connection to the receptacle using a power plug. Use an approved power plug with earth pin for the connection to the socket. 2. Power supply connection to a circuit breaker for the permanent connection. Use an approved circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.5 mm contact gap.
3. Do not release refrigerant during piping work for installation, servicing, reinstallation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
4. Installation work. It may need two people to carry out the installation work.
5. Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.

## 2 Specifications

### 2.1. CS-PC18GKF CU-PC18GKF

ITEM			UNIT	INDOOR UNIT	OUTDOOR UNIT
Performance Test Condition				NEW JIS	
C O O L I N G	Capacity		kW	5.28 - 5.28	
			BTU/h	18,000 - 18,000	
	EER		W/W	2.65 - 2.58	
			BTU/hW	9.05 - 8.79	
	Noise Level		dB (A)	High 45 - 45, Low 41 - 41	High 54 - 56
Moisture Removal			l/h	2.9	
			pt/h	6.1	
Air Volume	Lo	m³/min (ft³/min)	12.5 (442) - 12.5 (442)	—	
	Me	m³/min (ft³/min)	14.5 (512) - 14.5 (512)	—	
	Hi	m³/min (ft³/min)	15.8 (558) - 15.8 (558)	30.3 (1,070) - 31.3 (1,100)	
Refrigeration Control Device				—	Capillary Tube
Refrigeration Oil			cm³	—	SUNISO 4GDID or ATMOS M60 or ATMOS 56M (450)
Refrigerant (R-22)			g (oz)	—	980 (34.6)
Dimension	Height	mm (inch)	275 (10-13/16)	540 (21-1/4)	
	Width	mm (inch)	998 (39-9/32)	780 (30-23/32)	
	Depth	mm (inch)	230 (9-1/16)	289 (11-3/8)	
Net Weight			kg (lbs)	11.0 (24)	39.0 (86)
Pipe Diameter	Gas	mm (inch)	12.7 (1/2)		
	Liquid	mm (inch)	6.35 (1/4)		
Standard Length			m (ft)	5 (16.4)	
Pipe Length Range			m (ft)	3 (9.8) ~ 25 (82.0)	
Height Difference			m (ft)	20.0 (65.6)	
Additional Gas Amount			g/m (oz/ft)	20 (0.2)	
Refrigeration Charge Less			m (ft)	7.5 (24.6)	
Drain Hose	Inner Diameter		mm	16	—
	Length		mm	650	—
Compressor	Type			—	Rotary (1 cylinder) rolling piston type
	Motor Type			—	Induction (2-poles)
	Rated Output		kW	—	1.5
Fan	Type			Cross-Flow Fan	Propeller Fan
	Material			ASHT-18	PP
	Motor Type			Transistor (8-poles)	Induction (4-poles)
	Input Power		W	—	62 - 70
	Output Power		W	30	35
	Fan Speed	Lo	rpm	1,150 - 1,150	—
		Me	rpm	1,330 - 1,330	—
Hi		rpm	1,450 - 1,450	830 - 855	
Heat Exchanger	Fin Material			Aluminium (Pre Coat)	Aluminium (Blue Coated)
	Fin Type			Slit Fin	Corrugated Fin
	Row x Stage x FPI			2 x 15 x 21	2 x 24 x 16
	Size (W x H x L)		mm	810 x 315 x 25.4	702 x 504 x 25.4 722
Air Filter	Material			P. P. HONEY COMB	—
	Type			One-Touch	—

1. Cooling capacities are based on indoor temperature of 27°C D.B. (80.6°F D.B.), 19.0°C W.B. (66.2°F W.B.) and outdoor air temperature of 35°C D.B. (95°F D.B.), 24°C W.B. (75.2°F W.B.)



Item		Unit	
Power Source (Phase, Voltage, Cycle)		ø	Single
		V	220 - 240
		Hz	50
Input Power		kW	1.99 - 2.05
Starting Current		A	42
Running Current		A	9.8 - 10.0
Power Factor		%	92 - 85
Power factor means total figure of compressor, indoor fan motor and outdoor fan motor.			
*Maximum over current protection		A	15
Power Cord	Number of core		3 (1.5 mm <sup>2</sup> )
	Length	m	1.9
Thermostat			Mechanical Control
Protection Device			Inner Protector

Note

- Specifications are subject to change without notice for further improvement.

## 2.2. CS-PC24GKF CU-PC24GKF

ITEM			UNIT	INDOOR UNIT	OUTDOOR UNIT
Performance Test Condition				NEW JIS	
C O L I N G	Capacity		kW	7.03 - 7.03	
			BTU/h	24,000 - 24,000	
	EER		W/W	2.74 - 2.60	
			BTU/hW	9.34 - 8.89	
	Noise Level		dB (A)	High 48 - 49, Low 42 - 42	High 59 - 61
Moisture Removal			l/h	4.0	
			pt/h	8.5	
Air Volume	Lo		m <sup>3</sup> /min (ft <sup>3</sup> /min)	13.9 (490) - 13.9 (490)	26.6 (940) - 30.2 (1,070)
	Me		m <sup>3</sup> /min (ft <sup>3</sup> /min)	15.5 (550) - 15.5 (550)	—
	Hi		m <sup>3</sup> /min (ft <sup>3</sup> /min)	17.4 (610) - 17.4 (610)	52.0 (1,840) - 54.0 (1,910)
Refrigeration Control Device				—	Capillary Tube
Refrigeration Oil			cm <sup>3</sup>	—	SUNISO 4GDID or ATMOS M60 or ATMOS 56M (1,130)
Refrigerant (R-22)			g (oz)	—	1,400 (49.4)
Dimension	Height		mm (inch)	275 (10-13/16)	750 (29-17/32)
	Width		mm (inch)	998 (39-9/32)	875 (34-7/16)
	Depth		mm (inch)	230 (9-1/16)	345 (13-19/32)
Net Weight			kg (lbs)	11.0 (24)	58.0 (128)
Pipe Diameter	Gas		mm (inch)	15.8 (5/8)	
	Liquid		mm (inch)	6.35 (1/4)	
Standard Length			m (ft)	5 (16.4)	
Pipe Length Range			m (ft)	3 (9.8) ~ 25 (82.0)	
Height Difference			m (ft)	20.0 (65.6)	
Additional Gas Amount			g/m (oz/ft)	30 (0.3)	
Refrigeration Charge Less			m (ft)	7.5 (24.6)	
Drain Hose	Inner Diameter		mm	16	—
	Length		mm	650	—
Compressor	Type			—	Rotary (1 cylinder) rolling piston type
	Motor Type			—	Induction (2-poles)
	Rated Output		kW	—	2.2
Fan	Type			Cross-Flow Fan	Propeller Fan
	Material			ASHT-18	PP
	Motor Type			Transistor (8-poles)	Induction (6-poles)
	Input Power		W	—	148 - 166
	Output Power		W	30	80
	Fan Speed	Lo	rpm	1,310 - 1,310	440 - 500
		Me	rpm	1,460 - 1,460	—
		Hi	rpm	1,640 - 1,640	860 - 890
Heat Exchanger	Fin Material			Aluminium (Pre Coat)	Aluminium (Blue Coated)
	Fin Type			Slit Fin	Corrugated Fin
	Row x Stage x FPI			2 x 15 x 21	2 x 34 x 18
	Size (W x H x L)		mm	810 x 315 x 25.4	815 x 714 x 25.4 835
Air Filter	Material			P. P. HONEY COMB	—
	Type			One-Touch	—

1. Cooling capacities are based on indoor temperature of 27°C D.B. (80.6°F D.B.), 19.0°C W.B. (66.2°F W.B.) and outdoor air temperature of 35°C D.B. (95°F D.B.), 24°C W.B. (75.2°F W.B.)

Item		Unit	
Power Source (Phase, Voltage, Cycle)		ø	Single
		V	220 - 240
		Hz	50
Input Power		kW	2.57 - 2.70
Starting Current		A	67
Running Current		A	12.5 - 12.8
Power Factor		%	93 - 88
Power factor means total figure of compressor, indoor fan motor and outdoor fan motor.			
*Maximum over current protection		A	17.2
Power Cord	Number of core		3 (2.5 mm <sup>2</sup> )
	Length	m	1.9
Thermostat			Mechanical Control
Protection Device			Inner Protector

Note

- Specifications are subject to change without notice for further improvement.


## 3 Features

- **High efficiency**
- **Compact design**
- **Comfort Environment**
  - Air Filter with function to reduce dust and smoke.
  - Wider range of horizontal discharge air.
- **Auto Restart**
  - Random auto restart after power failure for safety restart operation.
- **Removable and washable Front Panel**
- **Quality Improvement**
  - Gas leakage detection.
  - Prevent Compressor reverse cycle.
  - Inner protector.
- **Long Installation Piping**
  - Long piping up to 25 meter.
- **24-hour timer setting**


## 4 Location of Controls and Components

### 4.1. Product Overview


#### 4.1.1. Indoor Unit





#### 4.1.2. Outdoor Unit



#### 4.1.3. Remote Control




\* For normal operation, the  button is not in use.

\* Press  button to restore the remote control's default setting.


## 5 Dimensions

### 5.1. Indoor Unit

#### CS-PC18GKF CS-PC24GKF




Relative position between the indoor unit and the installation plate <Front View>



Unit : mm


## 5.2. Outdoor Unit

### CU-PC18GKF



Unit: mm


CU-PC24GKF






## 6 Refrigeration Cycle Diagram

CS-PC18GKF CU-PC18GKF  
CS-PC24GKF CU-PC24GKF




## 7 Block Diagram

**CS-PC18GKF CU-PC18GKF**  
**CS-PC24GKF CU-PC24GKF**




# 8 Wiring Connection Diagram


## CS-PC18GKF CU-PC18GKF



## CS-PC24GKF CU-PC24GKF




## 9 Electronic Circuit Diagram




# 10 Printed Circuit Board

## 10.1. Main Printed Circuit Board

TOP VIEW



BOTTOM VIEW







### 10.3. Indicator panel

#### TOP VIEW



#### BOTTOM VIEW



# 11 Installation Instruction

## 11.1. CS-PC18GKF CU-PC18GKF

### 11.1.1. Select The Best Location

#### INDOOR UNIT

- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 2.5 m.

#### OUTDOOR UNIT

- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over 7.5m, additional refrigerant should be added as shown in the table.

#### REMOTE CONTROL


- Do not install at place where there is direct sunlight or near any heat source.

Model	Piping size		Rated Length (m)	Max. Elevation (m)	Min. Piping Length (m)	Max. Piping Length (m)	Additional Refrigerant (g/m)
	Gas	Liquid					
C18GK PC18GK	1/2"	1/4"	5	20	3	25	20

Example: For C18GK

If the unit is installed at a 10m distance, the quantity of additional refrigerant should be  $50g \times (10 - 7.5)m \times 20g/m = 50g$


### 11.1.2. Indoor/Outdoor Unit Installation Diagram



### 11.1.3. Indoor Unit

#### 11.1.3.1. HOW TO FIX INSTALLATION PLATE

The mounting wall is strong and solid enough to prevent it from the vibration.



The center of installation plate should be at more than 550 mm at right and left of the wall.

The distance from installation plate edge to ceiling should more than 67 mm.

From installation plate left edge to unit's left side is 47 mm.

From installation plate right edge to unit's right is 73 mm.

- (B)** : For left side piping, piping connection for liquid should be about 126 mm from this line.  
 : For left side piping, piping connection for gas should be about 174 mm from this line.  
 : For left side piping, piping connection cable should be about 984 mm from this line.

1. Mount the installation plate on the wall with 5 screws or more.  
 (If mounting the unit on the concrete wall, consider using anchor bolts.)
  - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
2. Drill the piping plate hole with  $\phi 70$  mm hole-core drill.
  - Line according to the arrows marked on the lower left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely 150 mm and 125 mm for left and right hole respectively.
  - Drill the piping hole at either the right or the left and the hole should be slightly slanted to the outdoor side.


#### 11.1.3.2. TO DRILL A HOLE IN THE WALL AND INSTALL A SLEEVE OF PIPING

1. Insert the piping sleeve to the hole.
2. Fix the bushing to the sleeve.
3. Cut the sleeve until it extrudes about 15 mm from the wall.

##### Caution


When the wall is hollow, please be sure to use the sleeve for tube ass'y to prevent dangers caused by mice biting the connecting cable.

4. Finish by sealing the sleeve with putty or caulking compound at the final stage.




#### 11.1.3.3. INDOOR UNIT INSTALLATION

##### 1. For the right rear piping



##### 2. For the right and right bottom piping



### 3. For the embedded piping

Replace the drain hose



Bend the embedded piping



- Use a spring bender or equivalent to bend the piping so that the piping is not crushed.

Install the Indoor Unit



Cut and flare the embedded piping



- When determining the dimensions of the piping, slide the unit all the way to the left on the installation plate.
- Refer to the section "Cutting and flaring the piping".

Pull the connecting cable into Indoor Unit



- The inside and outside connecting cable can be connected without removing the front grille.

Connect the piping



- Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)

Insulate and finish the piping




- Please refer to "Piping and finishing" column of outdoor section and "Insulation of piping connections" column as mentioned in Indoor/Outdoor Unit Installation.

Secure the Indoor Unit



Install the Indoor Unit

Hook the indoor unit onto the upper portion of installation plate. (Engage the indoor unit with the upper edge of the installation plate). Ensure the hooks are properly seated on the installation plate by moving it in left and right.




Secure the Indoor Unit

1. Power supply cord arrangement.  
Excess length of power supply cord should be arranged behind the chassis at piping keeping area as shown in the diagram without tying up in a bundle.  
Ensure that the power supply cord is not clamped in between unit's hook (2 position) and installation plate.  
Ensure that the power supply cord is not stretched between chassis back and installation plate. It may create squeak sound.
2. Press the lower left and right side of the unit against the installation plate until hooks engages with their slot (sound click).



**Warning** Do not tie up power supply cord into a bundle by band. It may generate heat and cause fire.


Pull out the piping and drain hose




How to keep the cover

In case of the cover is cut, keep the cover at the rear of chassis as shown in the illustration for future reinstallation.


(Left, right and 2 bottom covers for piping.)



Insert the connecting cable






To take out the unit, push the **PUSH** marking at the bottom unit, and pull it slightly towards you to disengage the hooks from the unit.




(This can be used for left rear piping and left bottom piping also.)

Exchange the drain hose and the cap


Rear view for left piping installation



- How to pull the piping and drain hose out, in case of the embedded piping.



- In case of left piping how to insert the connecting cable and drain hose.




#### 11.1.3.4. CONNECT THE CABLE TO THE INDOOR UNIT

1. The inside and outside connecting cable can be connected without removing the front grille.
  2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed  $3 \times 2.5 \text{ mm}^2$  flexible cord, type designation 245 IEC 57 or heavier cord.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
  - Earth lead wire shall be longer than the other lead wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.

Terminals on the indoor unit	1	2	
Colour of wires			
Terminals on the outdoor unit	1	2	


- Secure the cable onto the control board with the holder (clammer).



## 11.1.4. Outdoor Unit

### 11.1.4.1. INSTALL THE OUTDOOR UNIT

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
- Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut ( $\phi 10$  mm).
- When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.



### 11.1.4.2. CONNECTING THE PIPING


#### Connecting The Piping To Indoor Unit

Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe.

(In case of using long piping)

#### Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.



MODEL	Piping size (Torque)	
	Gas	Liquid
C18GK, PC18GK	1/2" (55 N•m)	1/4" (18 N•m)


#### Connecting The Piping To Outdoor Unit

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge. Make flare after inserting the flare nut (locate at valve) onto the copper pipe.


Align center of piping to valves and then tighten with torque wrench to the specified torque as stated in the table.

#### Cutting And Flaring The Piping


- Please cut using pipe cutter and then remove the burrs.
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- Please make flare after inserting the flare nut onto the copper pipes.




1. To cut




2. To remove burrs



3. To flare



#### ■ Improper flaring ■





When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

### 11.1.4.3. AIR PURGING OF THE PIPINGS AND INDOOR UNIT

#### 1) Checking a gas leakage

1. Remove the service port caps from both 3-way valves.
2. Connect the Manifold gauge set to the service port of liquid side 3-way valve.
3. Connect the Charging Cylinder to the Manifold gauge set and open the valve of the Cylinder.
4. Open the low pressure side valve of the Manifold gauge for approx. 10 seconds and then close.
5. Check gas-leakage of the connecting portion of pipings with the gas-leak detector.




#### <For the left pipings>

- 1) Measure the pressure.
- 2) Keep it for 5-10 minutes.
  - Ensure if the pressure indicated on the gauge is as same as that of measured at first time.

#### 2) Air purging

The air remaining in the Refrigeration cycle which contains moisture may cause malfunction on the Compressor.

1. To purge the air, push the pin on the Gas side 3-way valve for three seconds with a Hexagonal wrench and set it free for one minute.
  - Repeat this for three times.
2. To balance the refrigerant, close the low pressure side valve on the Manifold gauge and release refrigerant from the piping through service port until the gauge indicates 0.5 - 0.3 MPa.
3. Set both 3-way valves to open position with the Hexagonal wrench for the unit operation.



### 11.1.4.4. CONNECT THE CABLE TO THE OUTDOOR UNIT

1. Remove the control board cover from the unit by loosening the screw.
2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed  $3 \times 2.5 \text{ mm}^2$  flexible cord, type designation 245 IEC 57 or heavier cord.

Terminals on the indoor unit	1	2	
Colour of wires			
Terminals on the outdoor unit	1	2	

3. Secure the cable onto the control board with the holder (clamber).
4. Attach the control board cover to the original position with the screw.

## 11.2. CS-PC24GKF CU-PC24GKF

### 11.2.1. Select The Best Location

#### INDOOR UNIT

- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 2.5 m.

#### OUTDOOR UNIT

- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over 7.5 m, additional refrigerant should be added as shown in the table.

#### REMOTE CONTROL


- Do not install at place where there is direct sunlight or near any heat source.

Model	Piping size		Rated Length (m)	Max. Elevation (m)	Min. Piping Length (m)	Max. Piping Length (m)	Additional Refrigerant (g/m)
	Gas	Liquid					
C24GK PC24GK	5/8"	1/4"	5	20	3	25	30

Example: For C24GK

If the unit is installed at a 10m distance, the quantity of additional refrigerant should be  $75\text{g} \times (10 - 7.5)\text{m} \times 30\text{g/m} = 75\text{g}$

### 11.2.2. Indoor/Outdoor Unit Installation Diagram






### 11.2.3. Indoor Unit

#### 11.2.3.1. HOW TO FIX INSTALLATION PLATE

The mounting wall is strong and solid enough to prevent it from the vibration.



The center of installation plate should be at more than 550 mm at right and left of the wall.

The distance from installation plate edge to ceiling should more than 67 mm.

From installation plate left edge to unit's left side is 47 mm.

From installation plate right edge to unit's right is 73 mm.

- (B)** : For left side piping, piping connection for liquid should be about 126 mm from this line.  
 : For left side piping, piping connection for gas should be about 174 mm from this line.  
 : For left side piping, piping connection cable should be about 984 mm from this line.

- Mount the installation plate on the wall with 5 screws or more.  
 (If mounting the unit on the concrete wall, consider using anchor bolts.)
  - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
- Drill the piping plate hole with  $\phi 70$  mm hole-core drill.
  - Line according to the arrows marked on the lower left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely 150 mm and 125 mm for left and right hole respectively.
  - Drill the piping hole at either the right or the left and the hole should be slightly slanted to the outdoor side.


#### 11.2.3.2. TO DRILL A HOLE IN THE WALL AND INSTALL A SLEEVE OF PIPING

- Insert the piping sleeve to the hole.
- Fix the bushing to the sleeve.
- Cut the sleeve until it extrudes about 15 mm from the wall.

##### Caution


When the wall is hollow, please be sure to use the sleeve for tube ass'y to prevent dangers caused by mice biting the connecting cable.

- Finish by sealing the sleeve with putty or caulking compound at the final stage.




#### 11.2.3.3. INDOOR UNIT INSTALLATION

##### 1. For the right rear piping



##### 2. For the right and right bottom piping



### 3. For the embedded piping

Replace the drain hose



Bend the embedded piping



- Use a spring bender or equivalent to bend the piping so that the piping is not crushed.

Install the Indoor Unit



Cut and flare the embedded piping



- When determining the dimensions of the piping, slide the unit all the way to the left on the installation plate.
- Refer to the section "Cutting and flaring the piping".

Pull the connecting cable into Indoor Unit



- The inside and outside connecting cable can be connected without removing the front grille.

Connect the piping



- Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)


Insulate and finish the piping



- Please refer to "Piping and finishing" column of outdoor section and "Insulation of piping connections" column as mentioned in Indoor/Outdoor Unit Installation.

Secure the Indoor Unit


Pull out the piping and drain hose




How to keep the cover

In case of the cover is cut, keep the cover at the rear of chassis as shown in the illustration for future reinstallation.

(Left, right and 2 bottom covers for piping.)




Insert the connecting cable





Install the Indoor Unit

Hook the indoor unit onto the upper portion of installation plate. (Engage the indoor unit with the upper edge of the installation plate). Ensure the hooks are properly seated on the installation plate by moving it in left and right.



Secure the Indoor Unit

1. Power supply cord arrangement.  
Excess length of power supply cord should be arranged behind the chassis at piping keeping area as shown in the diagram without tying up in a bundle.  
Ensure that the power supply cord is not clamped in between unit's hook (2 position) and installation plate.  
Ensure that the power supply cord is not stretched between chassis back and installation plate. It may create squeak sound.
2. Press the lower left and right side of the unit against the installation plate until hooks engages with their slot (sound click).



**Warning** Do not tie up power supply cord into a bundle by band. It may generate heat and cause fire.




To take out the unit, push the **[PUSH]** marking at the bottom unit, and pull it slightly towards you to disengage the hooks from the unit.




(This can be used for left rear piping and left bottom piping also.)

Exchange the drain hose and the cap


Rear view for left piping installation



- How to pull the piping and drain hose out, in case of the embedded piping.



- In case of left piping how to insert the connecting cable and drain hose.




#### 11.2.3.4. CONNECT THE CABLE TO THE INDOOR UNIT

1. The inside and outside connecting cable can be connected without removing the front grille.
  2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed  $3 \times 2.5 \text{ mm}^2$  flexible cord, type designation 245 IEC 57 or heavier cord.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
  - Earth lead wire shall be longer than the other lead wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.


Terminals on the indoor unit	1	2	
Colour of wires			
Terminals on the outdoor unit	1	2	

- Secure the cable onto the control board with the holder (clammer).

Indoor




Outdoor



## 11.2.4. Outdoor Unit

### 11.2.4.1. INSTALL THE OUTDOOR UNIT

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
- Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø10 mm).
- When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.



### 11.2.4.2. CONNECTING THE PIPING


#### Connecting The Piping To Indoor Unit

Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe.

(In case of using long piping)

#### Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.



MODEL	Piping size (Torque)	
	Gas	Liquid
C24GK, PC24GK	5/8" (65 N•m)	1/4" (18 N•m)


#### Connecting The Piping To Outdoor Unit

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge. Make flare after inserting the flare nut (locate at valve) onto the copper pipe.


Align center of piping to valves and then tighten with torque wrench to the specified torque as stated in the table.

#### Cutting And Flaring The Piping


- Please cut using pipe cutter and then remove the burrs.
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- Please make flare after inserting the flare nut onto the copper pipes.




1. To cut




2. To remove burrs



3. To flare



#### ■ Improper flaring ■





When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

### 11.2.4.3. AIR PURGING OF THE PIPINGS AND INDOOR UNIT

#### 1) Checking a gas leakage

1. Remove the service port caps from both 3-way valves.
2. Connect the Manifold gauge set to the service port of liquid side 3-way valve.
3. Connect the Charging Cylinder to the Manifold gauge set and open the valve of the Cylinder.
4. Open the low pressure side valve of the Manifold gauge for approx. 10 seconds and then close.
5. Check gas-leakage of the connecting portion of pipings with the gas-leak detector.




#### <For the left pipings>

- 1) Measure the pressure.
- 2) Keep it for 5-10 minutes.
  - Ensure if the pressure indicated on the gauge is as same as that of measured at first time.

#### 2) Air purging

The air remaining in the Refrigeration cycle which contains moisture may cause malfunction on the Compressor.

1. To purge the air, push the pin on the Gas side 3-way valve for three seconds with a Hexagonal wrench and set it free for one minute.
  - Repeat this for three times.
2. To balance the refrigerant, close the low pressure side valve on the Manifold gauge and release refrigerant from the piping through service port until the gauge indicates 0.5 - 0.3 MPa.
3. Set both 3-way valves to open position with the Hexagonal wrench for the unit operation.



### 11.2.4.4. CONNECT THE CABLE TO THE OUTDOOR UNIT

1. Remove the control board cover from the unit by loosening the screw.
2. Connecting cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed  $3 \times 2.5 \text{ mm}^2$  flexible cord, type designation 245 IEC 57 or heavier cord.


Terminals on the indoor unit	1	2	
Colour of wires			
Terminals on the outdoor unit	1	2	

3. Secure the cable onto the control board with the holder (clamber).
4. Attach the control board cover to the original position with the screw.


# 12 Operation and Control

## 12.1. Cooling Operation

- Cooling operation can be set using remote control.
- This operation is applied to cool down the room temperature reaches the setting temperature set on the remote control.
- The remote control setting temperature, which takes the reading of intake air temperature sensor, can be adjusted from 16°C to 30°C.
- During cooling operation, the compressor will stop running and restart as shown in below figure.



### 12.1.1. Cooling Operation Time Diagram




<Description of operation>

- a - b, f - g, l - m, v - w : Minimum 60 seconds forced operation
- d - f, g - i, s - u : Minimum 3 minutes restart control (Time Delay Safety Control)
- g - l : Maximum 7 minutes time save control
- p - v : Anti-Freezing Control
- (×) d - f, g - i, s - u : Indoor fan rotates at Lo- for 20 seconds and off for 160 seconds.
- (+) w-y : Outdoor fan rotates at Lo (Outdoor fan control for PC24GK only)


Operation  
Stop

## 12.2. Soft Dry Operation

- Soft Dry operation can be set using remote control.
- Soft Dry operation is applied to dehumidify and to perform a gentle cooling to the room.
- This operation starts when the intake air temperature sensor reaches the setting temperature on the remote control.
- When operation begins, Soft Dry will be switched “ON” for a maximum 10 minutes, then Soft Dry operation will be turned “OFF” for a minimum 6 minutes. After that, the Soft Dry operation will be “ON” and “OFF” based on the setting temperature as shown in below figure.
- However after 3 minutes of compressor off, during Soft Dry “OFF” (within 6 minutes Soft Dry restart control), the indoor unit will start to operate at normal Cooling mode if the intake temperature is higher than Cooling “ON” point.



### 12.2.1. Soft Dry Operation Time Diagram



<Description of operation>

h – i, l – m, o – p, v – w : Minimum 60 seconds forced operation

n – o : Minimum 3 minutes restart control (Time Delay Safety Control) - Cooling operation

f – h, i – k, s – u : Minimum 6 minutes restart control (Time Delay Safety Control) - Soft dry operation

q – v : Anti-Freezing Control

Operation

Stop

## 12.3. Automatic Operation

- Automatic operation can be set using remote control.
- This operation starts to operate with indoor fan at SLo speed for 20 seconds to judge the intake air temperature.
- After judged the temperature, the operation mode is determined by referring to the below standard.

Intake Air Temperature	↑	Cooling Operation
	↓	Soft Dry Operation

- Then, the unit start to operate at determined operation mode, until it is switched off using remote control, with the setting temperature as shown in below table.

	Setting Temperature (Standard)
Cooling Operation	25°C
Soft Dry Operation	22°C

- The setting temperature for all the operations can be changed one level up or one level down from the standard temperature as shown in below table by pressing on the temperature up or temperature down button at remote control.

	Cooling	Soft Dry
Higher → +2°C	27°C	24°C
Standard → ±0°C	25°C	22°C
Lower → -2°C	23°C	20°C

- The operation mode judging temperature and standard setting temperature can be increased by 2°C permanently, by open the circuit of JX03 at printed circuit board indoor unit.

Intake Air Temperature	↑	Cooling Operation
	↓	Soft Dry Operation

	Setting Temperature (Standard)
Cooling Operation	27°C
Soft Dry Operation	24°C



## 12.4. Operation Control


(For 11.4.1. to 11.4.7. information applies only to Cooling and Soft Dry Operation)

### 12.4.1. Restart Control (Time Delay Safety Control)

- When the thermo-off temperature (temperature which compressor stops to operate) is reached during:-
  - Cooling operation - the compressor stops for 3 minutes (minimum) before resume operation.
  - Soft Dry operation - the compressor stops for 6 minutes (minimum) before resume operation.
- If the operation is stopped by the remote control, the compressor will not turn on within 3 minutes from the moment operation stop, although the unit is turn on again within the period.
- This phenomenon is to balance the pressure inside the refrigerant cycle.

### 12.4.2. 7 Minutes Time Save Control

- The compressor will start automatically if it has stopped for 7 minutes and the intake air temperature falls between the compressor ON temperature (A) and compressor OFF temperature (B) during the period.
- This phenomenon is to reduce the built up humidity inside a room.




### 12.4.3. 60 Seconds Forced Operation

- Once the air conditioner is turned on, the compressor will not stop within 60 seconds in a normal operation although the intake air temperature has reached the thermo-off temperature. However, force stop by pressing the OFF/ON operation button at the remote control is permitted.
- The reason for the compressor to force operate at minimum 60 seconds is to allow the refrigerant oil run in a full cycle and return back to the outdoor unit.

### 12.4.4. Anti-Freezing Control

- If the temperature of the indoor heat exchanger falls below 2°C continuously for 4 minutes or more, the compressor turns off. The fan speed setting remains the same.
- This phenomenon is to protect the indoor heat exchanger from freezing and to prevent higher volume of refrigerant in liquid form returning to the compressor.
- Compressor will restart again when the indoor heat exchanger temperature rises to 10°C (Recovery).
- Restart control (Time Delay Safety Control) will be applied in this Control if the recovery time is too short.



### 12.4.5. Compressor Reverse Rotation Protection Control

- If the compressor is operating continuously for 5 minutes or longer and the temperature difference between intake air and indoor heat exchanger is  $2.5^{\circ}\text{C}$  or less for continuous 2 minutes, compressor will stop and restart automatically.
- Time Delay Safety Control is activated before the compressor restart.



▲ T = Intake air temperature - Indoor heat exchanger temperature


- This is to prevent compressor from rotate reversely when there is an instantaneous power failure.

### 12.4.6. Starting Current Control

- When the compressor, outdoor fan motor and indoor fan motor are simultaneously started, the indoor fan motor will start to operate at 1.6 second later.
- The reason of the difference is to reduce the starting current flow.


### 12.4.7. Anti-Dew Formation Control

- Purpose is to prevent dew formation on indoor unit air discharge area.
- When room temperature is constant ( $\pm 1^{\circ}\text{C}$ ) the following conditions occur for 30 minutes continuously, anti-dew formation will activate:
  - Remote Control setting temperature is less than  $25^{\circ}\text{C}$ .
  - Compressor is on.
  - Cooling operation mode.
  - Indoor Fan motor operate at Low fan speed or QLo.
- This control is cancelled immediately when above condition is changed.
- Anti-Dew formation is control by:
  1. Increasing Air Flow Volume
    - a. Lo fan speed
      - Lo fan speed is changed to Lo+ after 30 min to prevent dew formation.



#### b. QLo fan speed


Dew formation may occurs at QLo cool, therefore QLo cool is operated only 1 hr 30 min (1 hr QLo, 30 min QLo +100 rpm). After that, it operates at QLo +180rpm (However Quiet LED remains on).




## 2. Narrowing

### Vertical Airflow Direction

- During Anti-dew condensation prevention, Airflow Direction Auto-control angle change from 10° - 38° to 10° - 27° under Cooling and Soft Dry operation mode.



- During Anti-dew condensation prevention, Airflow Direction Manual control angle change from 10°, 14°, 18°, 22°, 27° to 10°, 13°, 16°, 19°, 22° under Cooling and Soft Dry operation mode.



## 12.5. Indoor Fan Speed Control

- Indoor Fan Speed can be set using remote control.

### 12.5.1. Fan Speed Rotation Chart

COOL/DRY	CS-PC24GKF	CS-PC18GKF
Hi	1640	1450
Me	1460	1330
Lo+	1400	1280
Lo	1310	1150
Lo-	1100	980
SLo	860	780


### 12.5.2. Automatic Fan Speed Control

- When set to Auto Fan Speed, the fan speed is adjusted between maximum and minimum setting as shown in the table.
  - Fan speed rotates in the range of Hi, Me and Lo-.
  - Deodorizing Control will be activated.

Tap			SHi	Hi	Me	Lo+	CLo	Lo-	SLo	Stop
Cooling	Normal	Manual	Hi	○						
			Me		○					
			Lo			○				
		Auto			○	○		○		○
Soft Dry		Manual					○		○	
		Auto					○		○	
Auto Mode judgement									○	

- Auto Fan Speed during Cooling operation:


1. Indoor fan will rotate alternately between off and on as shown in below diagram.
2. At the beginning of each compressor start operation, indoor fan will increase fan speed gradually for deodorizing purpose.
3. For the first time the compressor operate, indoor fan will be switched to Hi fan speed from Lo- after 70 seconds from the start of compressor. This cause the room temperature to achieve the setting temperature quickly.
4. During compressor stop, indoor fan will operate at Lo- for the beginning 20 seconds to prevent higher volume of refrigerant in liquid form returning to the compressor.
5. After the compressor at turn off condition for 3 minutes, indoor fan will start to operate at Lo- to circulate the air in the room.  
This is to obtain the actual reading of the intake air temperature.
6. For the resume of compressor operation, indoor fan will operate at Me fan speed to provide comfort and lesser noise environment, after 70 seconds from the restart of compressor.



- ※ 1 Fan Speed is Hi until the compressor stops (when the room temperature reaches setting temperature).
- ※ 2 Fan Speed is Me after the compressor restarts.
- ※ 3 Variable rpm is equivalent to Lo- rpm.

- Auto Fan Speed during Soft Dry operation:

1. Indoor fan will rotate alternately between off and Lo-.
2. At the beginning of each compressor start operation, indoor fan will increase fan speed gradually for deodorizing purpose.
3. When compressor at turn off condition for 6 minutes, indoor fan will start fan speed at Lo- to circulate the air in the room.  
This is to obtain the actual reading of intake air temperature.



### 12.5.3. Manual Fan Speed Control

- Manual fan speed adjustment can be carried out by using the Fan Speed selection button at the remote control.
- There are 3 types of fan speed settings: Lo, Me, Hi.


## 12.6. Outdoor Fan Speed Control

- There is 2 speed for outdoor fan motor. Outdoor fan speed can be changed to Hi or Lo according to outdoor temperature.
- For Cooling or Soft Dry operation when outdoor temperature reaches to 31°C (Hi-speed), 29°C (Lo-speed).
- When the air conditioner is turned on, the compressor and the outdoor fan will operate simultaneously.
- Likewise, both compressor and outdoor fan will stop at the same time if the unit is turned off.

## 12.7. Vertical Airflow Direction Control


### 12.7.1. Auto Control

- When the vertical airflow direction is set to Auto using the remote control, the louver swings up and down as shown in the diagram.
- When stopped with remote control, the discharge vent is reset, and stop at the closing position.
- During Cooling operation or Soft Dry operation, indoor fan motor may stop to rotate at certain periods. At that condition, the louver will stop swinging and rest at the upper limit.



### 12.7.2. Manual Control

- When the vertical airflow direction is set to Manual using the remote control, the automatic airflow is released and the airflow direction louver move up and down in the range shown in the diagram.
- The louver can be adjusted by pressing the button to the desired louver position.
- When stopped with remote control, the discharge vent is reset, and stop at the closing position.



## 12.8. Timer Control

### 12.8.1. ON Timer

- When the ON Timer is set by using the remote control, the unit will start to operate slightly before the set time, so that the room will reach nearly to the set temperature by the set time.
- For Cooling and Soft Dry operation, the operation will start 15 minutes before the set time.
- For Automatic operation, the indoor fan will operate at SLo speed for 20 seconds, 15 minutes before the set time to detect the intake air temperature to determine the operation mode. The operation indication lamp will blink at this time.

### 12.8.2. OFF Timer

- When the OFF Timer is set by using the remote control, the unit will stop operate according to the desired setting.

#### Notes

1. By pressing ON/OFF operation button, the ON Timer or OFF Timer setting will not be cancelled.
2. To cancel the previous timer setting, press CANCEL button.
3. To activate the previous timer setting, press SET button.
4. If main power supply is switched off, the Timer setting will be cancelled.

## 12.9. Random Auto Restart Control

- If there is a power failure during operation, the air conditioner will automatically restart after 3 to 4 minutes when the power is resumed.
- It will start with previous operation mode and airflow direction.
- If there are more than one air conditioner unit in operation and power failure occur, restart time for each unit to operate will be decided randomly using 4 parameters:- intake air temperature, setting temperature, fan speed and air swing louver position.
- This Random Auto Restart Control is not available when Timer is set.
- This control can be omitted by open the circuit of JX02. (Refer printed circuit board indoor unit)


## 12.10. Remote Control Signal Receiving Sound

- Long beep sound will be heard when:
  - Stopping the air conditioner using ON/OFF switch.
- Short beep sound will be heard for others setting.

# 13 Servicing Mode

## 13.1. Auto OFF/ON Button

- The “Auto OFF/ON Button” (behind the front grille) is used to operate the air conditioner if remote control is misplaced or malfunctioning.
- Forced cooling operation is possible by pressing the “Auto OFF/ON Button” for more than 5s where “beep” sound is heard then release the button.
- User able to select remote control transmission code and toggle remote control signal receiving sound under various setting mode.
- To enter various setting mode:
  - Press the “Auto OFF/ON Button” continuously for 5s (beep sound is heard) and release.
  - Within 20s, press the “Auto OFF/ON Button” continuously for 5s again (2 beep sound is heard) and release.
  - Various setting mode has limit up to 20s. Then return to normal operation.




### 13.1.1. Toggle Remote Control Signal Receiving Sound

- Under various setting mode, press the “Auto OFF/ON Button” to toggle the remote control sound.
  - Short “beep”: Turn ON remote control signal receiving sound.
  - Long “beep”: Turn OFF remote control signal receiving sound.
- After “Auto OFF/ON Button” is pressed, the 20s counter for various setting mode is restarted.

### 13.1.2. Select Remote Control Transmission Code

- There are 4 type of remote control transmission code could be selected and stored in EEPROM of indoor unit. The indoor unit will only operate when received signal with same transmission code from remote control. This could prevent signal interference when there are 2 or more indoor unit installed nearby together.
- To change remote control transmission code, short or open jumpers at the remote control printed circuit board.

Remote Control Printed Circuit Board	Transmission Code Combination		
	J-A	J-B	Remote Control No.
	* Short	Open	A (default)
	Open	Open	B
	Short	Short	C
	Open	Short	D

- Under various setting mode, after select the transmission code combination of remote control, press any button of remote control to transmit a signal to indoor unit. The transmission code will be stored in EEPROM.
- After signal is received, the various setting mode is cancelled and return to normal operation.

## 13.2. Remote Control Button

### 13.2.1. SET

- To change the type of remote control transmission signal (there are totally four types of transmission codes)
  - Modify the jumper (back of PCB) & connector (front of PCB) at remote control PCB.
  - Press with pointer for more than 10 seconds.
  - Face the transmitter towards indoor unit receiver and press the timer SET button (to send the signal) or if the timer SET button is not pressed for 30 seconds, the setting mode is cancelled.
  - Press timer CANCEL button to exit the setting mode.

### 13.2.2. CLOCK

- To change the remote control's clock-hour and minute.
  - Press once to enter the clock setting mode.
  - Use timer increment button timer decrement button to change the time.
  - Press once again to exit the setting mode.

### 13.2.3. RESET

- To clear and restore the remote control setting to factory default.
  - Press once to clear the memory.

## 13.3. Test Mode Timer Table

Name		Time	Test Mode (When test point Short-circuited)	Remarks
Real Timer		1 hr.	1 min.	
		10 min	10 sec.	
		1 min.	1 sec.	
Timer Delay Safety Control		2 min. 58 sec.	0 sec.	
Forced Operation		60 sec.	0 sec.	
Timer Save Control		7 min.	42 sec.	
Anti-Freezing		4 min.	0 sec.	
Auto Mode Judgement		20 sec.	0 sec.	
Soft Dry	OFF	6 min.	36 sec.	Soft Dry: 10 min. operation
	ON	10 min.	60 sec.	
Deodorizing Control	Cooling	40 sec.	4 sec.	
		70 sec.	7 sec.	
		20 sec.	2 sec.	
		180 sec.	18 sec.	
	Soft Dry	40 sec.	4 sec.	
		360 sec.	36 sec.	
Comp. Reverse Rotation Detection		5 min.	30 sec.	Com. ON 5 min. and above
		2 min.	0 sec.	
Comp./ Fan Motor Delay Timer		1.6 sec.	0 sec.	
Random Auto Restart Control		0 ~ 62 sec.	0 ~ 6.2 sec.	

# 14 Troubleshooting Guide


## 14.1. Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal outlet air temperature and pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure and Outlet Air Temperature (Standard)

	Gas pressure Mpa (kg/cm <sup>2</sup> G)	Outlet air temperature (°C)
Cooling Mode	0.4 ~ 0.6 (4 ~ 6)	12 ~ 16

\* Condition: Indoor fan speed; High  
Outdoor temperature: 35°C





### 14.1.1. Relationship between the condition of the air conditioner and pressure and electric current

Condition of the air conditioner	Cooling Mode		
	Low Pressure	High Pressure	Electric current during operating
Insufficient refrigerant (gas leakage)	↘	↘	↘
Clogged capillary tube or Strainer	↘	↘	↘
Short circuit in the indoor unit	↘	↘	↘
Heat radiation deficiency of the outdoor unit	↗	↗	↗
Inefficient compression	↗	↘	↘

- Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

### 14.1.2. Diagnosis methods of a malfunction of a compressor

Nature of fault	Symptom
Insufficient compressing of a compressor	<ul style="list-style-type: none"> <li>• Electric current during operation becomes approximately 20% lower than the normal value.</li> <li>• The discharge tube of the compressor becomes abnormally hot (normally 70 to 90°C).</li> <li>• The difference between high pressure and low pressure becomes almost zero.</li> </ul>
Locker compressor	<ul style="list-style-type: none"> <li>• Electric current reaches a high level abnormally, and the value exceeds the limit of an ammeter. In some cases, a breaker turns off.</li> <li>• The compressor has a humming sound.</li> </ul>

# 15 Disassembly and Assembly Instructions

## 15.1. Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures

### 15.1.1. To remove the Front Grille

- Remove the 3 caps and 3 screws at the bottom of the Front Grille. (Fig. 1)
- Remove the Front Grille by releasing the 3 hooks at the top of the Front Grille. (Fig. 1)




Fig. 1

- Unhook the tabs at the Control Board to remove the Control Board Cover. (Fig. 2)




Fig. 2

### 15.1.2. To remove the Main Electronic Controller

- Release the 2 Particular Piece. (Fig. 3)
- Release the Indicator. (Fig. 3)
- Release the 2 screws for the earth wire. (Fig. 3)
- Release the screw Holder Terminal Board. (Fig. 3)




Fig. 3

- Release the hooks that hold the Main Electronic Controller and pull out the Main Electronic Controller. (Fig. 4)




Fig. 4

- Release the CN-DATA1 connector. (Fig. 5)
- Release the CN-STM1 connector. (Fig. 5)
- Release the CN-TH connector. (Fig. 5)




Fig. 5

### 15.1.3. To remove the Power Electronic Controller

- Release the hook that hold the Particular Piece and pull out the Power Electronic Controller. (Fig. 6)




Fig. 6

- Release the AC-303 connector. (Fig. 7)
- Release the CN-FM connector. (Fig. 7)
- Release the 2 connector P Terminal (BROWN) and L Terminal (BLACK) at the RY-PWR.




Fig. 7

### 15.1.4. To remove the Discharge Grille

- Pull out the Drain Hose (behind the Discharge Grille) from outlet to remove the Discharge Grille. (Fig. 8)



Fig. 8

### 15.1.5. To remove the Control Board

- Release the 3 screws. (Fig. 9)
- By pressing down the hook at the left, you will be able to remove the Control Board. (Fig. 9)



Fig. 9

### 15.1.6. To remove the Cross Flow Fan and Indoor Fan Motor

- Remove the screw at the Cross Flow Fan. (Fig. 10)

Reminder:-

To reinstall the Fan Motor, please adjust the connector location is positioned 90° with Fan Motor before fixing Control Board. (Fig. 10)




Fig. 10

- Remove the Bearing. (Fig. 11)
- Remove the screws at the left of the Evaporator. (Fig. 11)




Fig. 11

- Push up the Evaporator and pull out the Cross Flow Fan from shaft. By then, Fan Motor can be taken out. (Fig. 12)





Fig. 12

# 16 Technical Data


## 16.1. Thermostat Characteristics

### CS-PC18GKF CS-PC24GKF

- Cooling



- Soft Dry







16.2. Operation Characteristics

CS-PC18GKF CU-PC18GKF


• Cooling Characteristic

[Condition] Room temperature: 27/19°C  
Operation condition: High fan speed  
Piping length: 5 m



## • Pipe Length Characteristic


[Condition] Room temperature: 27/19°C  
 Operation condition: High fan speed  
 Outdoor temperature: 35/24°C



CS-PC24GKF CU-PC24GKF

• Cooling Characteristic


[Condition] Room temperature: 27/19°C  
Operation condition: High fan speed  
Piping length: 5 m





## • Pipe Length Characteristic

[Condition] Room temperature: 27/19°C  
 Operation condition: High fan speed  
 Outdoor temperature: 35/24°C



## 16.3. Fan Performance

CS-PC18GKF CU-PC18GKF			Hi	Me	Lo
Indoor	Fan Speed	rpm	1450	1330	1150
	Air Flow	m <sup>3</sup> /min	15.5	14.5	13.0
		ft <sup>3</sup> /min	547	512	459
Outdoor	Fan Speed	rpm	830		
	Air Flow	m <sup>3</sup> /min	34.0		
		ft <sup>3</sup> /min	1200		

CS-PC24GKF CU-PC24GKF			Hi	Me	Lo
Indoor	Fan Speed	rpm	1640	1460	1310
	Air Flow	m <sup>3</sup> /min	17.5	15.9	14.6
		ft <sup>3</sup> /min	618	561	515
Outdoor	Fan Speed	rpm	890		
	Air Flow	m <sup>3</sup> /min	55.8		
		ft <sup>3</sup> /min	1970		

## 16.4. Cooling Capacity Performance Data



### CS/CU-PC18GKF

Indoor intake air ambient temperature		Outdoor intake air ambient temperature (D.B./°C)																	
		25°C			30°C			35°C			40°C			43°C			52°C		
		TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT
DB	WB	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW
23	17	5.50	3.74	1.63	5.28	3.79	1.77	4.97	3.67	1.93	4.60	3.52	2.12	4.32	3.41	2.24	3.89	2.82	2.65
	19	5.81	3.15	1.73	5.62	3.17	1.87	5.34	3.12	2.04	4.97	3.02	2.24	4.72	2.96	2.37	4.36	2.79	2.88
	22	6.34	2.43	1.87	6.17	2.50	2.03	5.89	2.51	2.21	5.51	2.46	2.42	5.25	2.45	2.57	4.74	2.42	3.26
25	17	5.43	4.42	1.63	5.22	4.36	1.76	4.91	4.21	1.92	4.56	4.05	2.10	4.31	3.92	2.22	3.94	3.22	2.63
	19	5.81	3.90	1.74	5.61	3.88	1.88	5.30	3.79	2.04	4.94	3.66	2.23	4.69	3.56	2.37	4.32	3.26	2.92
	22	6.34	3.07	1.88	6.14	3.10	2.03	5.84	3.08	2.21	5.79	2.98	2.41	5.20	2.96	2.56	4.73	2.87	3.25
27	17	5.36	5.08	1.64	5.16	5.00	1.76	4.87	4.81	1.92	4.52	4.62	2.08	4.28	4.51	2.21	3.93	3.83	2.62
	19	5.82	4.58	1.75	5.60	4.53	1.89	5.28	4.38	2.05	4.91	4.24	2.27	4.65	4.11	2.36	4.24	3.71	2.72
	22	6.33	3.71	1.89	6.12	3.71	2.03	5.80	3.64	2.21	5.39	3.50	2.40	5.15	3.45	2.55	4.70	3.29	3.24
29	17	5.35	5.58	1.62	5.16	5.44	1.76	4.86	5.17	1.89	4.57	4.86	2.03	4.34	4.62	2.12	4.04	3.61	2.42
	19	5.81	5.26	1.74	5.60	5.19	1.88	5.28	5.00	2.03	4.95	4.82	2.17	4.70	4.70	2.26	4.36	4.32	2.62
	22	6.30	4.39	1.91	6.09	4.37	2.07	5.76	4.26	2.23	5.39	4.13	2.39	5.14	4.05	2.49	4.65	3.82	2.99
32	17	5.35	5.58	1.62	5.16	5.49	1.75	4.52	4.81	1.88	4.59	4.88	2.00	4.37	4.65	2.07	4.09	3.67	2.27
	19	5.80	6.11	1.73	5.60	5.96	1.88	5.28	5.62	2.01	4.97	5.29	2.14	4.74	5.05	2.21	4.45	4.35	2.48
	22	6.29	5.49	1.94	6.08	5.43	2.10	5.75	5.26	2.25	5.39	5.11	2.39	5.14	4.98	2.46	4.65	4.59	2.86

TC : Cooling Capacity (kW)

SHC : Sensible Heat Capacity (kW)


IPT : Cooling Power Consumption (kW)




CS/CU-PC24GKF

Indoor intake air ambient temperature		Outdoor intake air ambient temperature (D.B./°C)																	
		25°C			30°C			35°C			40°C			43°C			52°C		
		TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT	TC	SHC	IPT
DB	WB	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW	KW
23	17	7.32	4.38	2.15	7.03	4.44	2.33	6.62	4.30	2.54	6.12	4.12	2.79	5.75	3.99	2.95	5.18	3.30	3.49
	19	7.73	3.68	2.28	7.48	3.71	2.46	7.11	3.65	2.69	6.62	3.53	2.95	6.28	3.47	3.12	5.80	3.27	3.80
	22	8.44	2.84	2.46	8.21	2.93	2.67	7.84	2.94	2.91	7.33	2.88	3.19	6.99	2.87	3.38	6.31	2.84	4.29
25	17	7.24	5.17	2.15	6.95	5.10	2.32	6.54	4.93	2.53	6.07	4.75	2.76	5.73	4.59	2.93	5.24	3.77	3.47
	19	7.73	4.57	2.29	7.47	4.54	2.47	7.06	4.43	2.69	6.58	4.28	2.94	6.24	4.17	3.12	5.76	3.82	3.84
	22	8.44	3.59	2.47	8.18	3.63	2.67	7.78	3.60	2.91	7.71	3.49	3.18	6.92	3.46	3.37	6.30	3.36	4.28
27	17	7.14	5.95	2.16	6.87	5.85	2.32	6.48	5.64	2.53	6.02	5.42	2.74	5.70	5.28	2.91	5.24	4.48	3.45
	19	7.74	5.36	2.30	7.45	5.30	2.48	7.03	5.13	2.70	6.54	4.96	2.99	6.19	4.81	3.11	5.64	4.34	3.59
	22	8.43	4.34	2.48	8.14	4.34	2.68	7.72	4.26	2.92	7.17	4.10	3.16	6.86	4.04	3.36	6.26	3.85	4.26
29	17	7.13	6.54	2.14	6.87	6.37	2.32	6.47	6.05	2.49	6.08	5.69	2.68	5.78	5.41	2.80	5.37	4.23	3.18
	19	7.73	6.15	2.29	7.45	6.07	2.47	7.03	5.86	2.67	6.59	5.65	2.86	6.26	5.51	2.98	5.81	5.06	3.45
	22	8.39	5.14	2.52	8.11	5.12	2.73	7.67	4.99	2.94	7.18	4.84	3.15	6.85	4.75	3.28	6.20	4.47	3.93
32	17	7.12	6.53	2.13	6.87	6.43	2.31	6.01	5.63	2.47	6.11	5.72	2.64	5.82	5.45	2.72	5.45	4.29	3.00
	19	7.72	7.16	2.28	7.45	6.97	2.47	7.03	6.58	2.65	6.62	6.19	2.82	6.32	5.91	2.91	5.93	5.09	3.26
	22	8.37	6.43	2.55	8.09	6.36	2.76	7.66	6.16	2.96	7.18	5.98	3.14	6.85	5.83	3.24	6.20	5.38	3.77


TC : Cooling Capacity (kW)  
SHC : Sensible Heat Capacity (kW)  
IPT : Cooling Power Consumption (kW)






## 16.5. Sound Data

CS-PC18GKF






# 17 Exploded View and Replacement Parts List

## 17.1. Indoor Unit

CS-PC18GKF CS-PC24GKF



### Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.

REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-PC18GKF	CS-PC24GKF	REMARKS
1	CHASSY COMPLETE	1	CWD50C1394	←	
2	FAN MOTOR	1	CWA981149J	←	O
3	CROSS FLOW FAN COMPLETE	1	CWH02C1010	←	
4	SCREW - CROSS FLOW FAN	1	CWH551146	←	
5	BEARING ASS'Y	1	CWH64K007	←	
6	EVAPORATOR	1	CWB30C1574	CWB30C1854	
7	FLARE NUT (1/4")	1	CWT251026	←	
8	FLARE NUT (1/2") (5/8")	1	CWT251035	CWT251036	
9	INTAKE AIR SENSOR HOLDER	1	CWH32143	←	
10	DISCHARGE GRILLE COMPLETE	1	CWE20C2340	←	
11	VERTICAL VANE	16	CWE241088	←	
12	CONNECTING BAR	1	CWE261025	←	
14	AIR SWING MOTOR	1	CWA98K1008	←	O
15	LEAD WIRE - AIR SWING MOTOR	1	CWA67C4445	←	
16	HORIZONTAL VANE	1	CWE241152A	←	
17	HORIZONTAL VANE	1	CWE241153A	←	
18	CAP - DRAIN TRAY	1	CWH52C1001	←	
19	BACK COVER CHASIS	1	CWD932162B	←	
20	CONTROL BOARD CASING	1	CWH102291	←	
21	TERMINAL BOARD COMPLETE	1	CWA28C2153	CWA28C2154	O
22	POWER SUPPLY CORD	1	CWA20C2508	CWA20C2530	
23	ELECTRONIC CONTROLLER - MAIN	1	CWA73C2661	CWA73C2662	O
23a	ELECTRONIC CONTROLLER - POWER	1	CWA744053	←	O
24	INDICATOR COMPLETE	1	CWE39C1120	←	O
25	INDICATOR HOLDER	1	CWD932435	←	
26	INDICATOR HOLDER	1	CWD932436	←	
27	SENSOR COMPLETE	1	CWA50C2122	←	O
28	CONTROL BOARD TOP COVER	1	CWH131209	←	
29	CONTROL BOARD FRONT COVER	1	CWH131210	←	
30	REMOTE CONTROL COMPLETE	1	CWA75C2825	←	O
31	FRONT GRILLE COMPLETE	1	CWE11C3140	←	O
32	INTAKE GRILLE COMPLETE	1	CWE22C1159	←	
33	GRILLE DOOR	1	CWE141076	←	
34	AIR FILTER (L)	1	CWD001137	←	
35	AIR FILTER (R)	1	CWD001138	←	
36	SCREW - FRONT GRILLE	3	XTT4+16CFJ	←	
37	CAP - FRONT GRILLE	3	CWH521062A	←	
38	DRAIN HOSE	1	CWH851063	←	
39	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C067	←	
40	INSTALLATION PLATE	1	CWH36K1007	←	
41	FULCRUM	2	CWH621047	←	


(NOTE)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 061).
- "O" marked parts are recommended to be kept in stock.



## 17.2. Outdoor Unit

### CU-PC18GKF



#### Note


The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.

REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-PC18GKF	REMARKS
1	CHASSY ASS'Y	1	CWD50K2088	
2	SOUND PROOF MATERIAL	1	CWG302410	
3	FAN MOTOR BRACKET	1	CWD541030	
4	SCREW - FAN MOTOR BRACKET	2	CWH551198	
5	FAN MOTOR	1	CWA951264J	O
6	SCREW - FAN MOTOR MOUNT	4	CWH55406J	
7	PROPELLER FAN ASS'Y	1	CWH03K1006	
8	NUT - PROPELLER FAN	1	CWH56053J	
9	COMPRESSOR	1	2KS324D5BG04	O
10	ANTI - VIBRATION BUSHING	3	CWH50055	
11	NUT - COMPRESSOR MOUNT	3	CWH561049	
12	CONDENSER	1	CWB32C1770	
13	TUBE ASS'Y (CAPILLARY TUBE)	1	CWB15K1208	
14	2-WAY VALVE	1	CWB02306	
15	HOLDER COUPLING ASS'Y	1	CWH351046	
16	3-WAY VALVE (LIQUID)	1	CWB011397	O
17	3-WAY VALVE (GAS)	1	CWB011482	O
20	TERMINAL COVER	1	CWH171012	
21	NUT- TERMINAL COVER	1	CWH7080300J	
22	SOUND PROOF BOARD	1	CWH151023	
24	TERMINAL BOARD ASS'Y	1	CWA28K1033J	
25	CAPACITOR - COMPRESSOR	1	DS441456CPND	O
26	HOLDER CAPACITOR	1	CWH30071	
27	CAPACITOR - FAN MOTOR	1	DS441205NPQA	O
28	CABINET SIDE PLATE (L)	1	CWE041248A	
29	CABINET SIDE PLATE (R)	1	CWE04C1120	
30	CABINET FRONT PLATE	1	CWE06K1034	
32	CABINET TOP PLATE	1	CWE031014A	
33	CONTROL BOARD COVER	1	CWH131295	
34	CONTROL BOARD COVER COMPLETE	1	CWH13C1064	
35	HANDLE	1	CWE161010	
36	OPERATION INSTRUCTIONS	1	CWF565510	
37	INSTALLATION INSTRUCTIONS	1	CWF613112	
38	WIRE NET	1	CWD041111A	
39	STRAINER	1	CWB11025	
40	THERMOSTAT	1	CWA151045	
41	V-COIL COMPLETE	1	CWA43C2219	

(NOTE)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 061).
- "O" marked parts are recommended to be kept in stock.

# CU-PC24GKF



## Note

The above exploded view is for the purpose of parts disassembly and replacement.  
The non-numbered parts are not kept as standard service parts.

REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-PC24GKF	REMARKS
1	CHASSY ASS'Y	1	CWD50K2100	
2	COMPRESSOR	1	2JS438D3GA02	O
3	ANTI - VIBRATION BUSHING	3	CWH50055	
4	NUT - COMPRESSOR UNIT	3	CWH561049	
5	PACKING	3	CWB81043	
6	CONDENSER	1	CWB32C1577	
7	SOUND PROOF BOARD ASS'Y	1	CWH151056	
8	FAN MOTOR BRACKET	1	CWD541065	
9	SCREW - FAN MOTOR BRACKET	2	CWH551198	
10	FAN MOTOR	1	CWA951354J	O
11	SCREW - FAN MOTOR MOUNT	3	CWH55252J	
12	PROPELLER FAN ASS'Y	1	CWH03K1017	
13	NUT - PROPELLER FAN	1	CWH561038J	
14	HOLDER COUPLING	1	CWH351036	
15	3-WAY VALVE (LIQUID)	1	CWB011161	O
16	TUBE ASS'Y (CAPILLARY TUBE)	1	CWT024668	
17	3-WAY VALVE (GAS)	1	CWB011213	O
18	TERMINAL COVER	1	CWH171012	
19	NUT- TERMINAL COVER	1	CWH7080300J	
21	CAPACITOR - F.M	1	DS441505NPQB	O
22	CAPACITOR - COMP	1	CWA312079	O
23	HOLDER CAPACITOR	1	CWH30060	
24	TERMINAL BOARD ASS'Y	1	CWA28K1064J	
25	CABINET SIDE PLATE (L)	1	CWE041082A	
26	HANDLE	1	CWE161010	
27	CABINET SIDE PLATE (R)	1	CWE04C1127	
28	HANDLE	2	CWE16000E	
29	CABINET FRONT PLATE ASS'Y	1	CWE06K1045	
30	WIRE NET COMPLETE	1	CWD041041A	
31	CABINET TOP PLATE ASS'Y	1	CWE03K1011A	
32	CONTROL BOARD COVER	1	CWH131168	
33	CONTROL BOARD COVER COMPLETE	1	CWH131169A	
34	OPERATION INSTRUCTIONS	1	CWF565510	
35	INSTALLATION INSTRUCTIONS	1	CWF613085	
36	THERMOSTAT	1	CWA151040	O
37	STRAINER	1	CWB11025	
38	SOUND PROOF MATERIAL	2	CWG302230	

(NOTE)

- All parts are supplied from PHAAM, Malaysia (Vendor Code: 061).
- "O" marked parts are recommended to be kept in stock.