
Service Manual

Air Conditioner



Indoor Unit CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE CS-UE18QKE Outdoor Unit CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE CU-UE18QKE

> Destination Europe E.Europe Turkey

/ WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by \triangle in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

PRECAUTION OF LOW TEMPERATURE

In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

Panasonic[®]

© Panasonic Corporation 2013.

TABLE OF CONTENTS

1.	Safety Precautions3							
2.	Specifications5							
3.	Features1	4						
4.	Location of Controls and Components1	5						
4 4 4		5						
5.	Dimensions1	6						
_	1 Indoor Unit & Remote Control							
6.	Refrigeration Cycle Diagram2	0						
7.	Block Diagram2	1						
7	1 CS-YE9QKE CU-YE9QKE CS-YE12QKE CU-YE12QKE CS-UE9QKE CU-UE9QKE CS-UE12QKE CU-UE12QKE2 2 CS-UE18QKE CU-UE18QKE2							
8.	Wiring Connection Diagram2	3						
8 8	1 Indoor Unit							
9.	Electronic Circuit Diagram2	7						
-	1 Indoor Unit2 2 Outdoor Unit2							
10.	Printed Circuit Board3	1						
	0.1 Indoor Unit3 0.2 Outdoor Unit3							
11.	Installation Instruction3	6						
1	1.1 Select the Best Location	7						
12.	Operation Control4	5						
1 1 1 1 1	2.1 Basic Function 4 2.2 Indoor Fan Motor Operation 4 2.3 Outdoor Fan Motor Operation 4 2.4 Airflow Direction 4 2.5 ON Timer Control 4 2.6 OFF Timer Control 5 2.7 Auto Restart Control 5 2.8 Indication Panel 5	6 7 9 0						
13.	Protection Control5	1						
1	Protection Control For All Operations5 Protection Control For Cooling & Soft Dry Operation	3						
-	Servicing Mode5							
1	1.1 Auto OFF/ON Button5 1.2 Remote Control Button5	5						
15.	Troubleshooting Guide5	7						
1	5.1 Refrigeration Cycle System5	7						

15.2 Relationship Between The Condition Of The Air Conditioner And Pressure And Electric Current			
16. Disassembly and Assembly Instructions 89 16.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures	15.3 15.4	Air Conditioner And Pressure And Electric Current	58 59 60
16.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures	15.5	Self-diagnosis Method	62
Fan and Indoor Fan Motor Removal Procedures	16. Disa	assembly and Assembly Instructions	89
Procedures 93 16.3 Outdoor Electronic Controller Removal Procedure 97 17. Technical Data 98 17.1 Cool Mode Performance Data 98 17.2 Heat Mode Performance Data 100 18. Service Data 101 18.1 Cool Mode Outdoor Air Temperature Characteristic 101 18.2 Heat Mode Outdoor Air Temperature Characteristic 102 18.3 Piping Length Correction Factor 107 19. Exploded View and Replacement Parts List108 19.1 Indoor Unit 108	-	Fan and Indoor Fan Motor Removal Procedures	89
17.1 Cool Mode Performance Data	16.3	Procedures	
17.2 Heat Mode Performance Data	17. Tec	hnical Data	99
18.1 Cool Mode Outdoor Air Temperature Characteristic			
Characteristic	18. Serv	vice Data1	01
Characteristic 104 18.3 Piping Length Correction Factor 107 19. Exploded View and Replacement Parts List109 19.1 Indoor Unit 109	18.1		01
18.3 Piping Length Correction Factor	18.2		04
19.1 Indoor Unit	18.3		
	19. Ехр	loded View and Replacement Parts List1	09

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work must be installed or serviced by a licensed electrician. Be sure to use the correct rating of the power plug and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

⚠ WARNING	This indication shows the possibility of causing death or serious injury.
⚠ CAUTION	This indication shows the possibility of causing injury or damage to properties.

• The items to be followed are classified by the symbols:

\Diamond	This symbol denotes item that is PROHIBITED from doing.
------------	---

	⚠ WARNING	
1.	Do not modify the machine, part, material during repairing service.	
2.	If wiring unit is supplied as repairing part, do not repair or connect the wire even only partial wire break. Exchange the whole wiring unit is supplied as repairing part, do not repair or connect the wire even only partial wire break.	nit.
3.	Do not wrench the fasten terminal. Pull it out or insert it straightly.	
4.	Engage dealer or specialist for installation and servicing. If installation of servicing done by the user is defective, it will cause water leakage, electrical shock or fire.	
5.	Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electric shock or fire.	
6.	Use the attached accessories parts and specified parts for installation and servicing. Otherwise, it will cause the set to fall, water leafire or electrical shock.	kage,
7.	Install at a strong and firm location which is able to withstand the set's weight. If the strength is not enough or installation is not propodone, the set will drop and cause injury.	erly
8.	For electrical work, follow the local national wiring standard, regulation and the installation instruction. An independent circuit and sir outlet must be used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire.	gle
9.	This equipment is strongly recommended to install with Earth Leakage Circuit Breaker (ELCB) or Residual Current Device (RCD). Otherwise, it may cause electrical shock and fire in case equipment breakdown or insulation breakdown.	
10.	Do not use joint cable for indoor / outdoor connection cable. Use the specified Indoor/Outdoor connection cable, refer to installation instruction CONNECT THE CABLE TO THE INDOOR UNIT and connect tightly for indoor / outdoor connection. Clamp the cable so no external force will be acted on the terminal. If connecting or fixing is not perfect, it will cause heat up or fire at the connection.	that
11.	Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed perfectly, it wi cause heat-up or fire at the connection point of terminal, fire or electrical shock.	I
12.	When install or relocate air conditioner, do not let any substance other than the specified refrigerant, eg. air etc. mix into refrigeration cycle (piping). (Mixing of air etc. will cause abnormal high pressure in refrigeration cycle and result in explosion, injury etc.).	I
13.	Do not install outdoor unit near handrail of veranda. When installing air-conditioner unit at veranda of high rise building, child may cli up to outdoor unit and cross over the handrail and causing accident.	mb
14.	This equipment must be properly earthed. Earth line must not be connected to gas pipe, water pipe, earth of lightning rod and telephone. Otherwise, it may cause electric shock in case equipment breakdown or insulation breakdown.	\Diamond
15.	Keep away from small children, the thin film may cling to nose and mouth and prevent breathing.	\Diamond
16.	Do not use unspecified cord, modified cord, joint cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire.	\Diamond
17.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare may break and cause refrigerant gas leakage.	\Diamond
18.	 For R410A model, use piping, flare nut and tools which is specified for R410A refrigerant. Using of existing (R22) piping, flare nut and tools may cause abnormally high pressure in the refrigerant cycle (piping), and possibly result in explosion and injury. 	0

During installation, install the refrigerant piping properly before run the compressor. (Operation of compressor without fixing refrigeration piping and valves at opened condition will caused suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion,

Thickness or copper pipes used with R410A must be more than 0.8 mm. Never use copper pipes thinner than 0.8 mm.

• It is desirable that the amount of residual oil less than 40 mg/10 m.

During pump down operation, stop the compressor before remove the refrigeration piping. (Removal of compressor while compressor is operating and valves are opened will cause suck-in of air, abnormal high pressure in refrigeration cycle and result in explosion, injury etc.) 21. After completion of installation or service, confirm there is no leakage or refrigerant gas. It may generate toxic gas when the refrigerant contacts with fire. 22. Ventilate if there is refrigerant gas leakage during operation. It may cause toxic gas when refrigerant contacts with fire. 23. Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. 24. Must not use other parts except original parts described in catalog and manual. 25. Using of refrigerant other than the specified type may cause product damage, burst and injury etc.

	⚠ CAUTION	
1.	Do not install the unit at place where leakage of flammable gas may occur. In case gas leaks and accumulates at surrounding of the unit, it may cause fire.	\Diamond
2.	Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water may enter the room and damage furniture.	e the
3.	Tighten the flare nut with torque wrench according to specified method. If the flare nut is over-tightened, after a long period, the flare break and cause refrigerant gas leakage.	re may
4.	Do not touch outdoor unit air inlet and aluminium fin. It may cause injury.	\Diamond
5.	Select an installation location which is easy for maintenance.	
6.	Pb free solder has a higher melting point than standard solder; typically the melting point is 50°F – 70°F (30°C – 40°C) higher. Please use a high temperature solder iron. In case of the soldering iron with temperature control, please set it to 700 ± 20°F (370 ± Pb free solder will tend to splash when heated too high (about 1100°F / 600°C).	: 10°C).
7.	Power supply connection to the room air conditioner. Use power supply cord 3 × 1.5 mm² (1.0 ~ 1.75HP), 3 × 2.5 mm² (2.0 ~ 2.5HP) type designation 60245 IEC 57 or heavier cord. Connect the power supply cord of the air conditioner to the mains using one of the following method. Power supply point should be in easily accessible place for power disconnection in case of emergency. In some countries, permanent connection of this air conditioner to the power supply is prohibited. 1) Power supply connection to the receptacle using power plug. Use an approved 15/16A (1.0 ~ 1.75HP), 16A (2.0HP), 20A (2.5HP) power plug with earth pin for the connection to the socket. 2) Power supply connection to a circuit breaker for the permanent connection. Use an approved 16A (1.0 ~ 2.0HP), 20A (2.5HP) circuit breaker for the permanent connection. It must be a double pole switch with a minimum 3.0 mm contact gap.	
8.	Do not release refrigerant during piping work for installation, servicing, reinstallation and during repairing a refrigerant parts. Take care of the liquid refrigerant, it may cause frostbite.	\Diamond
9.	Installation or servicing work: It may need two people to carry out the installation or servicing work.	
10.	Do not install this appliance in a laundry room or other location where water may drip from the ceiling, etc.	\Diamond
11.	Do not sit or step on the unit, you may fall down accidentally.	\bigcirc
12.	Do not touch the sharp aluminium fins or edges of metal parts. If you are required to handle sharp parts during installation or servicing, please wear hand glove. Sharp parts may cause injury.	\Diamond

2. Specifications

		Model	Indoor		CS-YE9QKE			CS-YE12QKE	
			Outdoor		CU-YE9QKE		CU-YE12QKE		
Performance Test Condition				EUROVENT			EUROVENT		
Power Supply Phase, Hz					Single, 50			Single, 50	
	Power Supply V				230			230	
	kW				Mid.	Max.	Min.	Mid.	Max.
			kW	0.85	2.50	3.00	0.85	3.50	3.90
		Capacity	BTU/h	2900	8530	10200	2900	11900	13300
			kcal/h	730	2150	2580	730	3010	3350
	Rı	unning Current	A	-	3.20	ı	_	4.80	-
		Input Power	W	250	720	1.02k	255	1.09k	1.28k
	Annı	ual Consumption	kWh	_	360	-	-	545	_
			W/W	3.40	3.47	2.94	3.33	3.21	3.05
		EER	BTU/hW	11.60	11.85	10.00	11.37	10.92	10.39
ng			kcal/hW	2.92	2.99	2.53	2.86	2.76	2.62
Cooling		Pdesign	kW		2.5			3.5	
		SEER	(W/W)		5.6			5.6	
	ErP	Annual Consumption	kWh		156			219	
		Class			A+			A+	
	F	Power Factor	%	-	98	-	_	99	-
	Indoor Noise		dB-A (H/L/Q-Lo)	41 / 26 / 22 42 / 30 / 22					
			Power Level dB	57			58		
	Outdoor Noise		dB-A		47		48		
			Power Level dB	62			63		
	Capacity		kW	0.80	3.30	4.10	0.80	4.00	5.10
			BTU/h	2730	11300	14000	2730	13600	17400
			kcal/h	690	2840	3530	690	3440	4390
	Running Current		А	_	3.80	-	-	4.90	_
	Input Power		W	195	860	1.18k	200	1.10k	1.47k
			W/W	4.10	3.84	3.47	4.00	3.64	3.47
		COP	BTU/hW	14.00	13.14	11.86	13.65	12.36	11.84
			kcal/hW	3.54	3.30	2.99	3.45	3.13	2.99
Heating		Pdesign	kW		1.9			2.4	
Hea		Tbivalent	°C		-10			-10	
	ErP	SCOP	(W/W)		38			38	
		Annual Consumption	kWh		700			884	
		Class			A			Α	
	F	Power Factor	%		98	_	_	98	
	1	Indoor Noise	dB-A (H/L/Q-Lo)		41 / 27 / 25			42 / 33 / 25	
-			Power Level dB		57			58	
	C	Outdoor Noise	dB-A		48			50	
H			Power Level dB	-	63			65	
		np. : Capacity (kW) /			2.97 / 1.04k / 2.8			3.70 / 1.30k / 2.8	
Ext			/) / I.Power (W) / COP	2.66 / 1.12k / 2.38			3	3.20 / 1.41k / 2.2	1
	Max	Current (A) / Max Ir		5.3 / 1.18k				6.7 / 1.47k	
		Starting Currer	nt (A)	3.80			4.90		

Model		Indoor	CS-YE9QKE	CS-YE12QKE		
Wodei		Outdoor	CU-YE9QKE	CU-YE12QKE		
Туре			уре		Hermetic Motor	Hermetic Motor
Compressor Motor Type			Brushless (6-poles)	Brushless (6-poles)		
		Outpu	ıt Power	W	650	700
		Туре			Cross-Flow Fan	Cross-Flow Fan
Ī		Material			ASG20K1	ASG20K1
	М	lotor Typ	е		DC / Transistor (8 poles)	DC / Transistor (8 poles)
	In	put Pow	er	W	47.3	47.3
	Ou	tput Pov	ver	W	40.0	40.0
Fan		01.5	Cool	rpm	600	630
Indoor Fan		QLo	Heat	rpm	710	780
lud			Cool	rpm	680	800
	Cnood	Lo	Heat	rpm	760	980
	Speed	Mo	Cool	rpm	890	1010
		Ме	Heat	rpm	980	1140
		11:	Cool	rpm	1110	1220
		Hi	Heat	rpm	1200	1300
		Туре			Propeller Fan	Propeller Fan
	Material				PP	PP
Fan	Motor Type				AC / Induction (6 poles)	AC / Induction (6 poles)
loor	Input Power			W	-	-
Outdoor Fan	Output Power			W	40	40
	Speed	Hi	Cool	rpm	770	800
	Speeu	1 "	Heat	rpm	750	800
	Moisture Removal			L/h (Pt/h)	1.5 (3.2)	2.0 (4.2)
		QLo	Cool	m³/min (ft³/min)	5.74 (203)	5.69 (201)
		QLU	Heat	m³/min (ft³/min)	7.03 (248)	6.79 (240)
		1	Cool	m³/min (ft³/min)	6.68 (236)	7.59 (268)
ı	Indoor	Lo	Heat	m³/min (ft³/min)	7.62 (269)	8.85 (313)
A	Airflow	Ma	Cool	m³/min (ft³/min)	9.22 (326)	9.94 (351)
		Me	Heat	m³/min (ft³/min)	10.22 (361)	10.50 (371)
			Cool	m³/min (ft³/min)	11.7 (415)	12.3 (435)
		Hi	Heat	m³/min (ft³/min)	12.8 (450)	12.8 (450)
С	Outdoor		Cool	m³/min (ft³/min)	32.1 (1135)	31.0 (1095)
	Airflow	Hi	Heat	m³/min (ft³/min)	31.2 (1100)	31.0 (1095)
		Contro	ol Device		Expansion Valve	Expansion Valve
	rigeration Cycle	Refrig	erant Oil	cm ³	FV50S (320)	FV50S (320)
	- yolu	Refrige	rant Type	g (oz)	R410A, 850 (30.0)	R410A, 1.00k (35.3)
		Height	(I/D / O/D)	mm (inch)	290 (11-7/16) / 542 (21-11/32)	290 (11-7/16) / 542 (21-11/32)
Dir	mension		I/D / O/D)	mm (inch)	870 (34-9/32) / 780 (30-23/32)	870 (34-9/32) / 780 (30-23/32)
			[I/D / O/D)	mm (inch)	214 (8-7/16) / 289 (11-13/32)	214 (8-7/16) / 289 (11-13/32)
٧	Neight	, , ,		kg (lb)	9 (20) / 31 (68)	9 (20) / 33 (73)

Model		A a da l	Indoor	CS-YE9QKE		CS-YE	12QKE
			Outdoor	CU-YE9	QKE	CU-YE	12QKE
Pipe	Pipe Diameter (Liquid / Gas)		mm (inch)	6.35 (1/4) / 9.52 (3/8)		6.35 (1/4)	9.52 (3/8)
	Star	ndard length	m (ft)	5.0 (1	6.4)	5.0 (16.4)
g Ler	ngth ra	ange (min – max)	m (ft)	3 (9.8) ~ 1	5 (49.2)	3 (9.8) ~	15 (49.2)
Buildid I/D	& O/E	D Height different	m (ft)	15.0 (4	19.2)	15.0 ((49.2)
Ad	dditior	nal Gas Amount	g/m (oz/ft)	20 (0	.2)	20 (0.2)
Ler	ngth fo	or Additional Gas	m (ft)	7.5 (2	4.6)	7.5 (2	24.6)
Drain H	000	Inner Diameter	mm	16.	7	16	i.7
Diaiiiii	036	Length	mm	650)	65	50
		Fin Material		Aluminium (Pre Coat)	Aluminium	(Pre Coat)
Indoor F	leat	Fin Type		Slit F	in	Slit	Fin
Exchan	ger F	Row × Stage × FPI		2 × 15	× 17	2 × 15	5 × 21
	Size (W × H × L)		mm	610 × 315	5 × 25.4	610 × 315 × 25.4	
		Fin Material		Aluminium (Aluminium (Pre Coat)		(Pre Coat)
Outdo Heat	-	Fin Type		Corrugated Fin		Corrugated Fin	
Exchan	_	Row × Stage × FPI		1 × 20 × 19		2 × 24	1 × 17
		Size (W × H × L)	mm	22 × 508	22 × 508 × 708.4		× 713:684
Λ in []]	or	Material		Polypropelene		Polypro	pelene
Air Filt	.ei	Туре		One-touch		One-touch	
	Powe	er Supply		Indoor		Indoor	
Po	ower (Supply Cord	Α	Nil		Nil	
	The	ermostat		Nil		Nil	
F	rotec	tion Device		Nil	1	N	il
				Dry Bulb	Wet Bulb	Dry Bulb	Wet Bulb
		Cooling	Maximum °C	32	23	32	23
Indo Opera		Cooling	Minimum °C	16	11	16	11
Rar		Heating	Maximum °C	30	_	30	_
		Heating -	Minimum °C	16	_	16	_
		Cooling	Maximum °C	43	26	43	26
Outo		Cooling	Minimum °C	5	_	5	_
Opera Rar		Heating	Maximum °C	24	18	24	18
		Heating -	Minimum °C	-10	-11	-10	-11

- Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb) 1.
- Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb 2. (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb)
- 3.
- Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor 2/1°C. Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor -7/-8°C.
- Standby power consumption ≤ 2.0W (when switched OFF by remote control, except under self-protection control).
- Specifications are subjected to change without prior notice for further improvement.
- Maximum heating capacity shown are the values based on powerful operation.

 If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- The annual consumption is calculated by multiplying the input power by an average of 500 hours per year in cooling mode.

 SEER and SCOP classification is at 230V only in accordance with EN-14825. For heating, SCOP indicates the value of only Average heating
- season. Other fiche data indicates in an attached sheet.

Model		Madal	Indoor	CS-UE9QKE			CS-UE12QKE		
Outdoor				CU-UE9QKE		CU-UE12QKE			
		Performance Test (Condition		EUROVENT		EUROVENT		
	Do	wer Supply	Phase, Hz	Single, 50			Single, 50		
	FO	wei Suppiy	V		230			230	
	-				Mid.	Max.	Min.	Mid.	Max.
			kW	0.85	2.50	3.00	0.85	3.50	3.90
		Capacity	BTU/h	2900	8530	10200	2900	11900	13300
			kcal/h	730	2150	2580	730	3010	3350
	Ru	inning Current	Α	-	3.20	-	-	4.80	-
	ļ	Input Power	W	250	720	1.02k	255	1.09k	1.28k
	Annı	al Consumption	kWh	-	360	-	_	545	-
			W/W	3.40	3.47	2.94	3.33	3.21	3.05
		EER	BTU/hW	11.60	11.85	10.00	11.37	10.92	10.39
ing			kcal/hW	2.92	2.99	2.53	2.86	2.76	2.62
Cooling		Pdesign	kW		2.5			3.5	
	[SEER	(W/W)		5.6			5.6	
	ErP	Annual Consumption	kWh		156			219	
	•	Class			A+		A+		
	F	Power Factor	%	-	98	_	-	99	_
		ndoor Noise	dB-A (H/L/Q-Lo)		41 / 26 / 22		42 / 30 / 22		
	Indoor Noise		Power Level dB	57			58		
	Outdoor Noise		dB-A	47 48					
			Power Level dB	62 63			63		
	Capacity		kW	0.80	3.30	4.10	0.80	4.00	5.10
			BTU/h	2730	11300	14000	2730	13600	17400
			kcal/h	690	2840	3530	690	3440	4390
	Running Current		A	_	3.80	_	-	4.90	-
	Input Power		W	195	860	1.18k	200	1.10k	1.47k
			W/W	4.10	3.84	3.47	4.00	3.64	3.47
		COP	BTU/hW	14.00	13.14	11.86	13.65	12.36	11.84
			kcal/hW	3.54	3.30	2.99	3.45	3.13	2.99
Heating	}	Pdesign	kW		1.9			2.4	
Ŧ	ŀ	Tbivalent	°C		-10			-10	
	ErP	SCOP	(W/W)		38			38	
	}	Consumption	kWh		700			884	
	Class				A			A	
	F	Power Factor	%	_	98	_	_	98	_
	I	ndoor Noise	dB-A (H/L/Q-Lo)		41 / 27 / 25			42 / 33 / 25	
-			Power Level dB		57			58	
	0	utdoor Noise	dB-A		48			50	
\vdash	T		Power Level dB		63	^		65	<u>-</u>
-		ip. : Capacity (kW) /	` '		2.97 / 1.04k / 2.8			3.70 / 1.30k / 2.8	
Ext) / I.Power (W) / COP	2.66 / 1.12k / 2.38			3.20 / 1.41k / 2.27		
<u> </u>	Max	Current (A) / Max In	` ` `		5.3 / 1.18k			6.7 / 1.47k	
		Starting Currer	π (A)	3.80			4.90		

Model		Indoor	CS-UE9QKE	CS-UE12QKE		
		Outdoor	CU-UE9QKE	CU-UE12QKE		
Туре			Hermetic Motor	Hermetic Motor		
Compressor Motor Type			Brushless (6-poles)	Brushless (6-poles)		
		Outpu	ıt Power	W	650	700
		Туре			Cross-Flow Fan	Cross-Flow Fan
		Material			ASG20K1	ASG20K1
i [М	otor Typ	е		DC / Transistor (8 poles)	DC / Transistor (8 poles)
	In	put Pow	er	W	47.3	47.3
	Ou	tput Pov	ver	W	40	40
Fan		01.5	Cool	rpm	600	630
Indoor Fan		QLo	Heat	rpm	710	780
lnd			Cool	rpm	680	800
	Canad	Lo	Heat	rpm	760	980
	Speed	Mo	Cool	rpm	890	1010
		Me	Heat	rpm	980	1140
		11:	Cool	rpm	1110	1220
		Hi	Heat	rpm	1200	1300
		Туре			Propeller Fan	Propeller Fan
-	Material				PP	PP
Outdoor Fan	Motor Type				DC (8 poles)	DC (8 poles)
loor	Input Power			W	-	-
Outc	Output Power		W	40	40	
	Conned	Hi	Cool	rpm	770	800
	Speed	1 "	Heat	rpm	750	800
	Moisture Removal			L/h (Pt/h)	1.5 (3.2)	2.0 (4.2)
		QLo	Cool	m³/min (ft³/min)	5.74 (203)	5.69 (201)
		Heat		m³/min (ft³/min)	7.03 (248)	6.79 (240)
			Cool	m³/min (ft³/min)	6.68 (236)	7.59 (268)
	Indoor	Lo	Heat	m³/min (ft³/min)	7.62 (269)	8.85 (313)
,	Airflow	Ma	Cool	m³/min (ft³/min)	9.22 (326)	9.94 (351)
		Me	Heat	m³/min (ft³/min)	10.22 (361)	10.50 (371)
			Cool	m³/min (ft³/min)	11.7 (415)	12.3 (435)
		Hi	Heat	m³/min (ft³/min)	12.8 (450)	12.8 (450)
(Outdoor		Cool	m³/min (ft³/min)	32.1 (1135)	31.0 (1095)
,	Airflow	Hi	Heat	m³/min (ft³/min)	31.2 (1100)	31.0 (1095)
		Contro	ol Device		Expansion Valve	Expansion Valve
	frigeration Cycle	Refrig	erant Oil	cm ³	FV50S (320)	FV50S (320)
	2,010	Refrige	rant Type	g (oz)	R410A, 850 (30.0)	R410A, 1.00k (35.3)
		Height ((I/D / O/D)	mm (inch)	290 (11-7/16) / 542 (21-11/32)	290 (11-7/16) / 542 (21-11/32)
Di	mension	Width (I/D / O/D)	mm (inch)	870 (34-9/32) / 780 (30-23/32)	870 (34-9/32) / 780 (30-23/32)
		Depth (I/D / O/D)	mm (inch)	214 (8-7/16) / 289 (11-13/32)	214 (8-7/16) / 289 (11-13/32)
١	Weight	Net (I/	D / O/D)	kg (lb)	9 (20) / 31 (68)	9 (20) / 33 (73)

Model		Model	Indoor	CS-UES	QKE	CS-UE12QKE	
		Wodel	Outdoor	CU-UES	QKE	CU-UE12QKE	
[Pipe Diameter (Liquid / Gas)		mm (inch)	6.35 (1/4) /	6.35 (1/4) / 9.52 (3/8)		9.52 (3/8)
	Sta	andard length	m (ft)	5.0 (1	6.4)	5.0 (1	6.4)
Piping	Length	range (min – max)	m (ft)	3 (9.8) ~ 1	5 (49.2)	3 (9.8) ~ 1	5 (49.2)
Pip	I/D & O	/D Height different	m (ft)	15.0 (4	19.2)	15.0 (4	19.2)
	Additio	onal Gas Amount	g/m (oz/ft)	20 (0	.2)	20 (0	1.2)
	Length	for Additional Gas	m (ft)	7.5 (2	4.6)	7.5 (2	4.6)
Dra	in Hose	Inner Diameter	mm	16.	7	16.	7
Ыа	11111036	Length	mm	650)	650	0
		Fin Material		Aluminium (Pre Coat)	Aluminium (Pre Coat)
Indo	or Heat	Fin Type		Slit F	in	Slit F	in
Exc	changer	Row × Stage × FPI		2 × 15	× 17	2 × 15	× 21
		Size (W × H × L)	mm	610 × 315	5 × 25.4	610 × 315 × 25.4	
		Fin Material		Aluminium (Aluminium (Pre Coat)		Pre Coat)
_	utdoor	Fin Type		Corrugated Fin		Corrugated Fin	
	Heat changer	Row × Stage × FPI		1 × 20 × 19		2 × 24	× 17
		Size (W × H × L)	mm	22 × 508	22 × 508 × 708.4		713:684
۸:	. F:I4	Material		Polypropelene		Polyprop	pelene
Ai	r Filter	Туре		One-touch		One-to	ouch
	Pov	ver Supply		Indoor		Indoor	
	Power	Supply Cord	Α	Nil		Nil	
	Th	ermostat		Nil		Nil	
	Prote	ction Device		Ni		Nil	
				Dry Bulb	Wet Bulb	Dry Bulb	Wet Bulb
		On allin a	Maximum °C	32	23	32	23
_	Indoor	Cooling	Minimum °C	16	11	16	11
	Operation Range		Maximum °C	30	_	30	_
		Heating	Minimum °C	16	-	16	_
		0 "	Maximum °C	43	26	43	26
	Outdoor	Cooling	Minimum °C	5	-	5	_
	Operation Range		Maximum °C	24	18	24	18
		Heating	Minimum °C	-10	-11	-10	-11

- 1. Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb)
- Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb 2. (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb)

 Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor 2/1°C.

 Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor -7/-8°C.
- 3.
- 4.
- Standby power consumption ≤ 2.0W (when switched OFF by remote control, except under self-protection control).
- Specifications are subjected to change without prior notice for further improvement.
- Maximum heating capacity shown are the values based on powerful operation.

 If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with 8. rated voltage 230V shall be used.
- The annual consumption is calculated by multiplying the input power by an average of 500 hours per year in cooling mode.

 SEER and SCOP classification is at 230V only in accordance with EN-14825. For heating, SCOP indicates the value of only Average heating
- season. Other fiche data indicates in an attached sheet.

Model		Model	Indoor	CS-UE18QKE						
		Wodei	Outdoor	CU-UE18QKE						
		Performance Test (Condition		EUROVENT					
	Po	wer Supply	Phase, Hz		Single, 50					
	FU	wei Suppiy	V		230					
				Min.	Mid.	Max.				
			kW	0.98	5.00	5.60				
	Capacity		BTU/h	3340	17100	19100				
			kcal/h	840	4300	4820				
	Running Current		А	-	6.90	-				
	Input Power		W	285	285 1.54k					
	Annı	ual Consumption	kWh	-	770	_				
			W/W	3.44	3.25	3.20				
		EER	BTU/hW	11.72	11.10	10.91				
ling			kcal/hW	2.95	2.79	2.75				
Cooling		Pdesign	kW		5.0					
	E-D	SEER	(W/W)		6.5 269					
	ErP	Annual Consumption	kWh							
		Class			A++					
	F	Power Factor	%	_	97	-				
			dB-A (H/L)	44 / 37						
	ı	ndoor Noise	Power Level dB	60						
	Outdoor Noise		dB-A	48						
			Power Level dB	63						
	Capacity		kW	0.98	5.40	7.70				
			BTU/h	3340	18400	26300				
			kcal/h	840	4640	6620				
	Running Current		Α	-	6.70	_				
	Input Power		W	350	1.47k	2.30k				
			W/W	2.80	3.67	3.35				
		COP	BTU/hW	9.54	12.52	11.43 2.88				
			kcal/hW	2.40						
Heating		Pdesign	kW		4.0					
운		Tbivalent	°C		-10					
	ErP	SCOP Annual	(W/W)	4.3						
		Consumption	kWh	1302						
		Class			A+					
	Power Factor		%	_ 95 <u>_</u>						
	ı	ndoor Noise	dB-A (H/L)	44 / 37						
			Power Level dB	60						
	Outdoor Noise		dB-A Power Level dB	49						
H	_ow Temp. : Capacity (kW) / I.F			64						
_				5.58 / 2.04k / 2.74 4.79 / 2.09k / 2.29						
_ ⊏X(I	Extr Low Temp. : Capacity (kW) / I.Power (W) / COP			4.79 / 2.09k / 2.29 10.1 / 2.30k						
	Max Current (A) / Max Input Power (W)									
	Starting Current (A)			6.90						

Model			Indoor	CS-UE18QKE				
Wodel		Outdoor	CU-UE18QKE					
		Т	уре		Hermetic Motor			
Coi	mpressor	Motor Type			Brushless (4-poles)			
	Output Power		W	900				
	Туре				Cross-Flow Fan			
	Material				ASG20K1			
	Motor Type		ре		DC / Transistor (8 poles)			
	Input Power		W	94.8				
Fan	Output Power			W	40			
Indoor Fan		1	Cool	rpm	960			
pul		Lo	Heat	rpm	1070			
		Mo	Cool	rpm	1080			
	Speed	Me	Heat	rpm	1190			
		Hi	Cool	rpm	1200			
		П	Heat	rpm	1310			
		Туре			Propeller Fan			
	Material				PP			
Fan	Motor Type		ре		DC (8 poles)			
Outdoor Fan	Input Power		er	W	-			
Outc	Output Power		W	40				
	Speed	Hi	Cool	rpm	860			
	Speed	1 11	Heat	rpm	850			
	Moisture Removal			L/h (Pt/h)	2.8 (5.9)			
		Lo	Cool	m³/min (ft³/min)	12.65 (447)			
		LU	Heat	m³/min (ft³/min)	14.25 (503)			
	Indoor	Mo	Cool	m³/min (ft³/min)	14.45 (510)			
,	Airflow	Me	Heat	m³/min (ft³/min)	16.05 (567)			
		11:	Cool	m³/min (ft³/min)	16.30 (575)			
		Hi	Heat	m³/min (ft³/min)	17.90 (630)			
C	Outdoor	11:	Cool	m³/min (ft³/min)	34.4 (1215)			
,	Airflow	Hi	Heat	m³/min (ft³/min)	34.0 (1200)			
		Control Device			Expansion Valve			
	rigeration Cycle	Refrig	erant Oil	cm ³	FV50S (450)			
	0,0.0	Refrige	erant Type	g (oz)	R410A, 1.43k (50.5)			
		Height (I/D / O/D)		mm (inch)	290 (11-7/16) / 622 (24-1/2)			
Di	mension	on Width (I/D / O/D)		mm (inch)	1070 (42-5/32) / 824 (32-15/32)			
		Depth ((I/D / O/D)	mm (inch)	240 (9-15/32) / 299 (11-25/32)			
١	Neight			kg (lb)	12 (26) / 38 (84)			

		Madal	Indoor	CS-UE	18QKE					
		Model	Outdoor	Outdoor CU-UE18QKE						
	Pipe Diameter (Liquid / Gas)		mm (inch)	6.35 (1/4) / 12.70 (1/2)						
	Sta	andard length	m (ft)	5.0 (16.4)						
ing	Length	range (min – max)	m (ft)	3 (9.8) ~ 15 (49.2)						
Piping	I/D & O	/D Height different	m (ft)	15.0 (49.2)						
	Additio	onal Gas Amount	g/m (oz/ft)	20 (0.2)					
	Length for Additional Gas		m (ft)	7.5 (24.6)						
Dra	in Hoso	Inner Diameter	mm	16	.7					
Drain Hose		Length	mm	65	50					
		Fin Material		Aluminium (Pre Coat)						
	oor Heat	Fin Type		Slit	Slit Fin					
	changer	Row × Stage × FPI		2 × 15	2 × 15 × 17					
		Size (W × H × L)	mm	810 × 31	5 × 25.4					
		Fin Material		Aluminium	(Pre Coat)					
_	utdoor	Fin Type		Corruga	Corrugated Fin					
Ex	Heat changer	Row × Stage × FPI		2 × 28 × 17						
		Size (W × H × L)	mm	36.4 × 588 × 856.3:827.7						
Δ:	ir Filter	Material		Polypropelene						
A	Туре			One-touch						
	Pov	ver Supply		Inde	oor					
	Power	Supply Cord	Α	N	Nil					
	Tł	nermostat		N	il					
	Prote	ction Device		N	il					
				Dry Bulb	Wet Bulb					
		on	Maximum °C	32	23					
١,	Indoor		Minimum °C	16	11					
	Operatior Range		Maximum °C	30	-					
			Minimum °C	16	-					
			Maximum °C	43	26					
	Outdoor	Cooling	Minimum °C	5	_					
'	Operation Range		Maximum °C	24	18					
		Heating	Minimum °C	-10	-11					
				· · · · · · · · · · · · · · · · · · ·						

- Cooling capacities are based on indoor temperature of 27°C Dry Bulb (80.6°F Dry Bulb), 19.0°C Wet Bulb (66.2°F Wet Bulb) and outdoor air temperature of 35°C Dry Bulb (95°F Dry Bulb), 24°C Wet Bulb (75.2°F Wet Bulb) 1.
- 2. Heating capacities are based on indoor temperature of 20°C Dry Bulb (68°F Dry Bulb) and outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb)
- Heating low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor 2/1°C. 3.
- Heating extreme low temperature capacity, Input Power and COP measured at 230 V, indoor temperature of 20°C, outdoor -7/-8°C.
- Standby power consumption ≤ 2.0W (when switched OFF by remote control, except under self-protection control).
- Specifications are subjected to change without prior notice for further improvement.
- Maximum heating capacity shown are the values based on powerful operation.

 If the EUROVENT Certified models can be operated under the "extra-low" temperature condition, -7°C DB and -8°C WB temperature with rated voltage 230V shall be used.
- The annual consumption is calculated by multiplying the input power by an average of 500 hours per year in cooling mode.

 SEER and SCOP classification is at 230V only in accordance with EN-14825. For heating, SCOP indicates the value of only Average heating
- season. Other fiche data indicates in an attached sheet.

3. Features

Inverter Technology

- Wider output power range
- o Energy saving
- Quick Cooling
- Quick Heating
- o More precise temperature control

Environment Protection

Non-ozone depletion substances refrigerant (R410A)

Long Installation Piping

o CS/CU-YE9/12QKE, CS/CU-UE9/12/18QKE, long piping up to 15 meters

• Easy to use remote control

Quality Improvement


- o Random auto restart after power failure for safety restart operation
- Gas leakage protection
- Prevent compressor reverse cycle
- o Inner protector to protect compressor

• Serviceability Improvement

o Breakdown Self Diagnosis function


4. Location of Controls and Components

4.1 Indoor Unit




direction louver
• Do not adjust by hand.

4.2 Outdoor Unit



4.3 Remote Control




15


5. Dimensions

5.1 Indoor Unit & Remote Control


5.1.1 CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE



Relative position between the indoor unit and the installation plate <Front View>




5.1.2 CS-UE18QKE




5.2 Outdoor Unit


5.2.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE



5.2.2 CU-UE18QKE




6. Refrigeration Cycle Diagram




^{*} Not a standard replacement part.

7. Block Diagram

7.1 CS-YE9QKE CU-YE9QKE CS-YE12QKE CU-YE12QKE CS-UE9QKE CU-UE9QKE CS-UE12QKE CU-UE12QKE




7.2 CS-UE18QKE CU-UE18QKE




8. Wiring Connection Diagram

8.1 Indoor Unit

8.1.1 CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE




8.1.2 CS-UE18QKE



8.2 Outdoor Unit

8.2.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE



Resistance of Compressor Windings

MODEL	CU-YE9QKE/UE9QKE			
CONNECTION	5RS092XCD21			
U-V	1.152 Ω			
U-W	1.152 Ω			
V-W	1.152 Ω			

Note: Resistance at 20°C of ambient temperature.


Resistance of Compressor Windings

COMP. TERMINAL

MODEL	CU-YE12QKE/UE12QKE			
CONNECTION	5RS102XBC21			
U-V	0.858 Ω			
U-W	0.858 Ω			
V-W	0.858 Ω			

Note: Resistance at 20°C of ambient temperature.

8.2.2 CU-UE18QKE



Resistance of Compressor Windings


	9 -
MODEL	CU-UE18QKE
CONNECTION	5RD132XBE21
U-V	1.897 Ω
U-W	1.907 Ω
V-W	1.882 Ω

Note: Resistance at 20°C of ambient temperature.


9. Electronic Circuit Diagram

9.1 Indoor Unit

9.1.1 CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE





9.1.2 CS-UE18QKE




9.2 Outdoor Unit


9.2.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE









9.2.2 CU-UE18QKE








10. Printed Circuit Board


10.1 Indoor Unit

10.1.1 Main Printed Circuit Board



JP1 (Random Auto Restart enable/disable)


10.1.2 Indicator & Receiver Printed Circuit Board




10.2 Outdoor Unit

10.2.1 Main Printed Circuit Board

10.2.1.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE




10.2.1.2 CU-UE18QKE



10.2.2 CPU Printed Circuit Board

10.2.2.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE



11. Installation Instruction

11.1 Select the Best Location

11.1.1 Indoor Unit

- Do not install the unit in excessive oil fume area such as kitchen, workshop and etc.
- There should not be any heat source or steam near the unit.
- There should not be any obstacles blocking the air circulation.
- A place where air circulation in the room is good.
- A place where drainage can be easily done.
- A place where noise prevention is taken into consideration.
- Do not install the unit near the door way.
- Ensure the spaces indicated by arrows from the wall, ceiling, fence or other obstacles.
- Recommended installation height for indoor unit shall be at least 2.5 m.

11.1.2 Outdoor Unit


- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- There should not be any animal or plant which could be affected by hot air discharged.
- Keep the spaces indicated by arrows from wall, ceiling, fence or other obstacles.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- If piping length is over the [piping length for additional gas], additional refrigerant should be added as shown in the table.

	Horse Power (HP)	Piping size			Max.	Min. Piping	Max. Piping	Additional	Piping Length
Model		Gas	Liquid	Length (m)	Elevation (m)	Length (m)	Length (m)	Refrigerant (g/m)	for add. gas (m)
RE9***,UE9***,YE9***	1.0HP	9.52mm			15	3	15	20	7.5
RE12***,UE12***,YE12***	1.5HP	(3/8")			15	3	15	20	7.5
RE15***	1.75HP				15	3	15	20	7.5
UE18***	2.0HP	12.7mm (1/2") (1/2") 15.88mm (5/8")	6.35mm (1/4")	5	15	3	15	20	7.5
RE18***	2.UNF				15	3	20	20	7.5
RE24***	2.5HP				20	3	30	30	10

Example: For RE9***

If the unit is installed at 10 m distance, the quantity of additional refrigerant should be 50 g (10-7.5) m \times 20 g/m = 50 g.

11.1.3 Indoor/Outdoor Unit Installation Diagram




This illustration is for explanation purposes only.
 The indoor unit will actually face a different way

11.2 Indoor Unit

11.2.1 How to Fix Installation Plate

The mounting wall shall be strong and solid enough to prevent if from the vibration.



Model	Dimension							
Model	0	2	3	4	(\$)	6		
RE9***,UE9***,YE9*** RE12***,UE12***,YE12*** RE15***	490 mm	82 mm	439 mm	432 mm	43 mm	95 mm		
RE18***,UE18*** RE24***	590 mm	82 mm	539 mm	532 mm	169 mm	219 mm		

The center of installation plate should be at more than ① at right and left of the wall.

The distance from installation plate edge to ceiling should more than ②.

From installation plate center to unit's left side is 3.

From installation plate center to unit's right side is 4.

- B : For left side piping, piping connection for liquid should be about S from this line.
 - : For left side piping, piping connection for gas should be about ® from this line.
- Mount the installation plate on the wall with 5 screws or more (at least 5 screws). (If mounting the unit on the concrete wall, consider using anchor bolts.)
 - o Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
- 2 Drill the piping plate hole with ø70 mm hole-core drill.
 - Line according to the left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above.
 The hole center is obtained by measuring the distance namely 128 mm for left and right hole respectively.
 - o Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.


11.2.2 To Drill a Hole in the Wall and Install a Sleeve of Piping

- 1 Insert the piping sleeve to the hole.
- 2 Fix the bushing to the sleeve.
- 3 Cut the sleeve until it extrudes about 15 mm from the wall.


the wall is hollow, please be sure to

When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.


4 Finish by sealing the sleeve with putty or caulking compound at the final stage.



11.2.3 Indoor Unit Installation




11.2.3.1 For the right rear piping




the control board hole until terminal board area.

Intake grille

For the right and right bottom 11.2.3.2 piping






Step-6 Connect the piping

Please refer to "Connecting the piping" column in outdoor unit section. (Below steps are done after connecting the outdoor piping and gas-leakage confirmation.)


Step-7 Insulate and finish the piping

Please refer to "Insulation of piping connection" column as mentioned in indoor/outdoor unit installation.

Step-8 Secure the Indoor Unit



(This can be used for left rear piping and left bottom piping also.)




11.2.4 Connect the Cable to the Indoor Unit


The power supply cord, indoor and outdoor unit connection cable can be connected without removing the front grille.

- 1 Install the indoor unit on the installing holder that mounted on the wall.
- 2 Open the front panel and grille door by loosening the screw.
- 3 Cable connection to the power supply through Isolating Devices (Disconnecting means).
 - Connect approved type polychloroprene sheathed power supply cord 3 × 1.5 mm² (1.0 ~ 1.75HP), 3 × 2.5 mm² (2.0 ~ 2.5HP) type designation 60245 IEC 57 or heavier cord to the terminal board, and connect the others end of the cord to Isolating Devices (Disconnecting means).
 - Do not use joint power supply cord. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
 - In unavoidable case, joining of power supply cord between isolating devices and terminal board of air conditioner shall be done by using approved socket and plug with earth pin rated 15/16/20A. Wiring work to both socket and plug must follow to national wiring standard.
- 4 Bind all the power supply cord lead wire with tape and route the power supply cord via the left escapement.
- Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 × 1.5 mm² (1.0 ~ 1.75HP) or 4 × 2.5 mm² (2.0 ~ 2.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short. Allowable connection cable length of each indoor unit shall be 30 m or less.
- 6 Bind all the indoor and outdoor connection cable with tape and route the connection cable via the right escapement.

7 Remove the tapes and connect the power supply cord and connection cable between indoor unit and outdoor unit according to the diagram below.





- 8 Secure the power supply cord and connection cable onto the control board with the holder.
- 9 Close grille door by tighten with screw and close the front panel.



Note:

- Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.






11.3 Outdoor Unit

Install the Outdoor Unit 11.3.1

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
 - Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut (ø10 mm).
 - When installing at roof, please consider strong wind and earthquake. Please fasten the installation stand firmly with bolt or nails.



Model	АВ		С	D	
RE9***,UE9***,YE9***	570 mm	105 mm	18.5 mm	320 mm	
UE12***,YE12***	370 111111	103 11111	10.3 11111	320 111111	
RE12***					
RE15***	540 mm	160 mm	18.5 mm	330 mm	
UE18***					
RE18***	613 mm	131 mm	16 mm	360.5 mm	
RE24***	013111111		10 111111	300.3 11111	

Do not overtighten, overtightening may cause gas leakage.

Torque

[18 N•m (1.8 kgf.m)]

[42 N•m (4.3 kgf.m)]

Piping size

6.35 mm (1/4")

9.52 mm (3/8")

11.3.2 **Connect the Piping**

11.3.2.1 Connecting the Piping to Indoor

Please make flare after inserting flare nut (locate at joint portion, of tube assembly) onto the copper pipe. (In case of using long piping) Connect the pining


ormect the piping	12.7 mm (1/2")	[55 N•m (5.6 kgf.m)]
Align the center of piping and sufficiently tighten the flare nut with fingers.	15.88 mm (5/8")	[65 N•m (6.6 kgf.m)]
Further tighten the flare nut with torque wrench in	19.05 mm (3/4")	[100 N•m (10.2 kgf.m)]
specified torque as stated in the table.		

11.3.2.2 Connecting the Piping to **Outdoor**

Decide piping length and then cut by using pipe cutter. Remove burrs from cut edge.


Make flare after inserting the flare nut (located at valve) onto the copper pipe.

Align center of piping to valves and then tighten with torque wrench to the specified torque as stated in the table.



11.3.3 Evacuation of the Equipment

WHEN INSTALLING AN AIR CONDITIONER, BE SURE TO EVACUATE THE AIR INSIDE THE INDOOR UNIT AND PIPES in the following procedure.



- 1 Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve.
 - o Be sure to connect the end of the charging hose with the push pin to the service port.
- 2 Connect the center hose of the charging set to a vacuum pump.
- Turn on the power switch of the vacuum pump and make sure that the needle in the gauge moves from 0 cmHg (0 MPa) to -76 cmHg (-0.1 MPa). Then evacuate the air approximately ten minutes.
- 4 Close the Low side valve of the charging set and turn off the vacuum pump. Make sure that the needle in the gauge does not move after approximately five minutes.


 Note: BE SURE TO TAKE THIS PROCEDURE IN ORDER TO AVOID REFRIGERENT GAS LEAKAGE.
- 5 Disconnect the charging hose from the vacuum pump and from the service port of the 3-way valve.
- 6 Tighten the service port caps of the 3-way valve at a torque of 18 N•m with a torque wrench.
- Remove the valve caps of both of the 2-way valve and 3-way valve. Position both of the valves to "OPEN" using a hexagonal wrench (4 mm).
- 8 Mount valve caps onto the 2-way valve and the 3-way valve.
 - Be sure to check for gas leakage.
- If gauge needle does not move from 0 cmHg (0 MPa) to -76 cmHg (-0.1 MPa), in the step ③ above take the following measure:
- If the leak stops when the piping connections are tightened further, continue working from step ③.
- If the leak does not stop when the connections are retightened, repair location of leak.
- Do not release refrigerant during piping work for installation and reinstallation.
- Take care of the liquid refrigerant, it may cause frostbite.

11.3.4 Connect the Cable to the Outdoor Unit

- 1 Remove the control board cover from the unit by loosening the screw.
- 2 **Connection cable** between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 × 1.5 mm² (1.0 ~ 1.75HP) or 4 × 2.5 mm² (2.0 ~ 2.5HP) flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short. Allowable connection cable length of each indoor unit shall be 30 m or less.

Terminals on the outdoor unit	1	2	3	
Colour of wires				
Terminals on the indoor unit	1	2	3	

- 3 Secure the cable onto the control board with the holder (clamper).
- 4 Attach the control board cover back to the original position with screw.
- 5 For wire stripping and connection requirement, refer to instruction 11.2.4 of indoor unit.






 Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires for safety reason.

11.3.5 Piping Insulation

- 1 Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping end to prevent water from going inside the piping.
- 2 If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

11.3.5.1 Cutting and flaring the piping

- 1 Please cut using pipe cutter and then remove the burrs.
- 2 Remove the burrs by using reamer. If burrs are not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- 3 Please make flare after inserting the flare nut onto the copper pipes.



1. To cut

2. To remove burrs

2. To remove burrs

3. To flare

Copper pipe flare will evenly shine and be of even thickness.

Since the flare part comes into contact with the connections, carefully check the flare finish.


12. Operation Control

12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at outdoor unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal setting temperature and intake air temperature.

12.1.1 Internal Setting Temperature

Once the operation starts, remote control setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the air conditioner settings and the operation environment. The final shifted value will be used as internal setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.



12.1.2 Cooling Operation

12.1.2.1 Thermostat control

- Compressor is OFF when Intake Air Temperature Internal Setting Temperature < -1.5°C continue for 3 minutes.
- When compressor is OFF (Thermostat OFF) and AUTO FAN is set, the fan will stop periodically.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature > Compressor OFF point.

12.1.3 Soft Dry Operation

12.1.3.1 Thermostat control

- Compressor is OFF when Intake Air Temperature Internal Setting Temperature < -2.0°C continue for 3 minutes.
- When compressor is OFF (Thermostat OFF) and AUTO FAN is set, the fan will stop periodically.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature > Compressor OFF point.


12.1.4 Heating Operation

12.1.4.1 Thermostat control


- Compressor is OFF when Intake Air Temperature Internal Setting Temperature > +2.0°C continue for 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Intake Air Temperature Internal Setting Temperature < Compressor OFF point.

12.1.5 Automatic Operation

- This mode can be set using remote control and the operation is decided by remote control setting temperature, remote control operation mode and indoor intake air temperature.
- During operation mode judgment, indoor fan motor (with speed of Lo-) is running for 30 seconds to detect the indoor intake air temperature.
- Every 10 minutes, the indoor temperature is judged.
- For the 1st judgment
 - If indoor intake temperature remote control setting temperature ≥ 2°C, COOL mode is decided.
 - If -2°C ≤ indoor intake temperature remote control setting temperature < 2°C, DRY mode is decided.
 - If indoor intake temperature remote control setting temperature < -2°C, HEAT mode is decided.



- For the 2nd judgment onwards
 - o If indoor intake temperature remote control setting temperature ≥ 3°C, if previous operate in DRY mode, then continue in DRY mode, otherwise COOL mode is decided.
 - o If -2°C ≤ indoor intake temperature remote control setting temperature < 3°C, maintain with previous mode
 - If indoor intake temperature remote control setting temperature < -2°C, HEAT mode is decided.



12.2 Indoor Fan Motor Operation

12.2.1 Basic Rotation Speed (rpm)

A. Basic Rotation Speed (rpm)

i. Manual Fan Speed

[Cooling, Dry]

• Fan motor's number of rotation is determined according to remote control setting.

Remote control	0	0	0	0	0
Tab	Hi	Me	Me-	Lo	QLo

CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE

Remote control	0	0	0	0	0
Tab	Hi	Me+	Me	Me-	Lo

CS-UE18QKE

[Heating]

Fan motor's number of rotation is determined according to remote control setting.

Remote control	0	0	0	0	0
Tab	SHi	Me	Me-	Lo	QLo


CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE

Remote control	0	0	0	0	0
Tab	SHi	Me+	Me	Me-	Lo


CS-UE18QKE

ii Auto Fan Speed [Cooling, Dry]

- According to room temperature and setting temperature, indoor fan speed is determined automatically.
- When set temperature is not achieved, the indoor fan will operate according to pattern below.



- When set temperature achieved, the indoor fan speed will be fixed. When thermostat off, the fan stop periodically. [Heating]
- According to indoor pipe temperature, automatic heating fan speed is determined as follows.




B. Feedback control

- Immediately after the fan motor started, feedback control is performed once every second.
- During fan motor on, if fan motor feedback ≥ 2550 rpm or < 50 rpm continue for 10 seconds, then fan motor error counter increase, fan motor is then stop and restart. If the fan motor counter becomes 7 times, then H19 fan motor error is detected. Operation stops and cannot on back.

12.3 Outdoor Fan Motor Operation

Outdoor fan motor is operated with one fan speed only. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



12.4 Airflow Direction

- There are two types of airflow, vertical airflow (directed by horizontal vane) and horizontal airflow (directed by vertical vanes).
- Control of airflow direction can be automatic (angles of direction is determined by operation mode, heat
 exchanger temperature and intake air temperature) and manual (angles of direction can be adjusted using
 remote control).

12.4.1 Vertical Airflow


	Operation Mode			Va	ane Angle	(°)			
				2	3	4	5		
	Auto	Usual (Ventilation)			10 ~ 40				
Cooling	Auto	Control with dew	10 ~ 40						
Cooling	Manual	Usual (Ventilation)	10	17.5	25	32.5	40		
iviariuai	Iviariuai	Control with dew	10	17.5	25	32.5	40		
	Auto	Usual			10 ~ 40				
Dry	Auto	Control with dew			10 ~ 40				
Dry	Manual	Usual	10	17.5	25	32.5	40		
ivialiual		Control with dew	10	17.5	25	32.5	40		
Heating	Manual	Usual	10	21.2	32.5	43.8	55		

CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE

	Operation Mode			Va	ane Angle	(°)	
	Operation Mode			2	3	4	5
	Auto	Usual (Ventilation)			5 ~ 35		
Cooling	Auto	Control with dew			5 ~ 35		
Cooling	Manual	Usual (Ventilation)	5	12.5	20	27.5	35
Ivianuai	Control with dew	5	12.5	20	27.5	35	
	Auto	Usual	5 ~ 35				
Dry	Auto	Control with dew	5 ~ 35				
ыу	Manual	Usual	5	12.5	20	27.5	35
Ivianuai		Control with dew	5	12.5	20	27.5	35
Heating	Manual	Usual	5	17.5	30	42.5	55

CS-UE18QKE


- Automatic vertical airflow direction can be set using remote control; the vane swings up and down within the angles as stated above. For heating mode operation, the angle of the vane depends on the indoor heat exchanger temperature as Figure 1 below. It does not swing during fan motor stop. When the air conditioner is stopped using remote control, the vane will shift to close position.
- 2 Manual vertical airflow direction can be set using remote control; the angles of the vane are as stated above and the positions of the vane are as Figure 2 below. When the air conditioner is stopped using remote control, the vane will shift to close position.



12.4.2 Horizontal Airflow (For UE18QKE only)

1 Automatic horizontal airflow direction can be set using remote control; the vane swings left and right within the angles as stated below. It does not swing during fan motor stop. For heating mode operation, the angle of the vane depends on the indoor heat exchanger temperature as Figure 1 below.

Operation Mode	Vane Angle (°)	
Heating, with heat exchanger temperature		68 ~ 115
		90
Cooling and Soft Dry		68 ~ 115



2 Manual horizontal airflow direction can be set using remote control; the angles of the vane are as stated below and the positions of the vane are as Figure 2 above.


Pattern	1	2	3	4	5
Airflow Direction Patterns at Remote Control			7		
Vane Angle (°)	90	70	80	100	110

12.5 ON Timer Control

ON timer can be set using remote control, the unit with timer set will start operate earlier than the setting time. This is to provide a comfortable environment when reaching the set ON time.

60 minutes before the set time, indoor (at fan speed of Lo-) and outdoor fan motor start operate for 30 seconds to determine the indoor intake air temperature and outdoor air temperature in order to judge the operation starting time.

From the above judgment, the decided operation will start operate earlier than the set time as shown below.



12.6 OFF Timer Control

OFF timer can be set using remote control, the unit with timer set will stop operate at set time.

12.7 Auto Restart Control

- When the power supply is cut off during the operation of air conditioner, the compressor will re-operate within
 three to four minutes (there are 10 patterns between 2 minutes 58 seconds and 3 minutes 52 seconds to be
 selected randomly) after power supply resumes.
- This type of control is not applicable during ON/OFF Timer setting.
- This control can be omitted by open the circuit of JP1 at indoor unit printed circuit board.

12.8 Indication Panel

LED	POWER	TIMER
Color	Green	Orange
Light ON	Operation ON	Timer Setting ON
Light OFF	Operation OFF	Timer Setting OFF

Note:

- If POWER LED is blinking, the possible operation of the unit are Hot Start, during Deice operation, operation mode judgment, or ON timer sampling.
- If Timer LED is blinking, there is an abnormality operation occurs.

13. Protection Control

13.1 Protection Control For All Operations

13.1.1 Restart Control (Time Delay Safety Control)


- The Compressor will not turn on within 3 minutes from the moment operation stops, although the unit is turned on again by pressing OFF/ON button at remote control within this period.
- This control is not applicable if the power supply is cut off and on again.
- This phenomenon is to balance the pressure inside the refrigerant cycle.

13.1.2 Total Running Current

- 1 When the outdoor unit total running current (AC) exceeds X value, the frequency instructed for compressor operation will be decreased.
- 2 If the running current does not exceed X value for 5 seconds, the frequency instructed will be increased.
- 3 However, if total outdoor unit running current exceeds Y value, compressor will be stopped immediately for 3 minutes.

Model	YE9QKE/UE9QKE		YE12QKE/UE12QKE		UE18QKE	
Operation Mode	X (A)	Y (A)	X (A)	Y (A)	X (A)	Y (A)
Cooling / Soft Dry (A)	5.05	15.02	6.75		8.76	
Cooling / Soft Dry (B)	4.57		6.22	15.02	8.25	14.76
Cooling / Soft Dry (C)	4.57		6.22	15.02	8.25	14.70
Heating	4.65		5.92		9.50	

4 The first 30 minutes of cooling operation, (A) will be applied.



13.1.3 IPM (Power transistor) Prevention Control


- Overheating Prevention Control
 - 1 When the IPM temperature rises to 120°C, compressor operation will stop immediately.
 - 2 Compressor operation restarts after 3 minutes the temperature decreases to 110°C.
 - 3 If this condition repeats continuously 4 times within 20 minutes, timer LED will be blinking ("F96" is indicated).

DC Peak Current Control

- When electric current to IPM exceeds set value of $16.0 \pm 2.0 \text{A}$ (YE,UE9/12QKE) and $20.2 \pm 2.7 \text{A}$ (UE18QKE), the compressor will stop operate. Then, operation will restart after 3 minutes.
- 2 If the set value is exceeded again more than 30 seconds after the compressor starts, the operation will restart after 3 minute.
- If the set value exceeded again within 30 seconds after the compressor starts, the operation will restart after 1 minute. If this condition repeats continuously for 7 times, all indoor and outdoor relays will be cut off, timer LED will be blinking ("F99" is indicated).

13.1.4 Compressor Overheating Prevention Control

- Instructed frequency for compressor operation will be regulated by compressor discharge temperature. The changes of frequency are as below.
- If compressor discharge temperature exceeds 103°C, compressor will be stopped, occurs 4 times per 20 minutes, timer LED will be blinking. ("F97" is indicated.)



13.1.5 Low Pressure Prevention Control (Gas Leakage Detection)

- Control start conditions
 - For 5 minutes, the compressor continuously operates and outdoor total current is between 1.22A and 1.38 A (YE,UE9/12QKE), between 0.75A and 0.95A (UE18QKE).
 - During Cooling and Soft Dry operations:
 Indoor suction temperature indoor piping temperature is below 4°C.
 - During Heating operations : Indoor piping temperature - indoor suction is under 5°C.
- Control contents
 - o Compressor stops (and restart after 3 minutes).
 - If the conditions above happen 2 times within 20 minutes, the unit will:
 - Stop operation
 - Timer LED blinks and "F91" indicated.

13.1.6 Low Frequency Protection Control 1

 When the compressor operate at frequency lower than 24 Hz continued for 20 minutes, the operation frequency will be changed to 23 Hz for 2 minutes.

13.1.7 Low Frequency Protection Control 2


• When all the below conditions comply, the compressor frequency will change to lower frequency.

Temperature, T, for:	Cooling/Soft Dry	Heating
Indoor intake air (°C)	T < 14 or T ≥ 30	T < 14 or T ≥ 28
Outdoor air (°C)	T < 13 or T ≥ 38	T < 4 or T ≥ 24
Indoor heat exchanger (°C)	T < 30	T ≥ 0

13.2 Protection Control For Cooling & Soft Dry Operation

13.2.1 Outdoor Air Temperature Control

- The compressor operating frequency is regulated in accordance to the outdoor air temperature as shown in the diagram below.
- This control will begin 1 minute after the compressor starts.
- Compressor frequency will adjust base on outdoor air temperature.



13.2.2 Cooling Overload Control

- Detects the Outdoor pipe temperature and carry out below restriction/limitation (Limit the compressor Operation frequency).
- The compressor stop if outdoor pipe temperature exceeds 61°C.
- If the compressor stops 4 times in 20 minutes, Timer LED blinking (F95 indicated: outdoor high pressure rise protection).

13.2.3 Freeze Prevention Control 1

- When indoor heat exchanger temperature is lower than 0°C continuously for 6 minutes, compressor will stop operating.
- Compressor will resume its operation 3 minutes after the indoor heat exchanger is higher than 5°C.
- At the same time, indoor fan speed will be higher than during its normal operation.
- If indoor heat exchanger temperature is higher than 5°C for 5 minutes, the fan speed will return to its normal operation.

13.2.4 Freeze Prevention Control 2

- Control start conditions
 - During Cooling operation and soft dry operation
 - During thermo OFF condition, indoor intake temperature is less than 10°C or
 - Compressor stops for freeze prevention control
 - Either one of the conditions above occurs 5 times in 60 minutes.
- Control contents
 - Operation stops
 - o Timer LED blinks and "H99" indicated

13.2.5 Dew Prevention Control 1

- To prevent dew formation at indoor unit discharge area.
- This control will be activated if:
 - o Outdoor air temperature and Indoor pipe temperature judgment by microcontroller is fulfilled.
 - o When Cooling or Dry mode is operated more than 20 minutes or more.
- This control stopped if:
 - o Compressor stopped.
 - o Remote control setting changed (fan speed / temperature).
 - Outdoor air temperature and indoor intake temperature changed.
- Fan speed will be adjusted accordingly in this control.

13.2.6 Odor Cut Control

- To reduce the odor released from the unit.
 - Start Condition
 - AUTO FAN Speed is selected during COOL or DRY operation.
 - During freeze prevention control and timer preliminary operation, this control is not applicable.
 - Control content
 - Depends on compressor conditions:
 - Compressor OFF → Compressor ON.
 - The indoor unit fan stops temporarily and then starts to blow at minimum airflow for 30 seconds.
 - 2. Compressor ON → Compressor OFF.
 - The indoor unit fan stops for 90 seconds and then blows at minimum airflow for 20 seconds.


13.3 Protection Control For Heating Operation

13.3.1 Intake Air Temperature Control

Compressor will operate at limited freq., if indoor intake air temperature is 30°C or above.


13.3.2 Outdoor Air Temperature Control

 The Max current value is regulated when the outdoor air temperature rise above 14°C in order to avoid compressor overloading.



13.3.3 Overload Protection Control

- The compressor operating frequency is regulated in accordance to indoor heat exchanger temperature as shown below.
- If the heat exchanger temperature exceeds 60°C, compressor will stop.



13.3.4 Low Temperature Compressor Oil Return Control

 In heating operation, if the outdoor temperature falls below -10°C when compressor starts, the compressor frequency will be regulated up to 600 seconds.

13.3.5 Cold Draught Prevention Control


When indoor pipe temperature is low, cold draught operation starts where indoor fan speed will be reduced.

13.3.6 Deice Operation

 When outdoor pipe temperature and outdoor air temperature is low, deice operation start where indoor fan motor and outdoor fan motor stop and operation LED blinks.

14. Servicing Mode

14.1 Auto OFF/ON Button




1 AUTO OPERATION MODE

The Auto operation will be activated immediately once the Auto OFF/ON button is pressed. This operation can be used to operate air conditioner with limited function if remote control is misplaced or malfunction.

2 TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)

The Test Run operation will be activated if the Auto OFF/ON button is pressed continuously for more than 5 seconds. A "beep" sound will heard at the fifth seconds, in order to identify the starting of Test Run operation (Forced cooling operation). Within 5 minutes after Forced cooling operation start, the Auto OFF/ON button is pressed for more than 5 seconds. A 2 "beep" sounds will heard at the fifth seconds, in order to identify the starting of Forced heating operation.


The Auto OFF/ON button may be used together with remote control to set / change the advance setting of air conditioner operation.




3 REMOTE CONTROL NUMBER SWITCH MODE

The Remote Control Number Switch Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 11 seconds (3 "beep" sounds will occur at 11th seconds to identify the Remote Control Number Switch Mode is in standby condition) and press "AC RESET" button and then press any button at remote control to transmit and store the desired transmission code to the EEPROM.

There are 4 types of remote control transmission code could be selected and stored in EEPROM of indoor unit. The indoor unit will only operate when received signal with same transmission code from remote control. This could prevent signal interference when there are 2 or more indoor units installed nearby together. To change remote control transmission code, short or open jumpers at the remote control printed circuit board.



(YE12QKE, UE9QKE, UE12QKE, UE18QKE)



 During Remote Control Number Switch Mode, press any button at remote control to transmit and store the transmission code to the EEPROM.

Remote Control No.

A (Default)

В

С

D

4 REMOTE CONTROL RECEIVING SOUND OFF/ON MODE

The Remote Control Receiving Sound OFF/ON Mode will be activated if the Auto OFF/ON button is pressed continuously for more than 16 seconds (4 "beep" sounds will occur at 16th seconds to identify the Remote Control Receiving Sound Off/On Mode is in standby condition) and press "AC Reset" button at remote control.

Press "Auto OFF/ON button" to toggle remote control receiving sound.

- Short "beep": Turn OFF remote control receiving sound.
- o Long "beep": Turn ON remote control receiving sound.

After Auto OFF/ON Button is pressed, the 20 seconds counter for Remote Control Receiving Sound OFF/ON Mode is restarted.

14.2 Remote Control Button

14.2.1 SET Button

- To check remote control transmission code and store the transmission code to EEPROM:
 - o Press "Set" button continuously for 10 seconds by using pointer.
 - o Press "Timer Set" button until a "beep" sound is heard as confirmation of transmission code changed.

14.2.2 RESET (RC)

- To clear and restore the remote control setting to factory default.
 - Press once to clear the memory.

14.2.3 RESET (AC)

- To restore the unit's setting to factory default.
 - Press once to restore the unit's setting.

14.2.4 TIMER ▲

- To change indoor unit indicator's LED intensity.
 - Press continuously for 5 seconds.

14.2.5 TIMER ▼

- To change remote control display from Degree Celsius (°C) to Degree Fahrenheit (°F).
 - o Press continuously for 10 seconds.

15. Troubleshooting Guide


15.1 Refrigeration Cycle System

In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle. Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a fan. The normal outlet air temperature and pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

Normal Pressure and Outlet Air Temperature (Standard)

	Gas pressure MPa (kg/cm²G)	Outlet air temperature (°C)
Cooling Mode	0.9 ~ 1.2 (9 ~ 12)	12 ~ 16
Heating Mode	2.3 ~ 2.9 (23 ~ 29)	36 ~ 45

- ★ Condition: Indoor fan speed; High
 - Outdoor temperature 35°C at cooling mode and 7°C at heating mode.
 - Compressor operates at rated frequency



15.2 Relationship Between The Condition Of The Air Conditioner And Pressure And Electric Current

Condition of the	Cooling Mode			Heating Mode		
air conditioner	Low Pressure	High Pressure	Electric current during operation	Low Pressure	High Pressure	Electric current during operation
Insufficient refrigerant (gas leakage)	Ä	Ä	R	Ä	Ä	n
Clogged capillary tube or Strainer	Ä	Ä	u	71	7	7
Short circuit in the indoor unit	Ä	Ä	R	Я	Я	71
Heat radiation deficiency of the outdoor unit	7	7	7	Ä	Ä	Ä
Inefficient compression	7	Ä	Ä	7	Ä	'n

[•] Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

15.3 Breakdown Self Diagnosis Function

15.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- Once abnormality has occurred during operation, the unit will stop its operation, and Timer LEDs blink
- Although Timer LED goes off when power supply is turned off, if the unit is operated under a breakdown condition, the LED will light up again.
- In operation after breakdown repair, the Timer LED will no more blink. The last error code (abnormality) will be stored in IC memory.

15.3.2 To Make a Diagnosis

- 1 Timer LED start to blink and the unit automatically stops the operation.
- 2 Press the CHECK button on the remote controller continuously for 5 seconds.
- 3 "--" will be displayed on the remote controller display.
 - Note: Display only for "- -". (No transmitting signal, no receiving sound and no Power LED blinking.)
- 4 Press the "TIMER" ▲ or ▼ button on the remote controller. The code "H00" (no abnormality) will be displayed and signal will be transmitted to the main unit.
- 5 Every press of the button (up or down) will increase abnormality numbers and transmit abnormality code signal to the main unit.
- When the latest abnormality code on the main unit and code transmitted from the remote controller are matched, power LED will light up for 30 seconds and a beep sound (continuously for 4 seconds) will be heard. If no codes are matched, power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled by pressing the CHECK button continuously for 5 seconds or without any operation the remote control for 30 seconds.
- 8 The LED will be off if the unit is turned off or the RESET button on the main unit is pressed.

15.3.3 To Display Memorized Error Code (Protective Operation) status:

- 1 Turn power on.
- 2 Press the CHECK button on the remote controller continuously for 5 seconds.
- 3 "--" will be displayed on the remote controller display.
 - Note: Display only for "- -". (No transmitting signal, no receiving sound and no Power LED blinking.)
- 4 Press the "TIMER" ▲ or ▼ button on the remote controller. The code "H00" (no abnormality) will be displayed and signal will be transmitted to the main unit. The power LED lights up. If no abnormality is stored in the memory, three beeps sound will be heard.
- 5 Every press of the button (up or down) will increase abnormality numbers and transmit abnormality code signal to the main unit.

- 6 When the latest abnormality code on the main unit and code transmitted from the remote controller are matched, power LED will light up for 30 seconds and a beep sound (continuously for 4 seconds) will be heard. If no codes are matched, power LED will light up for 0.5 seconds and no sound will be heard.
- 7 The breakdown diagnosis mode will be canceled unless pressing the CHECK button continuously for 5 seconds or operating the unit for 30 seconds.
- 8 The same diagnosis can be repeated by turning power on again.



15.3.4 To Clear Memorized Error (Protective Operation) Status after Repair:

- 1 Turn power on (in standby condition).
- 2 Press the AUTO button for 5 seconds (A beep receiving sound) on the main unit to operate the unit at Forced Cooling Operation mode.
- 3 Press the CHECK button on the remote controller for about 1 second with a pointed object to transmit signal to main unit. A beep sound is heard from main unit and the data is cleared.

15.3.5 Temporary Operation (Depending On Breakdown Status)

- 1 Press the AUTO button (A beep receiving sound) on the main unit to operate the unit. (Remote control will become possible.)
- 2 The unit can temporarily be used until repaired.

Error Code	Operation	Temporary items	
H23	Cooling	Emergency	
H27, H28	Cooling, Heating	Operation with	
H26	Cooling, Heating	limited power	

15.4 Error Codes Table

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H00	No memory of failure	—	Normal operation	_	_
H11	Indoor/outdoor abnormal communication	After operation for 1 minute	Indoor fan only operation can start by entering into force cooling operation	Indoor/outdoor communication not establish	Indoor/outdoor wire terminal Indoor/outdoor PCB Indoor/outdoor connection wire
H12	Indoor unit capacity unmatched	90s after power supply	_	Total indoor capability more than maximum limit or less than minimum limit, or number of indoor unit less than two	Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue
H14	Indoor intake air temperature sensor abnormality	Continuous for 5s	_	Indoor intake air temperature sensor open or short circuit	Indoor intake air temperature sensor lead wire and connector
H15	Compressor temperature sensor abnormality	Continuous for 5s	_	Compressor temperature sensor open or short circuit	Compressor temperature sensor lead wire and connector
H16	Outdoor current transformer (CT) abnormality	-	_	Current transformer faulty or compressor faulty	Outdoor PCB faulty or compressor faulty
H19	Indoor fan motor merchanism lock	Continuous happen for 7 times	_	Indoor fan motor lock or feedback abnormal	 Fan motor lead wire and connector Fan motor lock or block
H23	Indoor heat exchanger temperature sensor abnormality	Continuous for 5s	ı	Indoor heat exchanger temperature sensor open or short circuit	Indoor heat exchanger temperature sensor lead wire and connector
H24	Indoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	1	Indoor heat exchanger temperature sensor 2 open or short circuit	Indoor heat exchanger temperature sensor 2 lead wire and connector
H25	Indoor ion device abnormality	Port is ON for 10s during ion device off	_	_	• ion device PCB
H27	Outdoor air temperature sensor abnormality	Continuous for 5s	_	Outdoor air temperature sensor open or short circuit	Outdoor air temperature sensor lead wire and connector
H28	Outdoor heat exchanger temperature sensor 1 abnormality	Continuous for 5s	1	Outdoor heat exchanger temperature sensor 1 open or short circuit	Outdoor heat exchanger temperature sensor 1 lead wire and connector
H30	Outdoor discharge pipe temperature sensor abnormality	Continuous for 5s	1	Outdoor discharge pipe temperature sensor open or short circuit	Outdoor discharge pipe temperature sensor lead wire and connector
H32	Outdoor heat exchanger temperature sensor 2 abnormality	Continuous for 5s	I	Outdoor heat exchanger temperature sensor 2 open or short circuit	Outdoor heat exchanger temperature sensor 2 lead wire and connector
H33	Indoor / outdoor misconnection abnormality	I	1	Indoor and outdoor rated voltage different	Indoor and outdoor units check
H34	Outdoor heat sink temperature sensor abnormality	Continuous for 2s		Outdoor heat sink temperature sensor open or short circuit	Outdoor heat sink sensor
H36	Outdoor gas pipe temperature sensor abnormality	Continuous for 5s	Heating protection operation only	Outdoor gas pipe temperature sensor open or short circuit	Outdoor gas pipe temperature sensor lead wire and connector
H37	Outdoor liquid pipe temperature sensor abnormality	Continuous for 5s	Cooling protection operation only	Outdoor liquid pipe temperature sensor open or short circuit	Outdoor liquid pipe temperature sensor lead wire and connector
H38	Indoor/Outdoor mismatch (brand code)	_	_	Brand code not match	Check indoor unit and outdoor unit
H39	Abnormal indoor operating unit or standby units	3 times happen within 40 minutes	_	Wrong wiring and connecting pipe, expansion valve abnormality, indoor heat exchanger sensor open circuit	Check indoor/outdoor connection wire and connection pipe Indoor heat exchanger sensor lead wire and connector Expansion valve and lead wire and connector

Diagnosis display	Abnormality / Protection control	Abnormality Judgment	Protection Operation	Problem	Check location
H41	Abnormal wiring or piping connection	_	_	Wrong wiring and connecting pipe, expansion valve abnormality	Check indoor/outdoor connection wire and connection pipe Expansion valve and lead wire and connector
H59	ECONAVI sensor abnormality	Continuous for 25s	_	ECONAVI sensor open or short circuit	ECONAVI sensor (defective or disconnected) ECONAVI PCB
H64	Outdoor high pressure sensor abnormality	Continuous for 1 minutes	_	High pressure sensor open circuit during compressor stop	High pressure sensor Lead wire and connector
H70	Light sensor abnormality	Continuous for 24 hours, 15days	_	Light sensor open or short circuit	Light sensor (defective or disconnected)
H97	Outdoor fan motor mechanism lock	2 times happen within 30 minutes	_	Outdoor fan motor lock or feedback abnormal	Outdoor fan motor lead wire and connector Fan motor lock or block
H98	Indoor high pressure protection	_	_	Indoor high pressure protection (Heating)	Check indoor heat exchanger Air filter dirty Air circulation short circuit
H99	Indoor operating unit freeze protection	_	_	Indoor freeze protection (Cooling)	Check indoor heat exchanger Air filter dirty Air circulation short circuit
F11	4-way valve switching abnormality	4 times happen within 30 minutes	_	4-way valve switching abnormal	4-way valve Lead wire and connector
F17	Indoor standby units freezing abnormality	3 times happen within 40 minutes	_	Wrong wiring and connecting pipe, expansion valve leakage, indoor heat exchanger sensor open circuit	Check indoor/outdoor connection wire and pipe Indoor heat exchanger sensor lead wire and connector Expansion valve lead wire and connector
F90	Power factor correction (PFC) circuit protection	4 times happen within 10 minutes	_	Power factor correction circuit abnormal	Outdoor PCB faulty
F91	Refrigeration cycle abnormality	2 times happen within 20 minutes	_	Refrigeration cycle abnormal	Insufficient refrigerant or valve close
F93	Compressor abnormal revolution	4 times happen within 20 minutes	_	Compressor abnormal revolution	Power transistor module faulty or compressor lock
F94	Compressor discharge overshoot protection	4 times happen within 30 minutes	_	Compressor discharge pressure overshoot	Check refrigeration system
F95	Outdoor cooling high pressure protection	4 times happen within 20 minutes	_	Cooling high pressure protection	Check refrigeration system Outdoor air circuit
F96	Power transistor module overheating protection	4 times happen within 30 minutes	_	Power transistor module overheat	PCB faulty Outdoor air circuit (fan motor)
F97	Compressor overheating protection	3 times happen within 30 minutes	_	Compressor overheat	Insufficient refrigerant
F98	Total running current protection	3 times happen within 20 minutes		Total current protection	Check refrigeration system Power source or compressor lock
F99	Outdoor direct current (DC) peak detection	Continuous happen for 7 times	_	Power transistor module current protection	Power transistor module faulty or compressor lock

15.5 Self-diagnosis Method


15.5.1 H11 (Indoor/Outdoor Abnormal Communication)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused

- Faulty indoor unit PCB.
- Faulty outdoor unit PCB.
- Indoor unit-outdoor unit signal transmission error due to wiring error.
- Indoor unit-outdoor unit signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.




15.5.2 H12 (Indoor/Outdoor Capacity Rank Mismatched)

Malfunction Decision Conditions

• During startup, error code appears when different types of indoor and outdoor units are interconnected.

Malfunction Caused

- Wrong models interconnected.
- Wrong indoor unit or outdoor unit PCBs mounted.
- Indoor unit or outdoor unit PCBs defective.
- Indoor-outdoor unit signal transmission error due to wrong wiring.
- Indoor-outdoor unit signal transmission error due to breaking of wire 3 in the connection wires between the indoor and outdoor units.




15.5.3 H14 (Indoor Intake Air Temperature Sensor Abnormality)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the temperatures detected by the indoor intake air temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- · Faulty PCB.




15.5.4 H15 (Compressor Temperature Sensor Abnormality)

Malfunction Decision Conditions

• During startup and operation of cooling and heating, the temperatures detected by the outdoor compressor temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.5 H16 (Outdoor Current Transformer)

Malfunction Decision Conditions

An input current, detected by Current Transformer CT, is below threshold value when the compressor is
operating at certain frequency value for 3 minutes.

Malfunction Caused

- · Lack of gas
- Broken CT (current transformer)
- Broken Outdoor PCB




15.5.6 H19 (Indoor Fan Motor – DC Motor Mechanism Locked)

Malfunction Decision Conditions

• The rotation speed detected by the Hall IC during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm).

Malfunction Caused

- Operation stops due to short circuit inside the fan motor winding.
- Operation stops due to breaking of wire inside the fan motor.
- Operation stops due to breaking of fan motor lead wires.
- Operation stops due to Hall IC malfunction.
- Operation error due to faulty indoor unit PCB.




15.5.7 H23 (Indoor Pipe Temperature Sensor Abnormality)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the temperatures detected by the indoor heat exchanger temperature sensor are used to determine sensor errors.

Malfunction Caused

- · Faulty connector connection.
- Faulty sensor.
- · Faulty PCB.




15.5.8 H27 (Outdoor Air Temperature Sensor Abnormality)

Malfunction Decision Conditions

• During startup and operation of cooling and heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.9 H28 (Outdoor Pipe Temperature Sensor Abnormality)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- · Faulty PCB.




15.5.10 H30 (Compressor Discharge Temperature Sensor Abnormality)

Malfunction Decision Conditions

• During startup and operation of cooling and heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.11 H32 (Outdoor Heat Exchanger Temperature Sensor 2 Abnormality)

Malfunction Decision Conditions

• During startup and operation of cooling and heating, the temperatures detected by the outdoor heat exchanger temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- · Faulty PCB.




15.5.12 H33 (Unspecified Voltage between Indoor and Outdoor)

Malfunction Decision Conditions

The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused

- Wrong models interconnected.
- Wrong indoor unit and outdoor unit PCBs used.
- Indoor unit or outdoor unit PCB defective.




15.5.13 H34 (Outdoor Heat Sink Temperature Sensor Abnormality)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the temperatures detected by the outdoor heat sink temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.14 H36 (Outdoor Gas Pipe Sensor Abnormality)

Malfunction Decision Conditions

• During startup and operation of cooling and heating, the temperatures detected by the outdoor gas pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.15 H37 (Outdoor Liquid Pipe Temperature Sensor Abnormality)

Malfunction Decision Conditions

 During startup and operation of cooling and heating, the temperatures detected by the outdoor liquid pipe temperature sensor are used to determine sensor errors.

Malfunction Caused

- Faulty connector connection.
- Faulty sensor.
- Faulty PCB.




15.5.16 H98 (Error Code Stored in Memory and no alarm is triggered / no TIMER LED flashing)

Malfunction Decision Conditions

- Indoor high pressure is detected when indoor heat exchanger is detecting very high temperature when the unit is operating in heating operation.
- Phenomena: unit is stopping and re-starting very often in heating mode

Malfunction Caused

- Indoor heat exchanger thermistor
- Clogged air filter or heat exchanger
- Over-bent pipe (liquid side)



15.5.17 H99 (Indoor Freeze Prevention Protection: Cooling or Soft Dry)


Error Code will not display (no Timer LED blinking) but store in EEPROM

Malfunction Decision Conditions

Freeze prevention control takes place (when indoor pipe temperature is lower than 2°C)

Malfunction Caused

- · Air short circuit at indoor unit
- Clogged indoor unit air filter
- Dust accumulation on the indoor unit heat exchanger
- 2/3 way valve closed
- Faulty indoor unit fan motor
- Refrigerant shortage (refrigerant leakage)
- Clogged expansion valve or strainer
- Faulty indoor pipe temperature sensor
- Faulty indoor unit PCB




15.5.18 F11 (4-way valve Abnormality)

Malfunction Decision Conditions

• When indoor heat exchanger is cold during heating (except deice) or when indoor heat exchanger is hot during cooling and compressor operating, the 4-way valve is detected as malfunction.

Malfunction Caused

- Indoor heat exchanger (pipe) thermistor
- 4-way valve malfunction



^{*} Check gas side pipe – for hot gas flow in cooling mode

15.5.19 F17 (Indoor Standby Units Freezing Abnormality)

Malfunction Decision Conditions


 When the different between indoor intake air temperature and indoor pipe temperature is above 10°C or indoor pipe temperature is below -1.0°C.

Remark:

When the indoor standby unit is freezing, the outdoor unit transfers F17 error code to the corresponding indoor unit and H39 to other indoor unit(s).

Malfunction Caused

- Wrong wiring connection
- Faulty sensor
- Faulty expansion valve




15.5.20 F90 (Power Factor Correction Protection)

Malfunction Decision Conditions

- To maintain DC voltage level supply to power transistor.
- To detect high DC voltage level after rectification.

Malfunction Caused

- During startup and operation of cooling and heating, when Power Factor Correction (PFC) protection circuitry at the outdoor unit main PCB senses abnormal DC voltage level for power transistors.
- When DC voltage detected is LOW, transistor switching will turn ON by controller to push-up the DC level.
- When DC voltage detected is HIGH (391Vdc 425Vdc), active LOW signal will send by the controller to turn OFF relay RY-C.




15.5.21 F91 (Refrigeration Cycle Abnormality)

Malfunction Decision Conditions

The input current is low while the compressor is running at higher than the setting frequency.

Malfunction Caused

- Lack of gas.
- 3-way valve close.




15.5.22 F93 (Compressor Rotation Failure)

Malfunction Decision Conditions

• A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused

- Compressor terminal disconnect
- Faulty Outdoor PCB
- Faulty compressor




15.5.23 F95 (Outdoor High Pressure Protection: Cooling or Soft Dry)

Malfunction Decision Conditions

• During operation of cooling or soft dry, when outdoor unit heat exchanger high temperature data is detected by the outdoor unit heat exchanger thermistor.

Malfunction Caused

- Outdoor heat exchanger temperature rise due to short-circuit of hot discharge air flow.
- Outdoor heat exchanger temperature rise due to defective of outdoor fan motor.
- Outdoor heat exchange temperature rise due to defective outdoor heat exchanger thermistor.
- Outdoor heat exchanger temperature rise due to defective of outdoor unit PCB.



15.5.24 F96 (IPM Overheating)

Malfunction Decision Conditions

 During operating of cooling and heating, when IPM temperature data (120°C) is detected by the IPM temperature sensor.

Multi Models Only


- o Compressor Overheating: During operation of cooling and heating, when the compressor OL is activated.
- Heat Sink Overheating: During operation of cooling and heating, when heat sink temperature data (90°C) is detected by the heat sink temperature sensor.

Malfunction Caused

- IPM overheats due to short circuit of hot discharge air flow.
- IPM overheats due to defective of outdoor fan motor.
- IPM overheats due to defective of internal circuitry of IPM.
- IPM overheats due to defective IPM temperature sensor.

Multi Models Only

- Compressor OL connector poor contact.
- Compressor OL faulty.




15.5.25 F97 (Compressor Overheating)

Malfunction Decision Conditions

• During operation of cooling and heating, when compressor tank temperature data (103°C) is detected by the compressor tank temperature sensor.

Malfunction Caused

- Faulty compressor tank temperature sensor
- 2/3 way valve closed
- Refrigerant shortage (refrigerant leakage)
- Faulty outdoor unit PCB
- · Faulty compressor




15.5.26 F98 (Input Over Current Detection)

Malfunction Decision Conditions

 During operation of cooling and heating, when an input over-current (X value in Total Running Current Control) is detected by checking the input current value being detected by current transformer (CT) with the compressor running.

Malfunction Caused

- Excessive refrigerant.
- Faulty outdoor unit PCB.




15.5.27 F99 (DC Peak Detection)

Malfunction Decision Conditions

During startup and operation of cooling and heating, when inverter DC peak data is received by the outdoor internal DC Peak sensing circuitry.

Malfunction Caused

- DC current peak due to compressor failure.
- DC current peak due to defective power transistor(s).
- DC current peak due to defective outdoor unit PCB.
- DC current peak due to short circuit.



16. Disassembly and Assembly Instructions



High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

16.1 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures

16.1.1 CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE

16.1.1.1 To remove front grille




Figure 1

16.1.1.2 To remove horizontal vane





Figure 2

16.1.1.3 To remove power electronic controller



 Detach connectors as labeled from the electronic controller. Then pull out main controller gently





Figure 3 Figure 4

16.1.1.4 To remove discharge grille



11. Then pull the discharge grille downward gently to dismantle it

Figure 5

16.1.1.5 To remove control board




Figure 6

16.1.1.6 To remove cross flow fan and indoor fan motor




Figure 7





Figure 8

16. Push the holdfast to the left and lift up the evaporator.




17. Remove the cross flow fan from the unit by pulling it to the left and downward.

18. Fan motor can be removed after the removal of cross flow fan.

Reminder: To reinstall the fan motor, adjust the fan motor connector to 45° towards you before fixing control board.

Figure 9



Reminder: To reinstall the cross flow fan, ensure cross flow fan is in line as shown in figure 10

Figure 10



High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.

16.2 Indoor Electronic Controllers, Cross Flow Fan and Indoor Fan Motor Removal Procedures

16.2.1 CS-UE18QKE

16.2.1.1 To remove front grille




Figure 1

16.2.1.2 To remove horizontal vane




Figure 2

16.2.1.3 To remove power electronic controller




Figure 3 Figure 4

16.2.1.4 To remove discharge grille




Figure 5

16.2.1.5 To remove control board




Figure 6

16.2.1.6 To remove cross flow fan and indoor fan motor




Figure 7




Figure 8

18. Push the holdfast to the left and lift up the evaporator.




Figure 9





Figure 10

16.3 Outdoor Electronic Controller Removal Procedure

16.3.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE

A Caution! When handling electronic controller, be careful of electrostatic discharge.

1. Remove the 3 screws of the Top Panel.



2. Remove the 6 screws of the Front Panel.




Fig. 2

- 3. Remove the screw of the Terminal Board Cover.
- 4. Remove the Top Cover of the Control Board by 4 hooks.




Fig. 3

5. Remove the Control Board as follows:




Fig. 4




Fig. 5




Fig. 6

16.3.2 CU-UE18QKE

 \triangle Caution! When handling electronic controller, be careful of electrostatic discharge.

1. Remove the 5 screws of the Top Panel.




Fig. 1

2. Remove the 8 screws of the Front Panel.




Fig. 2

- 3. Remove the screw of the Terminal Board Cover.
- 4. Remove the Top Cover of the Control Board by 4 hooks.




Fig. 3

5. Remove the Control Board as follows:




Fig. 4




Fig. 5




Fig. 6

17. Technical Data

Technical data provided are based on the air conditioner running under free frequency.

17.1 Cool Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Cool mode at 16°C

Voltage: 230V

17.1.1 CS-YE9QKE/CU-YE9QKE CS-UE9QKE/CU-UE9QKE

Indoo	or (°C)	Outdoor DB (°C)											
DB	WB	5			16			25			35		
	VVD	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	2525	2328	546	2711	2341	407	2546	2293	546	2500	2387	720
21	22.0	2854	1732	443	2800	1673	405	2778	1610	522	2449	1525	707
23	15.7	2547	2522	486	2404	2380	455	2306	2283	560	2120	2098	730
23	18.4	2504	1656	513	2543	1657	439	2534	1623	545	2174	1574	720
20	13.3	1954	1934	430	1574	1559	201	1782	1764	423	1948	1928	732
20	15.8	2057	1491	408	2043	1460	387	2257	1588	558	1979	1511	725

(Dry bulb value based on 46% humidity)

17.1.2 CS-YE12QKE/CU-YE12QKE CS-UE12QKE/CU-UE12QKE

Indoo	or (°C)	Outdoor DB (°C)											
DB WB	WB	5			16			25			35		
	VVD	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	3535	2919	827	3796	2935	615	3564	2874	827	3500	2993	1090
21	22.0	3995	2171	670	3920	2098	612	3890	2018	791	3428	1912	1071
23	15.7	3566	3530	736	3366	3333	689	3228	3196	848	2967	2938	1105
23	18.4	3505	2076	776	3561	2077	665	3547	2035	826	3044	1973	1089
20	13.3	2735	2708	651	2204	2182	305	2495	2470	641	2727	2699	1108
20	15.8	2879	1869	617	2860	1830	586	3160	1991	845	2771	1894	1098

(Dry bulb value based on 46% humidity)

17.1.3 CS-UE18QKE/CU-UE18QKE

Indoo	or (°C)	Outdoor DB (°C)											
DB	WB	5			16			25			35		
	VVD	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP	TC	SHC	IP
27	19.0	5535	4070	1067	5443	4070	1061	5064	3848	1333	5000	4043	1540
21	22.0	5669	3066	1122	5871	3238	1064	5507	3045	1348	5076	2324	1560
23	15.7	4957	3899	1130	5047	3919	1061	4685	3766	1308	4209	3584	1626
23	18.4	5357	2968	1180	5508	3093	1063	5150	2931	1322	4634	2759	1656
20	13.3	4123	3589	964	4412	3730	888	4388	3726	1307	3882	3447	1598
20	15.8	4865	3061	828	5895	3441	1439	5259	3189	1678	4336	1533	1740

(Dry bulb value based on 46% humidity)

TC - Total Cooling Capacity (W)

SHC - Sensible Heat Capacity (W)

IP - Input Power (W)

17.2 Heat Mode Performance Data

Unit setting: Standard piping length, Hi Fan, Heat mode at 30°C

Voltage: 230V

17.2.1 CS-YE9QKE/CU-YE9QKE CS-UE9QKE/CU-UE9QKE

Indoor (°C)	Outdoor WB (°C)											
DB	-10		-7		2		7		12			
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP		
24	1865	1079	2488	1124	2743	1060	3148	867	3418	893		
20	1965	1064	2660	1120	2970	1040	3300	860	3613	873		
16	1586	1038	2733	1108	3052	1049	3365	883	3524	858		

17.2.2 CS-YE12QKE/CU-YE12QKE CS-UE12QKE/CU-UE12QKE

Indoor (°C)	Outdoor WB (°C)											
DB	-10		-7		2		7	7	12			
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP		
24	2308	1358	2993	1415	3309	1325	3695	1109	4012	1142		
20	2431	1340	3200	1410	3700	1300	4000	1100	4241	1117		
16	1962	1307	3288	1395	3682	1311	3949	1129	4137	1098		

17.2.3 CS-UE18QKE/CU-UE18QKE

Indoor (°C)	Outdoor WB (°C)											
DB	-10		-7		2		7		12			
	TC	IP	TC	IP	TC	IP	TC	IP	TC	IP		
24	3991	2060	4775	2172	5500	2128	5261	1554	5790	1656		
20	4109	1986	4790	2090	5580	2040	5400	1470	6021	1589		
16	3837	1897	4832	1998	5640	1954	5534	1390	6182	1505		

TC - Total Cooling Capacity (W) SHC - Sensible Heat Capacity (W) IP - Input Power (W)

18. Service Data

Service data provided are based on the air conditioner running under rated frequency during forced cooling / forced heating mode.

18.1 Cool Mode Outdoor Air Temperature Characteristic

Condition


- Indoor room temperature: 27°C DryBulb/19°C Wet Bulb


- Unit setting: Standard piping length, forced cooling at 16°C, Hi fan


- Compressor frequency: Rated for cooling operation

Piping length: 5mVoltage: 230V


18.1.1 CS/CU-YE9QKE CS/CU-UE9QKE








18.1.2 CS/CU-YE12QKE CS/CU-UE12QKE



18.1.3 CS/CU-UE18QKE




18.2 Heat Mode Outdoor Air Temperature Characteristic


Condition

- Indoor room temperature: 20°C DryBulb/ -°C Wet Bulb
- Unit setting: Standard piping length, forced heating at 30°C, Hi fan
- Compressor frequency: Rated for Heating operation
- Piping length: 5mVoltage: 230V


18.2.1 CS/CU-YE9QKE CS/CU-UE9QKE



18.2.2 CS/CU-YE12QKE CS/CU-UE12QKE




18.2.3 CS/CU-UE18QKE



18.3 Piping Length Correction Factor


The characteristic of the unit has to be corrected in accordance with the piping length.

18.3.1 CS/CU-YE9QKE CS/CU-YE12QKE CS/CU-UE9QKE CS/CU-UE12QKE



Note: The graphs show the factor after added right amount of additional refrigerant.

18.3.2 CS/CU-UE18QKE




Note: The graphs show the factor after added right amount of additional refrigerant.

19. Exploded View and Replacement Parts List

19.1 Indoor Unit

19.1.1 CS-YE9QKE CS-YE12QKE CS-UE9QKE CS-UE12QKE



Note

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-YE9QKE	CS-YE12QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD50C1653	←	
<u> </u>	2	FAN MOTOR	1	L6CBYYYL0037	←	0
	3	CROSS-FLOW FAN COMPLETE	1	CWH02C1076	←	
	4	BEARING ASSY	1	CWH64K007	←	
	5	SCREW - CROSS-FLOW FAN	1	CWH551146	←	
	7	EVAPORATOR	1	CWB30C4829	CWB30C4830	
	8	FLARE NUT (LIQUID)	1	CWT251030	←	
	9	FLARE NUT (GAS)	1	CWT251031	←	
	10	CLIP FOR SENSOR	1	CWH32143	←	
	11	CONTROL BOARD CASING	1	CWH102449	←	
<u> </u>	12	TERMINAL BOARD COMPLETE	1	CWA28C2364	←	0
\triangle	13	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8118	CWA73C8119	0
\triangle	15	ELECTRONIC CONTROLLER - INDICATOR	1	CWA746716	←	0
	16	SENSOR COMPLETE	1	CWA50C2122	←	0
	23	CONTROL BOARD TOP COVER	1	CWH131467	←	
	24	INDICATOR HOLDER	1	CWD933406	←	
	25	CONTROL BOARD FRONT COVER CO.	1	CWH13C1247	←	
	26	DISCHARGE GRILLE COMPLETE	1	CWE20C3236	←	
	27	BACK COVER CHASSIS	1	CWD933233	←	
	28	FULCRUM	1	CWH621131	←	
	29	VERTICAL VANE	8	CWE241374	←	
	30	CONNECTING BAR	2	CWE261251	←	
\triangle	33	AIR SWING MOTOR	1	CWA981264	←	0
	34	CAP - DRAIN TRAY	1	CWH521259	←	
	35	HORIZONTAL VANE COMPLETE	1	CWE24C1385	←	
	36	REMOTE CONTROL COMPLETE	1	CWA75C4453	CWA75C4455	0
	37	FRONT GRILLE COMPLETE	1	CWE11C5835	←	0
	38	INTAKE GRILLE COMPLETE	1	CWE22C1861	←	
	39	GRILLE DOOR COMPLETE	1	CWE14C1090	←	
	40	AIR FILTER	2	CWD001279	←	0
	41	SCREW - FRONT GRILLE	2	XTT4+16CFJ	←	
	42	CAP - FRONT GRILLE	2	CWH521227	←	
	43	DRAIN HOSE	1	CWH851173	←	
	44	INSTALLATION PLATE	1	CWH361134	←	
	45	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	←	
	46	OPERATING INSTRUCTION	1	CWF569459	←	
	47	INSTALLATION INSTRUCTION	1	CWF616271	←	
	48	INSTALLATION INSTRUCTION	1	CWF616272	←	
	50	BAG	1	CWG861497	←	
	51	SHOCK ABSORBER (L)	1	CWG713386	←	
	52	SHOCK ABSORBER (R)	1	CWG713387	←	
	53	C.C.CASE	1	CWG567354	←	
	54	INSTALLATION INSTRUCTION	1	CWF616273	←	
	55	INSTALLATION INSTRUCTION	1	CWF616274	←	
	56	INSTALLATION INSTRUCTION	1	CWF616275	←	
	57	INSTALLATION INSTRUCTION	1	CWF616276	←	
	58	INSTALLATION INSTRUCTION	1	CWF616277	←	
	59	INSTALLATION INSTRUCTION	1	CWF616278	←	
	60	INSTALLATION INSTRUCTION	1	CWF616279	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-YE9QKE	CS-YE12QKE	REMARK
	61	INSTALLATION INSTRUCTION	1	CWF616280	←	
	62	OPERATING INSTRUCTION	1	CWF569460	←	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.


SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-UE9QKE	CS-UE12QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD50C1653	←	
<u> </u>	2	FAN MOTOR	1	L6CBYYYL0037	←	0
	3	CROSS-FLOW FAN COMPLETE	1	CWH02C1076	←	
	4	BEARING ASSY	1	CWH64K007	←	
	5	SCREW - CROSS-FLOW FAN	1	CWH551146	←	
	7	EVAPORATOR	1	CWB30C4829	CWB30C4830	
	8	FLARE NUT (LIQUID)	1	CWT251030	←	
	9	FLARE NUT (GAS)	1	CWT251031	←	
	10	CLIP FOR SENSOR	1	CWH32143	←	
	11	CONTROL BOARD CASING	1	CWH102449	←	
<u> </u>	12	TERMINAL BOARD COMPLETE	1	CWA28C2364	←	0
\triangle	13	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8118	CWA73C8119	0
\triangle	15	ELECTRONIC CONTROLLER - INDICATOR	1	CWA746716	←	0
	16	SENSOR COMPLETE	1	CWA50C2122	←	0
	23	CONTROL BOARD TOP COVER	1	CWH131467	←	
	24	INDICATOR HOLDER	1	CWD933406	←	
	25	CONTROL BOARD FRONT COVER CO.	1	CWH13C1247	←	
	26	DISCHARGE GRILLE COMPLETE	1	CWE20C3236	←	
	27	BACK COVER CHASSIS	1	CWD933233	←	
	28	FULCRUM	1	CWH621131	←	
	29	VERTICAL VANE	8	CWE241374	←	
	30	CONNECTING BAR	2	CWE261251	←	
\triangle	33	AIR SWING MOTOR	1	CWA981264	←	0
	34	CAP - DRAIN TRAY	1	CWH521259	←	
	35	HORIZONTAL VANE COMPLETE	1	CWE24C1385	←	
	36	REMOTE CONTROL COMPLETE	1	CWA75C4455	←	0
	37	FRONT GRILLE COMPLETE	1	CWE11C5836	←	0
	38	INTAKE GRILLE COMPLETE	1	CWE22C1861	←	
	39	GRILLE DOOR COMPLETE	1	CWE14C1090	←	
	40	AIR FILTER	2	CWD001279	←	0
	41	SCREW - FRONT GRILLE	2	XTT4+16CFJ	←	
	42	CAP - FRONT GRILLE	2	CWH521227	←	
	43	DRAIN HOSE	1	CWH851173	←	
	44	INSTALLATION PLATE	1	CWH361134	←	
	45	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	←	
	46	OPERATING INSTRUCTION	1	CWF569459	←	
	47	INSTALLATION INSTRUCTION	1	CWF616271	←	
	48	INSTALLATION INSTRUCTION	1	CWF616272	←	
	49	ANTI-BACTERIAL FILTER	1	CWD00C1280	←	0
	50	BAG	1	CWG861497	←	
	51	SHOCK ABSORBER (L)	1	CWG713386	←	
	52	SHOCK ABSORBER (R)	1	CWG713387	←	
	53	C.C.CASE	1	CWG567354	←	
	54	INSTALLATION INSTRUCTION	1	CWF616273	←	
	55	INSTALLATION INSTRUCTION	1	CWF616274	←	
	56	INSTALLATION INSTRUCTION	1	CWF616275	←	
	57	INSTALLATION INSTRUCTION	1	CWF616276	←	
	58	INSTALLATION INSTRUCTION	1	CWF616277	←	
	59	INSTALLATION INSTRUCTION	1	CWF616278	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-UE9QKE	CS-UE12QKE	REMARK
	60	INSTALLATION INSTRUCTION	1	CWF616279	←	
	61	INSTALLATION INSTRUCTION	1	CWF616280	←	
	62	OPERATING INSTRUCTION	1	CWF569460	←	

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.1.2 CS-UE18QKE



SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-UE18QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD50C1654	
\triangle	2	FAN MOTOR	1	ARW7627AC	0
	3	CROSS-FLOW FAN COMPLETE	1	CWH02C1077	
	4	BEARING ASSY	1	CWH64K1010	
	5	SCREW - CROSS-FLOW FAN	1	CWH551146	
	7	EVAPORATOR	1	CWB30C3860	
	8	FLARE NUT (LIQUID)	1	CWT251030	
	9	FLARE NUT (GAS)	1	CWT251032	
	10	CLIP FOR SENSOR	2	CWH32143	
	11	CONTROL BOARD CASING	1	CWH102449	
\triangle	12	TERMINAL BOARD COMPLETE	1	CWA28C2365	0
\triangle	13	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8120	0
$\overline{\mathbb{A}}$	15	ELECTRONIC CONTROLLER - INDICATOR	1	CWA746716	0
	16	SENSOR COMPLETE	1	CWA50C2122	0
	23	CONTROL BOARD TOP COVER	1	CWH131467	
	24	INDICATOR HOLDER	1	CWD933406	
	24a	INDICATOR HOLDER	1	CWD933496	
	25	CONTROL BOARD FRONT COVER CO.	1	CWH13C1247	
	26	DISCHARGE GRILLE COMPLETE	1	CWE20C3242	
	27	BACK COVER CHASSIS	1	CWD933031	
	28	FULCRUM	2	CWH621138	
	29	VERTICAL VANE	11	CWE241374	
	30	CONNECTING BAR	1	CWE261257	
	31	CONNECTING BAR	1	CWE261258	
\triangle	32	AIR SWING MOTOR	1	CWA98K1018	0
$\overline{\mathbb{A}}$	33	AIR SWING MOTOR	1	CWA981241	0
	34	CAP - DRAIN TRAY	1	CWH521259	
	35	HORIZONTAL VANE COMPLETE	1	CWE24C1392	
	36	REMOTE CONTROL COMPLETE	1	CWA75C4297	0
	37	FRONT GRILLE COMPLETE	1	CWE11C5837	0
	38	INTAKE GRILLE COMPLETE	1	CWE22C1888	
	39	GRILLE DOOR COMPLETE	1	CWE14C1090	
	40	AIR FILTER	2	CWD001283	0
	41	SCREW - FRONT GRILLE	3	XTT4+16CFJ	
	42	CAP - FRONT GRILLE	3	CWH521227	
	43	DRAIN HOSE	1	CWH851173	
	44	INSTALLATION PLATE	1	CWH361098	
	45	BAG COMPLETE - INSTALLATION SCREW	1	CWH82C1705	
	46	OPERATING INSTRUCTION	1	CWF569461	
	47	OPERATING INSTRUCTION	1	CWF569462	
	48	INSTALLATION INSTRUCTION	1	CWF616271	
	49	INSTALLATION INSTRUCTION	1	CWF616272	
	50	BAG	1	CWG861498	
	51	SHOCK ABSORBER (L)	1	CWG713402	
	52	SHOCK ABSORBER (R)	1	CWG713403	
	53	C.C.CASE	1	CWG567454	
	54	INSTALLATION INSTRUCTION	1	CWF616273	
	55	INSTALLATION INSTRUCTION	1	CWF616274	
1	56	INSTALLATION INSTRUCTION	1	CWF616275	
	57	INSTALLATION INSTRUCTION	1	CWF616276	


SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CS-UE18QKE	REMARK
	58	INSTALLATION INSTRUCTION	1	CWF616277	
	59	INSTALLATION INSTRUCTION	1	CWF616278	
	60	INSTALLATION INSTRUCTION	1	CWF616279	
	61	INSTALLATION INSTRUCTION	1	CWF616280	
	62	ANTI-BACTERIAL FILTER	1	CWD00C1280	0

(NOTE)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.2 Outdoor Unit

19.2.1 CU-YE9QKE CU-YE12QKE CU-UE9QKE CU-UE12QKE



Note

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-YE9QKE	CU-YE12QKE	REMARK
	1	CHASSIS ASSY	1	CWD50K2073	←	
	2	SOUND PROOF MATERIAL	1	CWG302314	←	
	3	FAN MOTOR BRACKET	1	CWD541089	←	
	4	SCREW - FAN MOTOR BRACKET	2	CWH551217	←	
<u> </u>	5	FAN MOTOR	1	ARS6411AC	←	0
· · · · · · · · · · · · · · · · · · ·	6	SCREW - FAN MOTOR MOUNT	4	CWH55252J	←	
	7	PROPELLER FAN ASSY	1	CWH03K1010	←	
	8	NUT - PROPELLER FAN	1	CWH56053J	←	
<u>^</u>	9	COMPRESSOR	1	5RS092XCD21	5RS102XBC21	0
	10	ANTI - VIBRATION BUSHING	3	CWH50077	←	
	11	NUT - COMPRESSOR MOUNT	3	CWH561096	←	
	12	CONDENSER	1	CWB32C4027	CWB32C3797	
	13	EXPANSION VALVE	1	CWB051055	←	0
	14	DISCHARGE MUFFLER (4-WAY VALVE)	1	CWB121010	←	0
	15	HOLDER COUPLING	1	CWH351233	←	
	16	2-WAYS VALVE (LIQUID)	1	CWB021180J	CWB021589	0
	17	3-WAY VALVE (GAS)	1	CWB011374	←	0
<u>^</u>	19	REACTOR	1	G0C103J00013	←	0
	20	TERMINAL COVER	1	CWH171039A	←	
	21	NUT - TERMINAL COVER	1	CWH7080300J	←	
	22	SOUND PROOF BOARD	1	CWH151172	←	
	23A	SOUND PROOF MATERIAL	1	CWG302315	←	
	23B	SOUND PROOF MATERIAL	1	CWG302316	←	
	23C	SOUND PROOF MATERIAL	1	CWG302317	←	
	24	SENSOR CO - COMP TEMP	1	CWA50C2205	←	0
	25	CONTROL BOARD COVER - TOP	1	CWH131264	←	
\triangle	26	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8416R	CWA73C8417R	0
$\frac{\square}{\mathbb{A}}$	27	TERMINAL BOARD ASSY	1	CWA28K1036J	←	0
	28	CABINET SIDE PLATE CO. (RIGHT)	1	CWE04C1512	←	
	29	SENSOR CO-AIR TEMP AND PIPE TEMP	1	CWA50C2764	←	0
	30	CABINET SIDE PLATE	1	CWE041031A	←	
	31	CABINET FRONT PLATE CO.	1	CWE06C1039	CWE06C1136	
	32	CABINET TOP PLATE	1	CWE031014A	←	
	33	PLATE - C. B. COVER TERMINAL	1	CWH131301	←	
	34	CONTROL BOARD COVER CO.	1	CWH13C1211	←	
	35	HANDLE	1	CWE161010	←	
	38	4-WAYS VALVE	1	CWB001063	←	0
\triangle	39	V-COIL COMPLETE (4-WAY VALVE)	1	CWA43C2431	←	0
$\frac{\sim}{\wedge}$	41	V-COIL COMPLETE (EXP.VALVE)	1	CWA43C2257	←	0
<u>~</u>	42	FLEXIBLE PIPE (L-TUBE)	1	CWH5850080	· ←	
	43	PACKING - L.TUBE	1	CWB81012	· ←	
	50	ACCESSORY CO. (DRAIN ELBOW)	1	CWG87C900	←	
	51	BAG	1	CWG861078	←	
	52	BASE BOARD - COMPLETE	1	CWG62C1095	←	
	53	SHOCK ABSORBER (RIGHT)	1	CWG712969	←	1

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-YE9QKE	CU-YE12QKE	REMARK
	54	SHOCK ABSORBER (LEFT)	1	CWG712970	←	
	55	C.C.CASE	1	CWG568356	←	

(Note)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.


SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-UE9QKE	CU-UE12QKE	REMARK
	1	CHASSIS ASSY	1	CWD50K2073	←	
	2	SOUND PROOF MATERIAL	1	CWG302314	←	
	3	FAN MOTOR BRACKET	1	CWD541089	←	
	4	SCREW - FAN MOTOR BRACKET	2	CWH551217	←	
<u> </u>	5	FAN MOTOR	1	ARS6411AC	←	0
	6	SCREW - FAN MOTOR MOUNT	4	CWH55252J	←	
	7	PROPELLER FAN ASSY	1	CWH03K1010	←	
	8	NUT - PROPELLER FAN	1	CWH56053J	←	
<u> </u>	9	COMPRESSOR	1	5RS092XCD21	5RS102XBC21	0
	10	ANTI - VIBRATION BUSHING	3	CWH50077	←	
	11	NUT - COMPRESSOR MOUNT	3	CWH561096	←	
	12	CONDENSER	1	CWB32C4027	CWB32C3797	
	13	EXPANSION VALVE	1	CWB051055	←	0
	14	DISCHARGE MUFFLER (4-WAY VALVE)	1	CWB121010	←	0
	15	HOLDER COUPLING	1	CWH351233	←	
	16	2-WAYS VALVE (LIQUID)	1	CWB021180J	CWB021589	0
	17	3-WAY VALVE (GAS)	1	CWB011374	←	0
<u> </u>	19	REACTOR	1	G0C103J00013	←	0
	20	TERMINAL COVER	1	CWH171039A	←	
	21	NUT - TERMINAL COVER	1	CWH7080300J	←	
	22	SOUND PROOF BOARD	1	CWH151172	←	
	23A	SOUND PROOF MATERIAL	1	CWG302315	←	
	23B	SOUND PROOF MATERIAL	1	CWG302316	←	
	23C	SOUND PROOF MATERIAL	1	CWG302317	←	
	24	SENSOR CO - COMP TEMP	1	CWA50C2205	←	0
	25	CONTROL BOARD COVER - TOP	1	CWH131264	←	
<u> </u>	26	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8416R	CWA73C8417R	0
\triangle	27	TERMINAL BOARD ASSY	1	CWA28K1036J	←	0
	28	CABINET SIDE PLATE CO. (RIGHT)	1	CWE04C1512	←	
	29	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C2764	←	0
	30	CABINET SIDE PLATE	1	CWE041031A	←	
	31	CABINET FRONT PLATE CO.	1	CWE06C1039	CWE06C1136	
	32	CABINET TOP PLATE	1	CWE031014A	←	
	33	PLATE - C. B. COVER TERMINAL	1	CWH131301	←	
	34	CONTROL BOARD COVER CO.	1	CWH13C1211	←	
	35	HANDLE	1	CWE161010	←	
	38	4-WAYS VALVE	1	CWB001063	←	0
<u> </u>	39	V-COIL COMPLETE (4-WAY VALVE)	1	CWA43C2431	←	0
$\stackrel{\sim}{\mathbb{A}}$	41	V-COIL COMPLETE (EXP.VALVE)	1	CWA43C2257	←	0
<u></u>	42	FLEXIBLE PIPE (L-TUBE)	1	CWH5850080	←	
	43	PACKING - L.TUBE	1	CWB81012	←	
	50	ACCESSORY CO. (DRAIN ELBOW)	1	CWG87C900	←	
	51	BAG	1	CWG861078	←	
	52	BASE BOARD - COMPLETE	1	CWG62C1095	←	
	53	SHOCK ABSORBER (RIGHT)	1	CWG712969	←	

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-YE9QKE	CU-YE12QKE	REMARK
	54	SHOCK ABSORBER (LEFT)	1	CWG712970	←	
	55	C.C.CASE	1	CWG568356	←	

(Note)

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.2.2 CU-UE18QKE



Note

SAFETY	REF. NO.	PART NAME & DESCRIPTION	QTY.	CU-UE18QKE	REMARK
	1	CHASSIS COMPLETE	1	CWD52K1277	
	2	SOUND PROOF MATERIAL	1	CWG302742	
	3	FAN MOTOR BRACKET	1	CWD541167	
	4	SCREW - FAN MOTOR BRACKET	2	CWH551217	
<u> </u>	5	FAN MOTOR	1	ARS6411AC	0
	6	SCREW - FAN MOTOR MOUNT	4	CWH55252J	
	7	PROPELLER FAN ASSY	1	CWH03K1066	
	8	NUT - PROPELLER FAN	1	CWH56053J	
<u> </u>	9	COMPRESSOR	1	5RD132XBE21	0
	10	ANTI - VIBRATION BUSHING	3	CWH50077	
	11	NUT - COMPRESSOR MOUNT	3	CWH56000J	
	12	CONDENSER	1	CWB32C3547	
	13	EXPANSION VALVE	1	CWB051055	0
	14	DISCHARGE MUFFLER	1	CWB121010	0
	15	HOLDER COUPLING	1	CWH351233	
	16	2-WAYS VALVE (LIQUID)	1	CWB021589	0
	17	3-WAY VALVE (GAS)	1	CWB011806	0
<u> </u>	19	REACTOR	1	G0C193J00016	0
	20	TERMINAL COVER	1	CWH171039A	
	21	NUT - TERMINAL COVER	1	CWH7080300J	
	22	SOUND PROOF BOARD	1	CWH151273	
	23A	SOUND PROOF MATERIAL	1	CWG302745	
	23B	SOUND PROOF MATERIAL	1	CWG302741	
	23C	SOUND PROOF MATERIAL	1	CWG302740	
	24	SENSOR - COMPLETE COMP. TEMP	1	CWA50C2894	0
	25	CONTROL BOARD COVER - TOP	1	CWH131473	
<u> </u>	26	ELECTRONIC CONTROLLER - MAIN	1	CWA73C8121R	0
$\overline{\mathbb{A}}$	27	TERMINAL BOARD ASSY	1	CWA28K1036J	
	28	CABINET SIDE PLATE CO. (RIGHT)	1	CWE04C1481	
	29	SENSOR CO - AIR TEMP AND PIPE TEMP	1	CWA50C2893	0
	30	CABINET SIDE PLATE	1	CWE041616A	
	31	CABINET FRONT PLATE CO.	1	CWE06C1441	
	32	CABINET TOP PLATE	1	CWE031148A	
	33	CONTROL BOARD COVER	1	CWH131470A	
	34	CONTROL BOARD COVER - COMPLETE	1	CWH13C1253	
	38	4-WAYS VALVE	1	CWB001063	0
\triangle	39	V-COIL COMPLETE - 4-WAY VALVE	1	CWA43C2431	0
\triangle	41	V-COIL COMPLETE - EXP.VALVE	1	CWA43C2257	0
	42	ACCUMULATOR	1	CWB131065	
	43	STRAINER	1	CWB11094	
	45	BAG - COMPLETE	1	CWG87C900	
	46	BAG	1	CWG861078	
	47	BASE BOARD - COMPLETE	1	CWG62C1162	
	48	SHOCK ABSORBER (RIGHT)	1	CWG713415	
	49	SHOCK ABSORBER (LEFT)	1	CWG713416	
	50	C.C.CASE	1	CWG568358	
			1		1

- (NOTE)
 All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
 "O" marked parts are recommended to be kept in stock.