
# Service Manual

Caller ID Compatible







KX-TG6411BXS/BXT (Base Unit)



(Charger Unit)

## Configuration for each model

Model No	Base Unit	Handset	Charger Unit
KX-TG6411	1 (TG6411)	1 (TGA641)	
KX-TG6412	1 (TG6411)	2 (TGA641)	1
KX-TG6413	1 (TG6411)	3 (TGA641)	2

Model No. KX-TG6411BXS
KX-TG6411BXT
KX-TG6412BXS
KX-TG6412BXT
KX-TG6413BXS
KX-TG6413BXS
KX-TG6413BXS

**KX-TGA641BXT** 

**Telephone Equipment** 

Digital Cordless Phone

S:Silver Version T:Titanium Black Version (for Asia, Middle Near East and other areas)

# **MARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

## IMPORTANT SAFETY NOTICE -

There are special components used in this equipment which are important for safety. These parts are marked by  $\triangle$  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

## · IMPORTANT INFORMATION ABOUT LEAD FREE, (PbF), SOLDERING

If lead free solder was used in the manufacture of this product, the printed circuit boards will be marked PbF. Standard leaded, (Pb), solder can be used as usual on boards without the PbF mark. When this mark does appear, please read and follow the special instructions described in this manual on the use of PbF and how it might be permissible to use Pb solder during service and repair work.

- When you note the serial number, write down all 11 digits. The serial number may be found on the bottom of the unit.
- The illustrations in this Service Manual may vary sllightly from the actual product.

# **TABLE OF CONTENTS**

		PAGE
1	Safety Precautions	4
	1.1. For Service Technicians	4
2	Warning	
	2.1. Battery Caution	
	2.2. About Lead Free Solder (Pbf: Pb free)	
	2.3. Discarding of P.C. Board	
3	Specifications	6
4	Technical Descriptions	
	4.1. Block Diagram (Base Unit)	7
	4.2. Circuit Operation (Base Unit)	
	4.3. Block Diagram (Handset)	11
	4.4. Circuit Operation (Handset)	
	4.5. Circuit Operation (Charger Unit)	13
	4.6. Signal Route	14
5	Location of Controls and Components	15
	Installation Instructions	
7	Operating Instructions	
	7.1. For Service Hint	
8	Service Mode	
	8.1. Engineering Mode	
	8.2. Copying Phonebook Items when Repairing	
	8.3. How to Clear User Setting	22
9	Troubleshooting Guide	23
	9.1. Troubleshooting Flowchart	
	9.2. Troubleshooting by Symptom (Base Unit and	d 
	Charger Unit)	
	9.3. Troubleshooting by Symptom (Handset)	
10	Disassembly and Assembly Instructions	43
	10.1. Disassembly Instructions	
	10.2. How to Replace the Handset LCD	
11	Measurements and Adjustments	4/
	11.1. Equipment Required	
	11.2. The Setting Method of JIG (Base Unit)	
	11.3. Adjustment Standard (Base Unit)	
	11.4. Adjustment Standard (Charger Unit) 11.5. The Setting Method of JIG (Handset)	
	11.6. Adjustment Standard (Handset)	
	11.7. Things to Do after Replacing IC or X'tal	
	11.8. RF Specification	
	11.9. How to Check the Handset Speaker o	
	Receiver	
	11.10. Frequency Table (MHz)	
12	Miscellaneous	
	12.1. How to Replace the Flat Package IC	
	12.2. How to Replace the Shield Case	
	12.3. Terminal Guide of the ICs, Transistors and	
	Diodes	
13	Schematic Diagram	
	13.1. For Schematic Diagram	
	13.2. Schematic Diagram (Base Unit)	
	13.3. Schematic Diagram (Handset)	
	13.4. Schematic Diagram (Charger Unit)	
14	Printed Circuit Board	
-	14.1. Circuit Board (Base Unit_Main)	
	14.2. Circuit Board (Handset)	71
	14.3. Circuit Board (Charger Unit)	
15	Exploded View and Replacement Parts List	
	15.1 Cabinet and Electrical Parts (Rase Unit)	

	PAGE
15.2. Cabinet and Electrical Parts (Handset)	75
15.3. Cabinet and Electrical Parts (Charger Unit)-	76
15.4. Accessories and Packing Materials	77
15.5 Replacement Part List	8C

# 1 Safety Precautions

## 1.1. For Service Technicians

- Repair service shall be provided in accordance with repair technology information such as service manual so as to prevent fires, injury or electric shock, which can be caused by improper repair work.
  - 1. When repair services are provided, neither the products nor their parts or members shall be remodeled.
  - 2. If a lead wire assembly is supplied as a repair part, the lead wire assembly shall be replaced.
  - 3. FASTON terminals shall be plugged straight in and unplugged straight out.
- · ICs and LSIs are vulnerable to static electricity.

When repairing, the following precautions will help prevent recurring malfunctions.

- 1. Cover plastic parts boxes with aluminum foil.
- 2. Ground the soldering irons.
- 3. Use a conductive mat on worktable.
- 4. Do not grasp IC or LSI pins with bare fingers.

# 2 Warning

## 2.1. Battery Caution

- 1. Danger of explosion if battery is incorrectly replaced.
- 2. Replace only with the same or equivalent type recommended by the manufacturer.
- 3. Dispose of used batteries according to the manufacture's Instructions.

## 2.2. About Lead Free Solder (Pbf: Pb free)

#### Note:


In the information below, Pb, the symbol for lead in the periodic table of elements, will refer to standard solder or solder that contains lead

We will use PbF solder when discussing the lead free solder used in our manufacturing process which is made from Tin (Sn), Silver (Ag), and Copper (Cu).

This model, and others like it, manufactured using lead free solder will have PbF stamped on the PCB. For service and repair work we suggest using the same type of solder.


#### Caution

- PbF solder has a melting point that is 50 °F ~ 70 °F (30 °C ~ 40 °C) higher than Pb solder. Please use a soldering iron with temperature control and adjust it to 700 °F ± 20 °F (370 °C ± 10 °C).
- · Exercise care while using higher temperature soldering irons.:
- Do not heat the PCB for too long time in order to prevent solder splash or damage to the PCB.
- PbF solder will tend to splash if it is heated much higher than its melting point, approximately 1100 °F (600 °C).
- When applying PbF solder to double layered boards, please check the component side for excess which may flow onto the opposite side (See the figure below).



## 2.2.1. Suggested PbF Solder

There are several types of PbF solder available commercially. While this product is manufactured using Tin, Silver, and Copper (Sn+Ag+Cu), you can also use Tin and Copper (Sn+Cu) or Tin, Zinc, and Bismuth (Sn+Zn+Bi). Please check the manufacturer's specific instructions for the melting points of their products and any precautions for using their product with other materials. The following lead free (PbF) solder wire sizes are recommended for service of this product: 0.3 mm, 0.6 mm and 1.0 mm.



## 2.3. Discarding of P.C. Board

When discarding P. C. Board, delete all personal information such as telephone directory and caller list or scrap P. C. Board.

# 3 Specifications

■ Standard:

**DECT (Digital Enhanced Cordless** 

Telecommunications),

GAP (Generic Access Profile)

■ Number of channels:

120 Duplex Channels

■ Frequency range: 1.88 GHz to 1.90 GHz

■ Duplex procedure:

TDMA (Time Division Multiple Access)

**■** Channel spacing:

1,728 kHz

■ Bit rate:

1,152 kbit/s

■ Modulation:

GFSK (Gaussian Frequency Shift Keying)

■ RF transmission power:

Approx. 10 mW (average power per channel)

■ Voice coding: ADPCM 32 kbit/s ■ Power source (AC Adaptor):

220-240V AC, 50/60 Hz Base unit: PQLV219BXZ Charger: PQLV219BXZ

■ Power consumption

Base unit:

Standby: Approx. 0.7 W Maximum: Approx. 3.8 W

Charger:

Standby: Approx. 0.2 W Maximum: Approx. 3.2 W ■ Operating conditions:

0 °C-40 °C, 20 %-80 % relative air humidity (dry)

**■** Dimensions:

Base unit: Approx. 55 mm x 126 mm x 126 mm Handset: Approx. 158 mm x 48 mm x 30 mm Charger: Approx. 52 mm x 75 mm x 88 mm

■ Mass (weight):

Base unit: Approx. 140 g Handset: Approx. 130 g Charger: Approx. 60 g

## Note:


• Design and specifications are subject to change without notice.

#### Note for Service:

- Operation range: Up to 300 m outdoors, Up to 50 m indoors, depending on the condition.
- Analog telephone connection: Telephone Line

# 4 Technical Descriptions

# 4.1. Block Diagram (Base Unit)



KX-TG6411/6412/6413 BLOCK DIAGRAM (BASE UNIT)

## 4.2. Circuit Operation (Base Unit)

## 4.2.1. **Outline**

Base Unit consists of the following ICs as shown in **Block Diagram (Base Unit)** (P.7).

- DECT BBIC (Base Band IC): IC7
  - Handling all the audio, signal and data processing needed in a DECT base unit
  - Controlling the DECT specific physical layer and radio section (Burst Module Controller section)
  - ADPCM code filter for speech encoding and speech decoding (DSP section)
  - Echo-cancellation and Echo-suppression (DSP section)
  - Any tones (tone, sidetone, ringing tone, etc.) generation (DSP section)
  - DTMF receiver (DSP section)
  - Clock Generation for RF Module
  - ADC, DAC, timer, and power control circuitry
  - PLL Oscillator
  - Detector
  - Compress/Expander
  - First Mixer
  - All interfaces (ex: RF Power Amp, EEPROM, LED, Analog Front End, etc.)
- RF Power Amp.: IC801
  - Amplifier for transmission and reception
- EEPROM: IC401
  - Temporary operating parameters (for RF, etc.)
- · Additionally,
  - Power Supply Circuit (+3.0 V, +2.4 V, +1.8 V output)
  - Crystal Circuit (10.368 MHz)
  - Charge Circuit
  - Telephone Line Interface Circuit

## 4.2.2. Power Supply Circuit

The power is supplied to the DECT BBIC, RF Module, EEPROM and Charge Contact from AC Adaptor (+6.5 V) as shown in Fig.101. The power supply is as follows;

• DECT BBIC (IC7):

DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  IC1  $\rightarrow$  IC7

DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  IC1 $\rightarrow$  Q9 $\rightarrow$  IC7

DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  IC1  $\rightarrow$  Q8  $\rightarrow$  IC7

• RF Power Amp. (IC801):


DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  IC1  $\rightarrow$  IC801 (Power AMP)

• EEPROM (IC401):

DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  IC1  $\rightarrow$  IC7 $\rightarrow$  IC401

• Charge Contact (TP16):

DC Jack (+6.5 V)  $\rightarrow$ D1 $\rightarrow$  R56  $\rightarrow$  R55  $\rightarrow$  D22 $\rightarrow$  TP16



## 4.2.3. Telephone Line Interface

#### <Function>

- · Bell signal detection
- · Clip signal detection
- ON/OFF hook circuit

### Bell & Clip (: Calling Line Identification Presentation: Caller ID) signal detection:

In the standby mode, Q3 is open to cut the DC loop current and decrease the ring load.

When ring voltage appears at the L1T (A) and L1R (B) leads (when the telephone rings), the AC ring voltage is transferred as follows;

- B  $\rightarrow$  L2  $\rightarrow$  C4  $\rightarrow$  R6  $\rightarrow$  R33  $\rightarrow$  IC7 Pin 21 (CID INp)
- A  $\rightarrow$  L1  $\rightarrow$  C3  $\rightarrow$  R4  $\rightarrow$  R35  $\rightarrow$  IC7 Pin 20 (CID INn)

#### **ON/OFF** hook circuit:

In the standby mode, Q3 is open, and connected as to cut the DC loop current and to cut the voice signal. The unit is consequently in an **on-hook condition**.

When IC7 detects a ring signal or press the TALK Key onto the handset, Q4 turns on and then Q3 turns on, thus providing an **off-hook condition** (DC current flows through the circuit) and the following signal flow makes the loop current.

• B  $\rightarrow$  L2  $\rightarrow$ D3  $\rightarrow$  Q3  $\rightarrow$  Q5  $\rightarrow$  R21  $\rightarrow$  R22  $\rightarrow$  D3  $\rightarrow$  L1  $\rightarrow$ A [OFF HOOK]

## 4.2.4. Transmitter/Receiver

· Audio Circuits and DTMF tone signal circuits.

Base Unit and Handset mainly consist of RF Module and DECT BBIC.

Base Unit and Handset transmit/receive voice signal and data signal through the antenna on carrier frequency.

## Signal Path:

\*Refer to Signal Route (P.14).

## 4.2.4.1. Transmitter Block

The voice signal input from the TEL LINE interface goes to RF Power Amp. (IC801) through DECT BBIC (IC7) as shown in **Block Diagram (Base Unit)** (P.7)

The voice signal passes through the analog part of IC7 where it is amplified and converted to a digital audio stream signal. The burst switch controller processes this stream performing encryption and scrambling, adding the various other fields to produce the GAP (Generic Access Profile) standard DECT frame, assigning to a time slot and channel etc.

In IC7, the carrier frequency is changing, and frequency modulated RF signal is generated. In IC801, RF signal is amplified, and radiated from antenna. Handset detects the voice signal or data signal in the circuit same as the following explanation of Receiver Block.

## 4.2.4.2. Receiver Block


The signal of 1900 MHz band (1881.792 MHz ~ 1897.344 MHz) which is input from antenna is input to IC7 as shown in **Block Diagram (Base Unit)** (P.7).

In IC7, the signal of 1900 MHz band is downconverted to 864 kHz signal and demodulated, as GAP (**G**eneric **A**ccess **P**rofile) standard DECT frames. It passes through the decoding section burst switch controller where it separates out the frame information and performs de-encryption and de-scrambling as required. It then goes to the DSP section where it is turned back into analog audio. This is amplified by the analog front end, and goes to the TEL LINE Interface.

#### 4.2.5. Pulse Dialling

During pulse dialing the hookswitch (Q3, Q4) is used to generate the pulses using the HOOK control signal, which is set high during pulses. To force the line impedance low during the "pause" intervals between dial pulses, the PULSE\_DIAL signal turns on Q2.

# 4.3. Block Diagram (Handset)



## 4.4. Circuit Operation (Handset)

#### 4.4.1. Outline

Handset consists of the following ICs as shown in Block Diagram (Handset) (P.11).

- DECT BBIC (Base Band IC): IC1
  - All data signals (forming/analyzing ACK or CMD signal)
  - All interfaces (ex: Key, Detector Circuit, Charge, DC/DC Converter, EEPROM, LCD, RF Power Amp.)
  - PLL Oscillator
  - Detector
  - Compress/Expander
  - Reception
- RF Power Amp: IC801
  - Amplifier for transmission
- EEPROM: IC3
  - Temporary operating parameters (for RF, etc.)


## 4.4.2. Power Supply Circuit/Reset Circuit

## **Circuit Operation:**

When power on the Handset, the voltage is as follows;

BATTERY(2.2 V ~ 2.6 V: BATT+)  $\rightarrow$  F1  $\rightarrow$  Q2 (1.8 V), IC1-43pin (2.5V)

The Reset signal generates IC1 (61 pin) and 1.8 V.



## 4.4.3. Charge Circuit

#### **Circuit Operation:**

When charging the handset on the Base Unit, the charge current is as follows;

 $DC+(6.5 \text{ V}) \rightarrow D1 \rightarrow R56 \rightarrow R55 \rightarrow D22 \rightarrow CHARGE+(Base) \rightarrow CHARGE+(Handset) \rightarrow Q4 \rightarrow D7 \rightarrow F1 \rightarrow BATTERY+... \text{ Battery...}$ 

 $\mathsf{BATTERY} \to \mathsf{R45} \to \mathsf{GND} \to \mathsf{CHARGE}\text{-}(\mathsf{Handset}) \to \mathsf{CHARGE}\text{-}(\mathsf{Base}) \to \mathsf{GND} \to \mathsf{DC}\text{-}(\mathsf{GND})$ 

In this way, the BBIC on Handset detects the fact that the battery is charged.

The charge current is controlled by switching Q9 of Handset.

Refer to Fig.101 in Power Supply Circuit (P.9).

## 4.4.4. Battery Low/Power Down Detector

#### **Circuit Operation:**

"Battery Low" and "Power Down" are detected by BBIC which check the voltage from battery.

The detected voltage is as follows;

· Battery Low

Battery voltage: V(Batt) ≤ 2.25 V ± 50 mV

The BBIC detects this level and " starts flashing.

Power Down

Battery voltage: V(Batt) ≤ 2.0 V ± 50 mV

The BBIC detects this level and power down.


## 4.4.5. Speakerphone

The hands-free loudspeaker at SP+ and SP- is used to generate the ring alarm.

# 4.5. Circuit Operation (Charger Unit)

# 4.5.1. Power Supply Circuit

The power supply is as shown.



AC Adaptor

## 4.6. Signal Route

```
SIGNAL
                                               ROUTE
SIGNAL ROUTE I
                   IN -
                                                                                OUT
DTMF TONE
                (BASE UNIT)
                IC7 (16) - R116 - R29 - C22 - Q5 - Q3 - D3 _ L1 - A
TEL OUT
(to Tel Line)
                (BASE UNIT)
DTMF TONE
                A - L1 __ D3 - Q3 - Q5 - R20 - C56 - R117 - IC7 (18)
TEL IN
(from Tel Line)
CDL TX
               (HANDSET)
               MIC (+) - R73 - C11 - RA4 - IC1 (20) IC1(77) - IC801 (4) IC801(9) - L802 - C812 -
(to Tel Line)
               DA801 - C803 - C859 - ANT to BASE
               (BASE UNIT)
               from HANDSET ANT1 - C851 - DA802 - C859 - C803 - DA801 - C826
                                                                           -IC7 (3)
                              ANT2 - C853 -
                                                                           IC7 (2)
                  - IC7 (16) - R116 - R29 - C22 - Q5 - Q3 - D3 — L1 - A
             ∸ (BASE UNIT)
CDL RX
             IC801 (9) -
(from Tel Line)
               L802 - C812 - DA801 - C803- C859 - DA802 -
                                                       - C851 - ANT1
                                                      C853 - ANT1 to HANDSET
             (HANDSET)
             <sup>1</sup> from BASE UNIT ANT - C859 - C803 - DA801 - C826 -
               T IC (16) - L9 - RECEIVER (+) IC (15) - RECEIVER (-)

→ (BASE UNIT)

Caller ID
             (from Tel Line)
               DA801 - C803 - C859 - DA802 — C851 - ANT1 to HANDSET

── (HANDSET)
SP-PHONE TX
               MIC (+) - R73 - C11 - RA4 - IC1 (20) IC1(77) - IC801 (4) IC1(78) - IC801 (9) - L802 - C812 -
(to Tel Line)
               DA801 - C803 - C859 - ANT to BASE
             (BASE UNIT)
               from HANDSET ANT1 - C851 __ DA802 - C859 - C803 - DA801 -C826 - ANT2 - C853 __
                                                                          - IC7 (3)
                                                                           IC7 (2)
               TIC7 (16) - R116 - R29 - C22 - Q5 - Q3 - D3 TL1 - A
                                                   L2 - B
SP-PHONE RX
             十 (BASE UNIT)
               (to Tel Line)
                                                        C851 - ANT1
               L802 - C812 - DA801 - C803 - C859 - DA802 -
                                                       C853 - ANT2 to HANDSET
               (HANDSET)
               from BASE UNIT ANT - C859 - C803 - DA801 - C826 — IC1 (3) IC1 (2)
                  - IC1 (33) - R209 - SP (-)
               IC1 (35) - R208 - SP (+)
```

# 5 Location of Controls and Components

Refer to the Operating Instructions.

#### Note:

You can download and refer to the Operating Instructions (Instruction book) on TSN Server.

## 6 Installation Instructions

Refer to the Operating Instructions.

#### Note:

You can download and refer to the Operating Instructions (Instruction book) on TSN Server.

# 7 Operating Instructions

Refer to the Operating Instructions.

#### Note:

You can download and refer to the Operating Instructions (Instruction book) on TSN Server.

## 7.1. For Service Hint

Items	Contents			
Battery	You could use other rechargeable batteries sold in a market, but the unit is not guaranteed to work properly.			
	The battery strength may not be indicated correctly if the battery is disconnected and connected again, even after it is fully charged. In that case, by recharging the battery as mentioned in <b>Battery Charge</b> , you will get a correct indication of the battery strength.			
PIN Code	<ul> <li>Change the PIN using the following method.</li> <li>1</li></ul>			


## 8 Service Mode

## 8.1. Engineering Mode

## 8.1.1. Base Unit

## Important:

Make sure the address on LCD is correct when entering new data. Otherwise, you may ruin the unit.




## H/S key operation

- 1). Register a Handset to a Base Unit.
- 2). Press ( ).
- 3). Select "Base Unit Setup" using [▲]or[▼] then press [■].
- 4). Enter "7", "2", "6", "2", "7", "6", "6", "4".

  Note: 7262 7664 = PANA SONI

  (see letters printed on dial keys)
- 5). Select "Write EEPROM" using [▲]or[▼] then press [■].
- 6). Enter "●", "●", "●", "●" (Address). (\*1)
- 7). Enter "\*", "\*" (New Data). (\*1)
- 8). Press [], a long confirmation beep will be heard.



# Frequently Used Items (Base Unit) ex.)

Items	Address	Default Data	New	Data	Remarks
C-ID (FSK) sensitivity	04 B6	00	01 (6 dB up)	02 (12 dB up)	When hex changes from "00" to "01" or "02", gain increases by 6 dB or 12 dB.
C-ID (DTMF) sensitivity	04 C4	50	60 (6 dB up)	70 (12 dB up)	When hex changes from "50" to "60" or "70", gain increases by 6 dB or 12 dB.
Frequency	00 02/00 01	02/70	-	-	Use these items in a READ-ONLY mode to
ID	00 10~00 14	Given value	-	-	confirm the contents. Careless rewriting may cause serious damage to the computer system.
Bell length	01 F7	32 (5 sec) (*2)	1E (3 sec)	14 (2 sec)	This is time until bell stops ringing. (Unit: 100 ms)
PULSE Dial speed (10PPS -> 20PPS)	03 9F	28 (40 msec) (*3)	19 (20 msec)	-	This is pulse make time. (Unit: 1 ms)
	03 A0	3C (60 msec) (*3)	19 (30 msec)	-	This is pulse break time. (Unit: 1 ms)
	01 E4	57 (870 msec) (*3)	2C (440 msec)	-	This is inter-digit time in pulse mode. (Unit: 10 ms)

## Note:

(\*1) When you enter the address or New Data, please refer to the table below.

Desired Number (hex)	Input Keys	Desired Number (hex)	Input Keys
0	0	A	[R] + 0
1	1	В	[R] + 1
		С	[R] + 2
		D	[R] + 3
		E	[R] + 4
9	9	F	[R] + 5


(\*2)

Bell length	$32(\text{hex}) = 50(\text{dec}) \rightarrow 50 \times 100 \text{ msec} = 5000 \text{ msec} (5 \text{ sec})$
PULSE Dial speed	28 (hex) = 40 (dec) → 40 × 1 msec = 40 msec → 28 (40 msec)
(10PPS -> 20PPS)	$3C \text{ (hex)} = 60 \text{ (dec)} \rightarrow 60 \times 1 \text{ msec} = 60 \text{ msec} \rightarrow 3C \text{ (60 msec)}$
	57 (hex) = 87 (dec) → 87 × 10 msec = 870 msec

## 8.1.2. Handset

## Important:

Make sure the address on LCD is correct when entering new data. Otherwise, you may ruin the unit.




## H/S key operation

- 1). Press [3].
- 2). Select "Handset Setup" using [▲] or [▼] then press [■].
- 3). Enter "7", "2", "6", "2", "7", "6", "6", "4".

  Note: 7262 7664 = PANA SONI

  (see letters printed on dial keys)
- 4). Select "Write EEPROM" using [▲] or [▼] then press [■].
- 5). Enter "●", "●", "●", "●" (Address). (\*1)
- 6). Enter "\*", "\*" (New Data). (\*1)
- 7). Press [], a long confirmation beep will be heard.
- 8). Press [🔨 🔾] (off) to return to standby mode.

  After that, remove and reinsert the batteries. Press the Power button for about 1 second if the power is not turned on.



## Frequently Used Items (Handset)

ex.

Items	Address	Default Data	New Data	Possible Adjusted Value MAX (hex)	Possible Adjusted Value MIN (hex)	Remarks
Sending level	00 06	Adjusted value	Given value	6F	00	(*2)
Receiving level	00 07	Adjusted value	Given value	00	3F	(*3)
Battery Low	00 04	70	-	-	-	
Frequency	00 02/00 01	02/70	-	-	-	(*4)
ID	00 10~00 14	Given value	-	-	-	

#### Note:

(\*1) When you enter the address or New Data, please refer to the table below.

Desired Number (hex.)	Input Keys	Desired Number (hex.)	Input Keys
0	0	A	[R] + 0
1	1	В	[R] + 1
		С	[R] + 2
		D	[R] + 3
		E	[R] + 4
9	9	F	[R] + 5

(\*2) When adding "01" (hex) to default value, sending level increases by 0.25 dB. ex.)

Item	Default Data	New Data	
	35	39 31	
Sending level	-8.5dBm	-7.5dBm	-9.5dBm

(\*3) When reducing "01" (hex) from default value, receiving level increases by 0.25 dB. ex.)

Item	Default Data	New Data	
	18	1C	14
Receiving level	-21dBm	-22dBm	-20dBm


(\*4) Use these items in a READ-ONLY mode to confirm the contents. Careless rewriting may cause serious damage to the handset.

## 8.2. Copying Phonebook Items when Repairing


You can copy the handset phonebook to another (compatible Panasonic) handset. This will help to save the original phonebook data which the customer has registered.

Available models: KX-TG6411/KX-TG6412/KX-TG6413

Refer to the following procedures.




Case 1: A base unit has a defect.
(Replacing a base unit PCB etc...)



 Register HS (A) to BS (B).
 HS (A) is normal, therefore no need to copy the phonebook data.

Case 2: A base unit has a defect.
(Replacing both a base unit and a handset)




- 1. Register HS (A) to BS (B) as a handset no. 2.
- 2. Copy the phonebook data from HS (A) to HS (B).
- 3. Cancel the HS 2 (HS (A)).

#### Note:


- BS=Base Unit , HS=Handset
- If the max number of handsets are already registered to the base unit, a new handset cannot be registered.

Case 3: A handset has a defect.
(Radio transmission is functioning.)



- 1. Cancel HS (A).
- 2. Register HS (B) as a handset no. 1.
- 3. Register HS (A) as a handset no. 2.
- 4. Copy the phonebook data from HS (A) to HS (B).
- 5. Cancel HS 2 (HS (A)).

Case 4: A handset has a defect.
(Radio transmission is functioning.)



- 1. Register HS (A) as a handset no. 2.
- 2. Copy the phonebook data from HS (A) to HS (B).
- 3. Cancel HS 2 (HS (A)).

## Note:

- · BS=Base Unit , HS=Handset
- If the max number of handsets are already registered to the base unit, a new handset cannot be registered.

## 8.3. How to Clear User Setting


Units are reset to the Factory settings by this operation (stored Phone numbers, Caller list and etc.)

#### Note:

- The reset menus differ depending on the following operations.
- This operation should not be performed for a usual repair.

## 8.3.1. Resetting both base unit and handset

Both the base unit and the registered handset which you did the following steps ① to ④ are reset. Other registered handsets will not be reset.




- (1) Connect the AC adaptor to the base unit and install the charged batteries into the handset.
- ② Confirm the handset is registered to the base unit ( \mathbb{Y} lights).

  If the handset is not registered to the base unit ( \mathbb{Y} is flashing), register it.
- 3 Lift the handset and press [ > 0] to put the handset in standby mode.
- 4 Press 1, 5, 9 and  $\times$  key of the handset simultaneously until a confirmation tone is heard.
- 5 Disconnect the AC adaptor, then remove the battery.

## 8.3.2. Resetting only handset

The only handset is reset by doing the following steps ① to ④.



- (1) Install the charged batteries into the handset.
- (2) Lift the handset and press [ > 0] to put the handset in standby mode.
- (3) Press (3), (5), (7) and (#) key of the handset simultaneously until a confirmation tone is heard. (\*1)
- 4 Remove the battery.


## Note: (\*1)

- The handset registration to the base unit is cancelled.
- If users do not bring the base unit with them, the registration procedure has to be done by users themselves.

# 9 Troubleshooting Guide

## 9.1. Troubleshooting Flowchart

## **Flow Chart**



## **Cross Reference:**

Check Power (P.24)

**Bell Reception** (P.34)

**Check Battery Charge (P.25)** 

Check Link (P.26)

Check the RF part (P.30)

**Check Handset Transmission (P.33)** 

**Check Handset Reception (P.33)** 


Signal Route (P.14)

Check Caller ID (P.33)


## 9.1.1. Check Power

#### 9.1.1.1. Base Unit

Is the AC Adaptor inserted into AC outlet? (\*1)



## 9.1.1.2. Handset




supply voltage of AC Adaptor.

**Cross Reference:** 

Power Supply Circuit/Reset Circuit (P.12)

## 9.1.2. Check Battery Charge


## 9.1.2.1. Base Unit



#### **Cross Reference:**

Charge Circuit (P.12)

## 9.1.2.2. Handset




#### **Cross Reference:**

Check Power (P.24)

Charge Circuit (P.12)

## 9.1.2.3. Charger Unit




## **Cross Reference:**

Charge Circuit (P.12)

## 9.1.3. Check Link

## 9.1.3.1. Base Unit




#### Note:

(\*1) Refer to Troubleshooting by Symptom (Base Unit and Charger Unit) (P.35)

### **Cross Reference:**

Check Point (Base Unit) (P.35)


**Power Supply Circuit (P.9)** 



## **Cross Reference:**

Check Point (Base Unit) (P.35)

## 9.1.3.2. Handset




## Note:

(\*1) Refer to Troubleshooting by Symptom (Handset) (P.39)

## **Cross Reference:**

Check Point (Handset) (P.39)

**Power Supply Circuit/Reset Circuit (P.12)** 



## **Cross Reference:**

Check Point (Handset) (P.39)


## 9.1.4. Check the RF part

## 9.1.4.1. Finding out the Defective part

- 1. Prepare Regular HS (Handset) and Regular BU (Base unit).
- 2. a. Re-register regular HS (Normal mode) to Base Unit (to be checked). If this operation fails in some ways, the Base Unit is defective.
  - b. Re-register Handset (to be checked) to regular BU (Normal mode). If this operation fails in some ways, the Handset is defective.


## After All the Checkings or Repairing

1. Re-register the checked Handset to the checked Base Unit, and Regular HS to Regular BU.



## 9.1.4.2. RF Check Flowchart

Each item (1  $\sim$  3) of RF Check Flowchart corresponds to **Check Table for RF part** (P.32). Please refer to the each item.



## Note:

(\*1) Base unit - refer to (G) of **Check Point (Base Unit)** (P.35) Handset - refer to (H) of **Check Point (Handset)** (P.39)


## 9.1.4.3. Check Table for RF part

No.	Item	BU (Base Unit) Check	HS (Handset) Check
1	Link Confirmation Normal	<ol> <li>Register Regular HS to BU (to be checked).</li> </ol>	Register HS (to be checked) to Regular BU.
	HS, BU Mode: [Normal mode]	<ol><li>Press [Talk] key of the Regular HS to establish link.</li></ol>	Press [Talk] key of the HS to establish link.
2	X'tal Frequency confirmation	1. Check X'tal Frequency. (*1) (10.368 MHz ± 100 Hz)	1. Check X'tal Frequency. (*2) (10.368 MHz ±100Hz)
3	Range Confirmation Normal	Register Regular HS to BU (to be checked).	Register HS (to be checked) to Regular BU.
	HS, BU Mode: [Normal mode]	<ol> <li>Press [Talk] key of the Regular HS to establish link.</li> <li>Compare the range of the BU (being checked) with that of the Regular BU.</li> </ol>	Press [Talk] key of the HS to establish link.     Compare the range of the HS (being checked) with that of the Regular HS.

## Note:

- (\*1) Refer to Adjustment Standard (Base Unit) (P.49)
- (\*2) Refer to Adjustment Standard (Handset) (P.53)


## 9.1.5. Check Handset Transmission



#### **Cross Reference:**

Signal Route (P.14)

## 9.1.6. Check Handset Reception



Check CDL RX (HANDSET) in Signal Route.

#### **Cross Reference:**

How to Check the Handset Speaker or Receiver (P.57) Signal Route (P.14)

## 9.1.7. Check Caller ID


Check Caller ID in Signal Route.

## **Cross Reference:**


Signal Route (P.14)

## 9.1.8. Bell Reception

## 9.1.8.1. Base Unit



## 9.1.8.2. Handset



## **Cross Reference:**

Telephone Line Interface (P.10)

Check Link (P.26)

How to Check the Handset Speaker or Receiver (P.57)

## 9.2. Troubleshooting by Symptom (Base Unit and Charger Unit)

If your unit has below symptoms, follow the instructions in remedy column. Remedies depend on whether you have DECT tester (\*1) or not.

	Remedy (*2)		
Symptom	You don't have DECT Tester.	You have DECT Tester. (Model Number : CMD60)	
You cannot dial.	Check item (A)-(H),(T).	Check item (A)-(I), (J)-(P),(T).	
You cannot hear the caller's voice.	Check item (A)-(G),(T).	Check item (A)-(G), (J)-(P), (Q),(T).	
You cannot use handset a little away from base unit even if the handset is within range of the base unit.	-	Check item (I)-(O).	
The acoustic transmit level is high or low.	Check item (P).	Check item (P).	
The acoustic reception level is high or low.	Check item (P).	Check item (P).	
Base unit and handset do not link each other.	Check item (A)-(H).	Check item (A)-(O).	
The unit cannot charge.	Check item (Q).	Check item (Q).	

#### Note:

- (\*1) A general repair is possible even if you don't have the DECT tester because it is for confirming the levels, such as Acoustic level in detail.
- (\*2) Refer to Check Point (Base Unit) (P.35)

## 9.2.1. Check Point (Base Unit)

Please follow the items below when BBIC or EEPROM or FLASH is replaced.

## Note:

After the measuring, suck up the solder of TP.

\*: Connections (P.47) is required beforehand.

The connections of simulator equipments are as shown in Adjustment Standard (Base Unit) (P.49).

	Items	Check Point	Procedure	Check or Replace Parts
( <b>A</b> )	3.0 V Supply Confirmation	VDD3	1. Confirm that the voltage between test point VDD3 and GND is 3.0 V $\pm$ 0.2 V.	IC1, C31, C32, R38, R39, C36, F1, C37, D1
( <b>B</b> )	1.8 V Supply Confirmation	VDD1	<ol> <li>Confirm that the voltage between test point VDD1 and GND is 1.8 V ± 0.02 V.</li> <li>Execute the command "VDD", then check the current value.</li> <li>Adjust the 1.8V voltage of VDD1 executing command "VDD XX"(XX is the value).</li> </ol>	Q8, C75, C614, C61, IC7
	Charge Pump 2.5V Supply Confirma- tion	VDD5	Confirm that the voltage between test point VDD5 and GND is 2.5 V -0.1/+0.3 V.	IC7,C625,C631
	Charge Pump 3.0V Supply Confirma- tion	VDD4	1. Confirm that the voltage between test point VDD4 and GND is 3.0 V $\pm$ 0.2 V.	IC7,C616,C630
(E)*	BBIC Confirmation	-	BBIC Confirmation (Execute the command "getchk").     Confirm the returned checksum value. Connection of checksum value and program number is shown below.      checksum value program number     ex.) 7723 DBB1EN	IC7, X1, R77, RA80
( <b>F</b> )*	EEPROM Confirmation	-	EEP-ROM Confirmation (Execute the command "sendchar EPV").     Confirm the returned Value(Value for reference is written at "EEPROM C/SUM" in Software_Version_Table.xls).	IC7, RA402, C51, R657, IC401
( <b>G</b> )*	BBIC Clock Adjustment	CLK	<ol> <li>Input Command "sendchar WWD ff 48 IC 8006"</li> <li>Confirm that the voltage between testpoint VDD4 and GND is less than 1.0 V.</li> <li>Input Command "sendchar sfr", then you can confirm the current value.</li> <li>Check X'tal Frequency. (10.368 MHz ± 100 Hz).</li> <li>If the frequency is not 10.368MHz ± 100Hz, adjust the frequency of CLK executing the command "sendchar sfr xx xx (where xx is the value)" so that the reading of the frequency counter is 10.368000 MHz ± 5 Hz.</li> </ol>	X1, IC7, R430, C305

## KX-TG6411BXS/KX-TG6411BXT/KX-TG6412BXS/KX-TG6412BXT/KX-TG6413BXS/KX-TG6413BXT/KX-TGA641BXS/KX-TGA641BXT

Items	
(I)* Hookswitch Check with DC Characteristics  1. Connect Telephone Socket to Tel-simulator which is connected with 600 2. Set line votales to 48 V and line current to 40mA at off-hook condition of mal telephone.  3. Execute the command "hookoff"  4. Confirm that the line current is 40 mA ± 5 mA.  5. Execute the command "hookon".  6. Confirm that the line current is less than + 0.8 mA.  1. Connect Telephone Socket to DTMF tester. (Load=600 Ω)  2. Link Handset and push dial key.  3. Confirm DTMF character.  4. Confirm that the line Group is -4.0 dBm ~ -8.0 dBm.  5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.  8. Remove the Antenna before starting step from 1 to 7.  1. Configure the DECT tester (CMD60) as follows;  Setting?  1. Traffic Stot: 4  1. Mode: Loopback  1. PMID: 00000  1. RF LEVEL = -70 dBm.  2. Execute the command "sendchar TST".  3. Execute the command "sendchar dmv 2 2".  4. Check that "Signalling Status" has been set to "Locked", then press "AC REP".  5. Initiate connection from Dect tester ("set up connect")  6. Execute the command "ANT1".  7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated with ≥ 690 kHz using data type Figa1.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "writmod xx", where xx is the value.)	Check or Replace Parts
2. Set line voltage to 48 V and line current to 40mA at off-hook condition of mal telephone. 3. Execute the command "hookoff" 4. Confirm that the line current is 40 mA ± 5 mA. 5. Execute the command "hookon". 6. Confirm that the line current is less than + 0.8 mA. 1. Connect Telephone Socket to DTMF tester. (Load=600 Ω) 2. Link Handset and push dial key. 3. Confirm that the low Group is -4.0 dBm ~ -8.0 dBm. 5. Confirm that the low Group is -4.0 dBm ~ -10.0 dBm. 8. Confirm that the low Group is -4.0 dBm ~ -10.0 dBm. 8. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm. 9. Transmitted Power Confirmation 1. Configure the DECT tester (CMD60) as follows; 4. Setting 1. Transmitted Power Confirmation Exercise the command "sendchar TST". 3. Execute the command "sendchar TST". 3. Execute the command "sendchar TST". 3. Execute the command "sendchar dmv 2 2". 4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI". 5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm. 1. Follow steps 1 to 6 of (J). 7. Confirm that the P-Field Modulation is -370 ± 30 / +370 ± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31. 8. Adjust the B-Field Modulation is -370 ± 30 / +370 ± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31. 8. Adjust the B-Field Modulation is -400 ± 200	· ·
mal telephone 3. Execute the command "hookoff" 4. Confirm that the line current is 40 mA ± 5 mA. 5. Execute the command "hookoff" 6. Confirm that the line current is less than + 0.8 mA.  1. Connect Telephone Socket to DTMF tester. (Load=600 Ω) 2. Link Handset and push dial key. 3. Confirm DTMF character. 4. Confirm DTMF character. 4. Confirm that the lw Group is -4.0 dBm ~ -8.0 dBm. 5. Confirm that the DW Group is -9.0 dBm. 6. Confirm that the DECT tester (CMD60) as follows; 4. Setting? 1. Transmitted Power Confirmation  ANTI_TP  ANTI_TP  ANTI_TP  ANTI_TC arrier: 5 1. Traffic Carrier: 5 1. Traffic Carrier: 5 1. Traffic Carrier: 5 1. Traffic Carrier: 5 1. Execute the command "sendchar TST". 3. Execute the command "sendchar dmv 2.2". 4. Check that "Signalling Status" has been set to "Locked", then press "AC RFP". 5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm.  (K)* Modulation Check and Adjustment  ANTI_TP  ANTI_TP  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  Follow of (J).	
3. Execute the command "hookoff"   4. Confirm that the line current is 40 mA ± 5 mA.	R17, D3,
4. Confirm that the line current is 40 mA ± 5 mA. 5. Execute the command "hookon".   6. Confirm that the line current is less than + 0.8 mA.   7. Confirm that the line current is less than + 0.8 mA.   8. Execute the command "hookon".   9. Confirm that the line current is less than + 0.8 mA.   1. Connect Telephone Socket to DTMF tester. (Load=600 Ω)   2. Link Handset and push dial key.   3. Confirm DTMF character.   4. Confirm that the high Group is -4.0 dBm ~ -8.0 dBm.   5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.   6. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.   7. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.   8. Remove the Antenna before starting step from 1 to 7.   1. Configure the DECT tester (CMD60) as follows;   Setting     1. Transmitted Power Confirm that Dect tester (CMD60) as follows;   1. Configure the DECT tester (CMD60) as follows;   1. Configure the DECT tester (CMD60) as follows;   2. Execute the Command "sendchar TST".   3. Execute the command "sendchar drm 2 2".   4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".   5. Initiate connection from Dect tester ("set up connect")   6. Execute the command "ANT1".   7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.   7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & 1 lated width ≥ 690 kHz using data type Fig31.   8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)   1. Confirm that the S-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)	R18~R24,
5. Execute the command 'hookon'.	C15~C17, D21,
6. Confirm that the line current is less than + 0.8 mA.     1. Connect Telephone Socket to DTMF tester. (Load=600 Ω)     2. Link Handset and push dial key.     3. Confirm DTMF character.     4. Confirm that the high Group is -4.0 dBm ~ -8.0 dBm.     5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.     6. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.     7. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.     8. ANTI_TP	Q5, R27, IC7
Connect Telephone Socket to DTMF tester. (Load=600 Ω)   Confirm ThMF character.	Q0,1121,101
2. Link Handset and push dial key. 3. Confirm DTMF character. 4. Confirm that the high Group is -4.0 dBm ~ -8.0 dBm. 5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm. 8. Remove the Antenna before starting step from 1 to 7. 1. Configure the DECT tester (CMD60) as follows; < Setting> • Test mode: FP • Traffic Carrier: 5 • Traffic Slot: 4 • Mode: Loopback • PMID: 00000 • RF LEVEL = -70 dBm. 2. Execute the command "sendchar TST". 3. Execute the command "sendchar dmv 2 2". 4. Check that "Signalling Status" has been set to "Locked", then press "AC RFP!". 5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  [K)* Modulation Check and Adjustment    ANTI_TP	IC7, R116,
3. Confirm DTMF character. 4. Confirm that the high Group is -4.0 dBm ~ -8.0 dBm. 5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.  Remove the Antenna before starting step from 1 to 7.  1. Configure the DECT tester (CMD60) as follows;  Setting>	C141, R29, C22,
4. Confirm that the high Group is -4.0 dBm ~ -8.0 dBm. 5. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm. 1. Configure the DECT tester (CMD60) as follows;  Setting>  Test mode: FP  Traffic Carrier: 5  Traffic Slot: 4  Mode: Loopback  PMID: 00000  RF LEVEL = -70 dBm.  2. Execute the command "sendchar dmv 2 2".  4. Check that "Signalling Status" has been set to "Locked", then press "ACRFP".  5. Initiate connection from Dect tester ("set up connect")  Execute the command "ANT1".  7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  Follow steps 1 to 6 of (J).  (K)* Modulation Check and Adjustment  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  (L)* Frequency Offset Check  Follow steps 1 to 6 of (J).	C23, Q5, D21
S. Confirm that the low Group is -6.0 dBm ~ -10.0 dBm.   (J)*   Transmitted Power Confirmation	
Transmitted Power Confirmation	
firmation  ANTI_TP  1. Configure the DECT tester (CMD60) as follows; <pre></pre>	IC7,
<ul> <li>Setting&gt;         <ul> <li>Test mode: FP</li> <li>Traffic Carrier: 5</li> <li>Traffic Carrier: 5</li> <li>Traffic Slot: 4</li> <li>Mode: Loopback</li> <li>PMID: 00000</li> <li>RF LEVEL = -70 dBm.</li> </ul> </li> <li>2. Execute the command "sendchar TST".         <ul> <li>3. Execute the command "sendchar dmv 2 2".</li> <li>4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".</li> <li>5. Initiate connection from Dect tester ("set up connect")</li> <li>6. Execute the command "ANT1".</li> <li>7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.</li> </ul> </li> <li>[K)* Modulation Check and Adjustment</li> <li>ANTI_TP</li> <li>Follow steps 1 to 6 of (J).</li> <li>7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div &amp; I lated width § 690 kHz using data type Fig31.</li> <li>8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)</li> </ul> <li>[L)* Frequency Offset Check</li> <li>Follow steps 1 to 6 of (J).</li>	C802~C806,
Traffic Carrier: 5     Traffic Slot: 4     Mode: Loopback     PMID: 00000     RF LEVEL = -70 dBm.     Execute the command "sendchar TST".     Secute the command "sendchar dmv 2 2".     4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".     5. Initiate connection from Dect tester ("set up connect")     6. Execute the command "ANT1".     7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.   (K)* Modulation Check and Adjustment  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  7.Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31. 8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  Follow steps 1 to 6 of (J).	C808~C814,
Traffic Carrier: 5     Traffic Slot: 4     Mode: Loopback     PMID: 00000     RF LEVEL = -70 dBm.     Execute the command "sendchar TST".     Secute the command "sendchar dmv 2 2".     4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".     5. Initiate connection from Dect tester ("set up connect")     6. Execute the command "ANT1".     7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.   (K)* Modulation Check and Adjustment  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  7.Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31. 8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  Follow steps 1 to 6 of (J).	C820, C819,
Mode: Loopback   PMID: 00000     RF LEVEL = -70 dBm.     Execute the command "sendchar TST".     3. Execute the command "sendchar dmv 2 2".     4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".     5. Initiate connection from Dect tester ("set up connect")     6. Execute the command "ANT1".     7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.     (K)*   Modulation Check and Adjustment   ANTI_TP     ANTI_TP     Follow steps 1 to 6 of (J).     7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.     8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)     (L)*   Frequency Offset Check   - Follow steps 1 to 6 of (J).	C822, C823,
PMID: 00000 • RF LEVEL = -70 dBm. 2. Execute the command "sendchar TST". 3. Execute the command "sendchar dmv 2 2". 4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI". 5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  Follow steps 1 to 6 of (J). 7.Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≧ 690 kHz using data type Fig31. 8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	C825, C827,
RF LEVEL = -70 dBm.     Execute the command "sendchar TST".     S. Execute the command "sendchar dmv 2 2".     4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".     5. Initiate connection from Dect tester ("set up connect")     6. Execute the command "ANT1".     7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.   (K)* Modulation Check and Adjustment  - ANTI_TP  ANTI_TP  ANTI_TP  ANTI_TP  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  8. Adjust the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)	C826, C834,
2. Execute the command "sendchar TST".  3. Execute the command "sendchar dmv 2 2".  4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".  5. Initiate connection from Dect tester ("set up connect")  6. Execute the command "ANT1".  7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  [K)* Modulation Check and Adjustment  - ANTI_TP  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  - Follow steps 1 to 6 of (J).	C851, C853,
3. Execute the command "sendchar dmv 2 2". 4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI". 5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  (K)* Modulation Check and Adjustment  Follow steps 1 to 6 of (J). 7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31. 8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)	C859~C861,
4. Check that "Signalling Status" has been set to "Locked", then press "AC RFPI".  5. Initiate connection from Dect tester ("set up connect")  6. Execute the command "ANT1".  7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)	DA801, DA802,
RFPI".  5. Initiate connection from Dect tester ("set up connect")  6. Execute the command "ANT1".  7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	IC801,
5. Initiate connection from Dect tester ("set up connect") 6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  (K)* Modulation Check and Adjustment  - ANTI_TP  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J). 7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & follow steps 1 to 6 of (J). 8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  - Follow steps 1 to 6 of (J).	
6. Execute the command "ANT1". 7. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.    Modulation Check and Adjustment	C855~C858,
T. Confirm that the NTP value at ANT is 19.0 dBm ~ 25.0 dBm.  (K)* Modulation Check and Adjustment  ANTI_TP  ANTI_TP  Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  Follow steps 1 to 6 of (J).	R801~R807,
(K)* Modulation Check and Adjustment  - ANTI_TP  - Follow steps 1 to 6 of (J).  7. Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8. Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check  - Follow steps 1 to 6 of (J).	R106, R109,
Adjustment  ANTI_TP  7.Confirm that the B-Field Modulation is -370 ± 30/ +370± 30 kHz/div & I lated width ≥ 690 kHz using data type Fig31.  8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	Q9, C617
lated width ≥ 690 kHz using data type Fig31. 8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	IC7,
8.Adjust the B-Field Modulation if required. (Execute the command "read and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	· · · · · · · · · · · · · · · · · · ·
and "wrtmod xx", where xx is the value.)  (L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	C808~C814,
(L)* Frequency Offset Check - Follow steps 1 to 6 of (J).	
	C822, C823,
	C825, C827,
	C826, C834,
	C851, C853, C859~C861,
	DA801, DA802,
	IC801,
	L801~L803,
	C855~C858,
	R801~R807,
	R106, R109,
	Q9, C617
	IC7,
ANTE TELEFORM THE PRODUCTION OF THE STATE OF	C802~C806,
	C808~C814,
	C820, C819,
	C822, C823,
	C825, C827,
	C826, C834,
	C851, C853,
	C859~C861,
	DA801, DA802,
	IC801,
	L801~L803,
	C855~C858,
	R801~R807,
	R106, R109,
	Q9, C617

	Items	Check	Procedure	Check or
(5.5) di	5 15 0 5	Point		Replace Parts
( <b>M</b> )*	Frequency Drift Confir-	-	Follow steps 1 to 6 of (J).	IC7,
	mation	ANTI_TP	7.Confirm that the frequency drift is < ± 35 kHz/ms.	C802~C806,
				C808~C814,
				C820, C819, C822, C823,
				C825, C827,
				C826, C834,
				C851, C853,
				C859~C861,
				DA801, DA802,
				IC801,
				L801~L803,
				C855~C858,
				R801~R807,
				R106, R109,
<b>(\$1</b> ) #	0 ''' '' D '			Q9, C617
( <b>N</b> )*	Sensitivity Receiver	- ANTI TD	Follow steps 1 to 6 of (J).	IC7,
	Confirmation	ANTI_TP	7.Set DECT tester power to -90 dBm.	C802~C806, C808~C814,
			8.Confirm that the BER is < 1000 ppm.	C820, C819,
				C822, C823,
				C825, C827,
				C826, C834,
				C851, C853,
				C859~C861,
				DA801, DA802,
				IC801,
				L801~L803,
				C855~C858,
				R801~R807,
				R106, R109, Q9, C617
<b>(O</b> )*	Timing Confirmation	_	Follow steps 1 to 6 of (J).	IC7,
(0)	Tilling Committee	ANTI_TP	7.Confirm that the Timing accuracy is	C802~C806,
			• ± 5.0 ppm (When adjust the frequency of CLK in item (G)).	C808~C814,
			• ± 15 ppm (When do not adjust the frequency of CLK in item (A)).	C820, C819,
				C822, C823,
				C825, C827,
				C826, C834,
				C851, C853,
				C859~C861,
				DA801, DA802, IC801,
				L801~L803,
				C855~C858,
				R801~R807,
				R106, R109,
				Q9, C617
<b>(P</b> )*	Power RAMP Confirma-	-	Follow steps 1 to 6 of (J).	IC7,
	tion		7.Confirm that Power RAMP is matching.	C802~C806,
				C808~C814,
				C820, C819,
				C822, C823,
				C825, C827,
				C826, C834, C851, C853,
				C851, C853, C859~C861,
				DA801, DA802,
				IC801,
				L801~L803,
				C855~C858,
				R801~R807,
				R106, R109,
		<u></u>		Q9, C617

### KX-TG6411BXS/KX-TG6411BXT/KX-TG6412BXS/KX-TG6412BXT/KX-TG6413BXS/KX-TG6413BXT/KX-TGA641BXS/KX-TGA641BXT

	Items	Check	Procedure	Check or
		Point		Replace Parts
( <b>Q</b> )	Audio Check	-	1. Link with Handset.	IC7, SA1, L1,
			2. Input -45dBm/1kHz to MIC of Handset.	L2, D3, Q3, Q4,
			Measure the Level at Line I/F and distortion level.	R14, R15, R16,
			3. Confirm that the level is -8.5 dBm ± 2 dBm and that the distortion level is < 5%	R17, D21, Q5,
			at TEL Line (600 $\Omega$ Load).	R19, R20, C14,
			4. Input -20 dBm/1 kHz to Line I/F.	C56, R117,
			Measure the level at Receiver of Handset and distortion level	R116, C141, R9,
			(*Receive volume set to second position from minimum).	C22, C23
			5. Confirm that the level is -21.0 dBm ± 2 dBm and that the distortion level is <	
			5% at Receiver (Volume Middle, 150 $\Omega$ Load).	
( <b>R</b> )	Charging Check	-	<ol> <li>Connect Charge Contact 12 Ω/2 W resistor between charge+ and charge</li> </ol>	R55, R56, D22,
			<ol><li>Measure and confirm voltage across the resistor is 3.10 V ± 0.3 V.</li></ol>	D23
<b>(S)</b>	2.4V Supply Confirma-	VDD2	<ol> <li>Confirm that the voltage between test point VDD2 and GND is 2.5V ± 0.2V.</li> </ol>	IC7, Q9, C617
	tion VDD2			

# 9.2.2. Check Point (Charger Unit)

	Items	Check	Procedure	Check or
		Point		Replace Parts
(A)	Charging Check	-	<ol> <li>Connect Charge Contact 12Ω/2 W resistor between charge+ and charge</li> </ol>	R1, F1
			2. Measure and confirm voltage across the resistor is 3.1 V $\pm$ 0.3 V.	

### Note:

After the measuring, suck up the solder of TP.

The connection of adjustment equipment is as shown in Adjustment Standard (Charger Unit) (P.50).

## 9.3. Troubleshooting by Symptom (Handset)

If your unit has below symptoms, follow the instructions in remedy column. Remedies depend on whether you have DECT tester (\*1) or not.

	Remedy (*2)		
Symptom	You don't have DECT Tester.	You have DECT Tester. (Model Number : CMD60)	
Battery strength is not indicated correctly by Battery icon.	Check item (A)-(D), (E)-(G).	Check item (A)-(D), (E)-(G).	
You cannot hear the caller's voice.	Check item (A)-(C), (H).	Check item (A)-(C), (H)-(M), (O).	
You cannot use handset a little away from base unit even if the handset is within range of the base unit.	-	Check item (I)-(M).	
Does not link between base unit and handset.	Check item (A)-(C), (H).	Check item (A)-(C), (I)-(M).	
The Audio level is high or low.	Check item (O).	Check item (O).	
The SP-Phone level is high or low.	Check item (P).	Check item (P).	

#### Note:

(\*2) Refer to Check Point (Handset) (P.39)

### 9.3.1. Check Point (Handset)

Please follow the items below when BBIC or EEPROM is replaced.

#### Note:

After the measuring, suck up the solder of TP.

\*: Connections (P.51) is required beforehand.

The connections of adjustment equipments are as shown in Adjustment Standard (Handset) (P.53).

	Items	Check	Procedure	Check or
		Point		Replace Parts
( <b>A</b> )*	1.8 V Supply Adjustment	VDD1	1. Confirm that the voltage between test point VDD1 and GND is 1.8 V $\pm$ 0.02 V.	IC1, Q2, C48,
			Execute the command "VDD", then check the current value.	D1, C1, C44,
			3. Adjust the 1.8V voltage of VDD1 executing command "VDD XX"(XX is the	
			value).	C40, C45, F1
( <b>B</b> )*	BBIC Confirmation	-	BBIC Confirmation (Execute the command "getchk").	IC1, X1, RA61,
			Confirm the returned checksum value.	R64, R66
			Connection of checksum value and program number is shown below.	
			checksum value program number	
			ex.) 88AE DBF2BA	
(C)*	EEP-ROM Confirmation	-	EEP-ROM Confirmation (Execute the command "sendchar EPV").	IC1, IC3,
			2. Confirm the returned Value (Value for reference is written at "EEPROM C/	
			SUM" in Software_Version_Table.xls).	C172
( <b>D</b> )	0	-	1. Apply 3.5 V between CHG(+) and CHG(-) with DC power supply and set cur-	IC1, Q4 Q9,
	Charge Current Monitor		rent limit to 250 mA.	D7, R6, R7,
	Check		Confirm the indication of "charging" on LCD.	F1, C1, R2,
			Confirm that the current limit LED of DC power supply is ON/OFF.	R30, R31, R8,
			Confirm it after waiting over 1 minute at least.	R45
			3. Decrease current limit of DC power supply to 100 mA.	
			4. Confirm that the current limit LED of DC power supply is stable. (Current limiter	
			is ON.)	
			(If charge control cannot be confirmed by this procedure, please use battery to hand-	
/E\*	Charge Detection (OFF)		set power supply and try again.)	101 04 00
(E)*	Charge Detection (OFF) Check	-	Stop supplying 3.5 V to CHG (+) and CHG (-).     Confirm the indication of "charging" has been cleared.	IC1, Q4 Q9, D7, R6, R7,
	CHECK		2. Committing indication of charging has been dealed.	F1, C1, R2,
				R30, R31, R8,
				R30, R31, R6,
				K40

<sup>(\*1)</sup> A general repair is possible even if you don't have the DECT tester because it is for confirming the levels, such as Acoustic level in detail.

	Items	Check Point	Procedure	Check or Replace Parts
( <b>F</b> )*	Battery Monitor Check	-	1. Apply 2.25 V between BATT+ and BATT	iC1, F1, C1,
` '	,		2. Execute the command	R12, R45
			sendchar PAD	, , , , , , ,
			sendchar LED 0	
			sendchar CRX 0 1	
			sendchar AD1	
			It assumes that the return value is XX.	
			a) 6c ≤ XX ≤ 71: No need to adjust	
			b) XX: 6A ~ 6B: Need to adjust	
			XX: 72 ~ 74: Need to adjust	
			Write AD value of 2.25 V to EEPROM.	
			ex) read data: XX = 6A, write data: YY = 6A	
			read data: XX = 73, write data: YY = 73	
			EEPROM = 0004(Low Voltage) write "YY"	
			Execute the command "wreeprom 00 04 01 YY".	
			EEPROM = 0005(No Voltage) write "YY - 1D"	
			Execute the command "xwreeprom 00 05 01 ZZ".	
			EEPROM = 000A(Low Voltage BL) write "YY - 16"	
			Execute the command "wreeprom 00 0A 01 WW".	
			Note:	
			ZZ = YY - C	
			No Voltage writing data limit is '00'.	
			c) XX: 00 ~ 69: Reject	
			XX: 75 ~ FF: Reject	
( <b>G</b> )	Battery Low Confirma-	-	1. Apply 2.40 V between BATT+ and BATT	IC1, F1, C1,
	tion		2. Confirm that there is no flashing of Battery Icon.	R12, R45
			3. Apply 2.25 V ± 0.08 V between BATT+ and BATT	
/# #\ ±	BBIO OL I A II I	0117	4. Confirm that there is flashing of Battery Icon.	104 1/4 047
( <b>H</b> )*	BBIC Clock Adjustment	CLK	1. Apply 2.6 V between BATT+ and BATT- with DC power.	IC1, X1, C47
			2. Input Command "sendchar sfr", then you can confirm the current value.	
			3. Check X'tal Frequency. (10.368 MHz ± 100 Hz).	
			4. If the frequency is not 10.368 MHz ± 100 Hz, adjust the frequency of CLK execution the command "condehor of two years are the value" of the value.	
			cuting the command "sendchar sfr xx xx (where xx is the value)" so that the reading of the frequency counter is 10.368000 MHz ± 5 Hz.	
			Note:	
			Clear the registered information for Base Unit before measurement, because the	
			Frequency will not possibly get stable due to the registered information.	
			Pressing the button of "3" "7" "9" "#" clears the registration.	
			Register to it on Base Unit after measurement.	
(I)*	Transmitted Power Con-		Remove the Antenna before starting step from 1 to 4.	IC1,
(-)	firmation		Configure the DECT tester (CMD60) as follows;	C802~C806,
			<pre><setting></setting></pre>	C808~C814,
			Test mode: PP	C819~C820,
			• RFPI: 0102030405	C822,
			Traffic Carrier: 5	C825~C827,
			Traffic Slot: 4	C834,
			Mode: Loopback	C859~C864,
			• RF LEVEL = -70 dBm	L801~L804,
			• PACKET: PP32Z	DA801,
			2. Execute the command "sendchar TST 01 02 03 04 05".	R801~R808
			Initiate connection from DECT tester.	
			<ol><li>Confirm that the NTP value at ANT is 19 dBm ~ 25 dBm.</li></ol>	
( <b>J</b> )*	Modulation Check and	-	Follow steps 1 to 3 of (K).	IC1,
	Adjustment		4.Confirm that the B-Field Modulation is -370±30/ +370±30 kHz/div & Modulated	C802~C806,
			width ≥ 690 kHz using data type Fig 31.	C808~C814,
				C819~C820,
				C822,
				C825~C827,
				C834,
				C859~C864,
				L801~L804,
i l				DA801,
				R801~R808

### KX-TG6411BXS/KX-TG6411BXT/KX-TG6412BXS/KX-TG6412BXT/KX-TG6413BXS/KX-TG6413BXT/KX-TGA641BXS/KX-TGA641BXX

z.	IC1, C802~C806, C808~C814,
Z.	C802~C806, C808~C814,
	C808~C814,
	0040 0000
	C819~C820,
	C822,
	C825~C827,
	C834,
	C859~C864, L801~L804,
	DA801,
	R801~R808
	IC1,
ms.	C802~C806,
	C808~C814,
	C819~C820,
	C822,
	C825~C827,
	C834, C859~C864,
	L801~L804,
	DA801,
	R801~R808
	IC1,
	C802~C806,
	C808~C814,
	C819~C820,
	C822,
	C825~C827, C834,
	C859~C864,
	L801~L804,
	DA801,
	R801~R808
	IC1,
	C802~C806,
	C808~C814,
	C819~C820, C822,
	C825~C827,
	C834,
	C859~C864,
	L801~L804,
	DA801,
	R801~R808
ulator.	IC1, C12, D19,
mA.	D20, C96,
e output level. nd that the distortion level is < 5%	C97, R215, R27, RA4,
is that the distortion level is > 9/0	C11, C13,
re Receiving level at REV+ and	
<b>G</b>	MIC, L9, RA2,
d that the distortion level is < 5%	R73, R74
lator.	IC1, C12, C73,
mA.	D13, D14,
/. Pacaiving level at SD+ and SD-	R152, R73, R74, RA2,
Receiving level at SP+ and SP	
a that the dictoractification is < 070.	C13, RA4,
	R27, R28,
	R208, R209,
	C96, C97,
	R215, C72
CP3.0V and GND is 3.0V -0.1/	C52, C53, C49
24.0V and OND :- 4.0V .0.0V	050 051
P4.0V and GND is 4.0V -0.2V.	C50, C51
CF	

## 9.3.2. Troubleshooting for Speakerphone

When the customer's telephone line corresponds to the following conditions, and the transmission signal of SP-Phone is interrupted, performing the next set up to a cordless handset will improve it to some extent.

#### **Conditions**

- 1. When customer's line has less line loss.
  - ex.) The customer is using optical fiber, ISDN terminal adaptor, or PBX.
  - In this case, receiving signal is strong and it may affect transmission signal.
- 2. When the other party is talking from noisy place.
  - ex.) The other party is using cellular phone. The background noise is very loud.
  - In this case, the noise from the other party (i.e. surrounding noise) may affect transmission signal.


#### **Setting Method**

• Change the handset address of EEPROM (0129) from 00 to 01 by Engineering Mode.

# 10 Disassembly and Assembly Instructions


# 10.1. Disassembly Instructions

# 10.1.1. Base Unit




### 10.1.2. Handset


1 Remove the 2 screws.




② Insert a JIG (PQDJ10006Y) between the cabinet body and the cabinet cover, then pull it along the gap to open the cabinet.




(3) Likewise, open the other side of the cabinet.



4 Remove the cabinet cover by pushing it upward.



(5) Remove the tape and solders.



6 2 screws


(6) Remove the 2 screws to remove the 2 charge terminals.

(7) Remove the screw to remove the main P. C. board.

44


# 10.1.3. Charger Unit

(1) Remove the screw to remove the cabinet cover.




- (2) Remove the solders to remove the 2 charge terminals.
- (3) Remove the screw to remove the main P.C. board.

# How to Replace the Handset LCD





Peel off the FFC (Flexible Flat Cable) from the LCD, in the direction of the arrow. Take care to ensure that the foil on the P.C. board

is not damaged.




Fit the heatseal of a new LCD.






Heatweld with the tip of the soldering iron about 5 to 8 seconds (in case of 60W soldering iron).




Vertical Interval Tolerance

> NG (Inclined)



NG

(Vertical interval tolerance is more than 0.2 mm.)



NG

(Horizontal interval tolerance is more than 0.2 mm.)

# 11 Measurements and Adjustments

This chapter explains the measuring equipment, the JIG connection, and the PC setting method necessary for the measurement in **Troubleshooting Guide** (P.23)

## 11.1. Equipment Required

- Digital multi-meter (DMM): it must be able to measure voltage and current.
- · Oscilloscope.
- Frequency counter: It must be precise enough to measure intervals of 1 Hz (precision; ±4 ppm) Hewlett Packard, 53131A is recommended.
- DECT tester: Rohde & Schwarz, CMD 60 is recommended.
   This equipment may be useful in order to precisely adjust like a mass production.

## 11.2. The Setting Method of JIG (Base Unit)

This section explains the PC setting to use command required in Check Point (Base Unit)(P.35).

#### <Preparation>

- Serial JIG cable: PQZZ1CD300E\*
  PC which runs in DOS mode
- Batch file CD-ROM for setting: PNZZTG6411BX


#### Note:

\*: If you have the JIG Cable for TCD500 series (PQZZ1CD505E), change the following values of resistance. Then you can use it as a JIG Cable for both TCD300 and TCD500 series. (It is an upper compatible JIG Cable.)

Resistor	Old value (kΩ)	New value (kΩ)
R2	22	3.3
R3	22	3.3
R4	22	4.7
R7	4.7	10

#### 11.2.1. Connections

- ① Connect the AC adaptor to DC-JACK (base unit).
- ② Connect the JIG Cable GND (black) to GND.
- 3 Connect the JIG Cable RX (red) to URX and TX (yellow) to UTX.



Base unit P. C. board

#### Note:

\*: COM port names may vary depending on what your PC calls it.

#### 11.2.2. How to install Batch file into P.C.

- **1.** Insert the Batch file CD-ROM into CD-ROM drive and copy PNZZTG\*\*\*\* folder to your PC (example: D drive).
- 2. Open an MS-DOS mode window.

#### <Example for Windows>

On your computer, click [Start], select Programs (All Programs for Windows XP/Windows Server 2003), then click

MS-DOS Prompt. (for Windows 95/Windows 98)

Ωr

Accessories-MS-DOS Prompt. (for Windows Me)

Or

Command Prompt. (for Windows NT 4.0)

Or

Accessories-Command Prompt.

(for Windows 2000/Windows XP/Windows Server 2003)

- **3.** At the DOS prompt, type "D:" (for example) to select the drive, then press the **Enter** key.
- **4.** Type "CD ¥PNZZTG\*\*\*\*", then press the Enter key.
- **5.** Type "SET\_COM=X", then press the Enter key
- (X: COM port number used for the serial connection on your PC).
- **6.** Type "READID", then press the Enter key.
  - ·If any error messages appear, change the port number or check the cable connection.
  - ·If any value appear, go to next step.
- **7.** Type "**DOSKEY**", then press the **Enter** key.

## <Example>

- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PQZZTG\*\*\*\*
- D: ¥PNZZTG\*\*\*\* >SET\_COM=X
- D: ¥PNZZTG\*\*\*\*>READID
- 00 52 4F A8 A8
- D: ¥PNZZTG\*\*\*\*>DOSKEY
- D: ¥PNZZTG\*\*\*\*>\_

#### <Example: error happens>

- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PNZZTG\*\*\*
- D: ¥PNZZTG\*\*\*\* >SET\_COM=X
- D: ¥PNZZTG\*\*\*\*>READID
  CreateFile error

ERROR 10: Can't open serial port

D: ¥PNZZTG \*\*\*\*>\_

#### Note:

• "\*\*\*\*" varies depending on the country or models.

### 11.2.3. Commands


See the table below for frequently used commands.

Command name	Function	Example
rdeeprom	Read the data of EEPROM	Type "rdeeprom 00 00 FF", and the data from address "00 00" to "FF" is read out.
readid	Read ID (RFPI)	Type "readid", and the registered ID is read out.
writeid	Write ID (RFPI)	Type "writeid 00 18 E0 0E 98", and the ID "0018 E0 0E 98" is written.
hookoff	Off-hook mode on Base	Type "hookoff".
hookon	On-hook mode on Base	Type "hookon".
getchk	Read checksum	Type "getchk".
wreeprom	Write the data of EEPROM	Type "wreeprom 01 23 45". "01 23" is address and "45" is data to be written.

## 11.3. Adjustment Standard (Base Unit)

When connecting the simulator equipment for checking, please refer to below.

## 11.3.1. Bottom View




Note:

(A) - (S) is referred to Check Point (Base Unit) (P.35)

# 11.4. Adjustment Standard (Charger Unit)

When connecting the simulator equipment for checking, please refer to below.

## 11.4.1. Bottom View



#### Note:

(A) is referred to Check Point (Charger Unit) (P.38)

## 11.5. The Setting Method of JIG (Handset)

This section explains the PC setting to use command required in Check Point (Handset)(P.39).

#### <Preparation>

Serial JIG cable: PQZZ1CD300E\*

• PC which runs in DOS mode

• Batch file CD-ROM for setting: PNZZTG6411BX


#### Note:

\*: If you have the JIG Cable for TCD500 series (PQZZ1CD505E), change the following values of resistance. Then you can use it as a JIG Cable for both TCD300 and TCD500 series. (It is an upper compatible JIG Cable.)

Resistor	Old value (kΩ)	New value (kΩ)
R2	22	3.3
R3	22	3.3
R4	22	4.7
R7	4.7	10

### 11.5.1. Connections

- ①Connect the DC Power or Battery to BATT+ and BATT-.
- <sup>2</sup>Connect the JIG cable GND (black) to GND.
- 3 Connect the JIG cable UTX (yellow) to UTX and URX (red) to URX.



#### Note:

\*: COM port names may vary depending on what your PC calls it.

#### 11.5.2. How to install Batch file into P.C.

- 1. Insert the Batch file CD-ROM into CD-ROM drive and copy PNZZTG\*\*\*\*\* folder to your PC (example: D drive).
- 2. Open an MS-DOS mode window.

#### <Example for Windows>

On your computer, click [Start], select Programs (All Programs for Windows XP/Windows Server 2003),

MS-DOS Prompt. (for Windows 95/Windows 98)

Or

Accessories-MS-DOS Prompt. (for Windows Me)

Or

Command Prompt. (for Windows NT 4.0)

Or

**Accessories-Command Prompt.** 

(for Windows 2000/Windows XP/Windows Server 2003)

- **3.** At the DOS prompt, type "D:" (for example) to select the drive, then press the **Enter** key.
- **4.** Type "CD ¥PNZZTG\*\*\*\*\*, then press the Enter key.
- **5.** Type "SET RTX\_COM=X", then press the Enter key (X: COM port number used for the serial connection on your PC).
- **6.** Type "**READID**", then press the **Enter** key.
  - ·If any error messages appear, change the port number or check the cable connection.
  - •If any value appear, go to next step.
- **7.** Type "DOSKEY", then press the Enter key.

#### <Example>

- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PQZZTG\*\*\*\*\*
- D: ¥PNZZTG\*\*\*\* >SET RTX\_COM=X
- D: ¥PNZZTG\*\*\*\*\*>READID
- 00 52 4F A8 A8
- D: ¥PNZZTG\*\*\*\*\*>DOSKEY
- D: ¥PNZZTG\*\*\*\*\*> \_

#### <Example: Error happens>

- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PNZZTG\*\*\*\*\*
- D: ¥PNZZTG\*\*\*\*\* >SET RTX COM=X
- D: ¥PNZZTG\*\*\*\*\*>READID
  CreateFile error

ERROR 10: Can't open serial port

D: ¥PNZZTG\*\*\*\*\*> \_

#### Note:

• "\*\*\*\*" varies depending on the country or models.

### 11.5.3. Commands


See the table below for frequently used commands.

Command name	Function	Example
rdeeprom	Read the data of EEPROM	Type "rdeeprom 00 00 FF", and the data from address "00 00" to "FF" is read out.
readid	Read ID (RFPI)	Type "readid", and the registered ID is read out.
writeid	Write ID (RFPI)	Type "writeid 00 18 E0 0E 98", and the ID "0018 E0 0E 98" is written.
getchk	Read checksum	Type "getchk".
wreeprom	Write the data of EEPROM	Type "wreeprom 01 23 45". "01 23" is address and "45" is data to be written.

# 11.6. Adjustment Standard (Handset)

When connecting the simulator equipments for checking, please refer to below.

## 11.6.1. Component View



Note:

(A) - (R) is referred to Check Point (Handset) (P.39)

# 11.7. Things to Do after Replacing IC or X'tal

If repairing or replacing BBIC (FLASH type), EEPROM and X'tal, it is necessary to download the required data such as Programming data or adjustment data, etc in memory.

The set doesn't operate if it is not executed.

### 11.7.1. How to download the data

#### 11.7.1.1. Base Unit

First, operate the PC setting according to The Setting Method of JIG (Base Unit)(P.47).

Then download the appropriate data according to the following procedures.

	Items	How to download/Required adjustment
BBIC (FLASH type) (IC7)	Programming data is stored in memory.	1) Make sure to connect the JIG cable, then disconnect the DC Power in order to download the data.  2) Execute the command "flw480 ******.hex".  3) Connect the DC Power.  4) Press the PC Enter key once.  5) After a few minutes, "Successful upgrade" is displayed on the PC indicating downloading has finished.  6) Detach the JIG cable, then disconnect the DC Power.  7) Connect the DC Power.  8) Connect the JIG cable again, and execute the command "getchk", then confirm the checksum value is correct.  • If the downloading fails, start again from step 1).  9) Default batch file: Execute the command "default.bat".  10) Country version batch file: Execute the command "TG6411XXrevYY.bat". (*1)  11) Clock adjustment: Refer to Check Point (G). (*2)
EEPROM (IC401)	Adjusted parameter data is stored in memory. (country version batch file, default batch file, etc.)	1) Change the address "0000" of EEPROM to "00" to download
X'tal (X1)	System clock	Clock adjustment data is in EEPROM, adjust the data again after replacing it.  1) Refer to Check Point (F). (*2)

#### Note:

(\*1) XX: country code, YY: revision number, ZZ: Voice Prompt

"XX", "YY" and "ZZ" vary depending on the country version. You can find them in the batch file, PNZZ- mentioned in **The Setting Method of JIG (Base Unit)** (P.47).

(\*2) Refer to Check Point (Base Unit) (P.35)

## 11.7.1.2. Handset

First, operate the PC setting according to The Setting Method of JIG (Handset)(P.51).

Then download the appropriate data according to the following procedures.

Items		How to download/Required adjustment	
BBIC (FLASH type)	Programming data is stored in memory.	1) Make sure to connect the JIG cable, then disconnect the DC	
(IC1)		Power in order to download the data.	
		2) Execute the command "flw480 *******.hex".	
		3) Connect the DC Power.	
		4) Press and hold the handset Power key.	
		5) While holding down the handset Power key, press the PC Enter key once.	
		6) After a few minutes, "Successful upgrade" is displayed on the PC indicating downloading has finished.	
		7) Detach the JIG cable, then press the handset Power key to turn it on.	
		8) Connect the JIG cable again, and execute the command "getchk", then confirm the checksum value is correct.  • If the downloading fails, start again from step 1).	
		<ul><li>10) Default batch file: Execute the command "default.bat".</li><li>11) Default batch file (remaining): Execute the command "TGA641DEFrevYY.bat". (*3).</li></ul>	
		12) Country version batch file: Execute the command "TGA641XXrevYY.bat". (*3).	
		13) Clock adjustment: Refer to Check Point (H). (*4).	
		14) 1.8 V setting and battery low detection: Refer to Check Point (A), (F) and (G). (*4).	
EEPROM (IC3)	Adjusted parameter data is stored in memory. (country version batch file, default batch file, etc.)	Default batch file: Execute the command "default.bat".     Default batch file (remaining): Execute the command "TGA641DEFrevYY.bat". (*3)	
		3) Country version batch file: Execute the command "TGA641XXrevYY.bat". (*3)	
		4) Clock adjustment: Refer to Check Point (J). (*4)	
		5) 1.8 V setting and battery low detection: Refer to Check Point (A), (F) and (G). (*4)	
X'tal (X1)	System clock	Clock adjustment data is in EEPROM, adjust the data again after replacing it.  1) Refer to Check Point (H). (*4)	

### Note:

(\*3) XX: country code, YY: revision number

"XX" and "YY" vary depending on the country version. You can find them in the batch file, PNZZ- mentioned in **The Setting Method of JIG (Handset)** (P.51).

(\*4) Refer to Check Point (Handset) (P.39)

# 11.8. RF Specification

# 11.8.1. Base Unit

Item	Value	Refer to *
TX Power		Check Point (Base Unit) (J)
Modulation	-370±30/+370±30 kHz/div & Modulated	Check Point (Base Unit) (K)
	width ≧ 690 kHz	
Frequency Offset	-50 kHz ~ +50 kHz	Check Point (Base Unit) (L)
Frequency Drift	< ± 35 kHz / ms	Check Point (Base Unit) (M)
RX Sensitivity	< 1000 ppm	Check Point (Base Unit) (N)
Timing Accuracy	< ± 5.0 ppm/<±15.0ppm	Check Point (Base Unit) (O)
Power RAMP	Power RAMP is matching	Check Point (Base Unit) (P)

<sup>\*:</sup> Refer to Check Point (Base Unit) (P.35)


## 11.8.2. Handset

Item	Value	Refer to **
TX Power	19 dBm ~ 25 dBm	Check Point (Handset) (I)
Modulation	-370±30/+370±30 kHz/div & Modulated	Check Point (Handset) (J)
	width ≧ 690 kHz	
Frequency Offset	-50 kHz ~ +50 kHz	Check Point (Handset) (K)
Frequency Drift	< ± 35 kHz / ms	Check Point (Handset) (L)
RX Sensitivity	< 1000 ppm	Check Point (Handset) (M)
Power RAMP	Power RAMP is matching	Check Point (Handset) (N)

<sup>\*\*:</sup> Refer to Check Point (Handset) (P.39)

# 11.9. How to Check the Handset Speaker or Receiver

- 1. Prepare the digital voltmeter, and set the selector knob to ohm meter.
- 2. Put the probes at the speaker terminals as shown below.



# 11.10. Frequency Table (MHz)

Channel No	BASE UNIT		HANDSET	
	Transmit Frequency	Receive Frequency	Transmit Frequency	Receive Frequency
1	1897.344	1897.344	1897.344	1897.344
2	1895.616	1895.616	1895.616	1895.616
3	1893.888	1893.888	1893.888	1893.888
4	1892.160	1892.160	1892.160	1892.160
5	1890.432	1890.432	1890.432	1890.432
6	1888.704	1888.704	1888.704	1888.704
7	1886.976	1886.976	1886.976	1886.976
8	1885.248	1885.248	1885.248	1885.248
9	1883.520	1883.520	1883.520	1883.520
10	1881.792	1881.792	1881.792	1881.792

#### Note:

Channel No. 10: In the Test Mode on Base Unit and Handset.

# 12 Miscellaneous

## 12.1. How to Replace the Flat Package IC

Even if you do not have the special tools (for example, a spot heater) to remove the Flat IC, with some solder (large amount), a soldering iron and a cutter knife, you can easily remove the ICs that have more than 100 pins.

### 12.1.1. Preparation

- PbF (: Pb free) Solder
- · Soldering Iron

Tip Temperature of 700 °F ± 20 °F (370 °C ± 10 °C)

**Note:** We recommend a 30 to 40 Watt soldering iron. An expert may be able to use a 60 to 80 Watt iron where someone with less experience could overheat and damage the PCB foil.

Flux

Recommended Flux: Specific Gravity  $\rightarrow$  0.82. Type  $\rightarrow$  RMA (lower residue, non-cleaning type)


Note: See About Lead Free Solder (Pbf: Pb free) (P.4)

### 12.1.2. How to Remove the IC


1. Put plenty of solder on the IC pins so that the pins can be completely covered.

Note:


If the IC pins are not soldered enough, you may give pressure to the P.C. board when cutting the pins with a cutter.



2. Make a few cuts into the joint (between the IC and its pins) first and then cut off the pins thoroughly.



3. While the solder melts, remove it together with the IC pins.



When you attach a new IC to the board, remove all solder left on the board with some tools like a soldering wire. If some solder is left at the joint on the board, the new IC will not be attached properly.


## 12.1.3. How to Install the IC

1. Temporarily fix the FLAT PACKAGE IC, soldering the two marked pins.




\*Check the accuracy of the IC setting with the corresponding soldering foil.

2. Apply flux to all pins of the FLAT PACKAGE IC.




3. Solder the pins, sliding the soldering iron in the direction of the arrow.



## 12.1.4. How to Remove a Solder Bridge

- 1. Lightly resolder the bridged portion.
- 2. Remove the remaining solder along the pins using a soldering iron as shown in the figure below.



## 12.2. How to Replace the Shield Case

## 12.2.1. Preparation

- PbF (: Pb free) Solder
- · Soldering Iron

Tip Temperature of 700°F ± 20°F (370°C ± 10°C)

#### Note:

We recommend a 30 to 40 Watt soldering iron. An expert may be able to use a 60 to 80 Watt iron where someone with less experience could overheat and damage the PCB foil.

• Hot Air Desoldering Tool

Temperature: 608°F ± 68°F (320°C ± 20°C)

### 12.2.2. Caution


- To replace the IC efficiently, choose the right sized nozzle of the hot air desoldering tool that matches the IC package.
- Be careful about the temperature of the hot air desoldering tool not to damage the PCB and/or IC.

## 12.2.3. How to Remove the Shield Case


#### Note:

If you don't have special tools (ex. Hot air disordering tool), conduct the following operations.


1. Cut the case along perforation.




2. Remove the cut part.



3. Cut the four corners along perforation.




4. Remove the reminds by melting solder.




## 12.2.4. How to Install the Shield Case

#### Note:

- If you don't have special tools (ex. Hot air disordering tool), conduct the following operations.
- Shield case's No. : PNMC1013Z
  - 1. Put the shield case.




2. Solder the surroundings.




# 12.3. Terminal Guide of the ICs, Transistors and Diodes

## 12.3.1. Base Unit



## 12.3.2. Handset



# 13 Schematic Diagram

## 13.1. For Schematic Diagram

## 13.1.1. Base Unit (Schematic Diagram (Base Unit))

#### Notes:

1. DC voltage measurements are taken with voltmeter from the negative voltage line.

Important Safety Notice:

Components identified by  $\triangle$  mark have special characteristics important for safety. When replacing any of these components, use only the manufacturer's specified parts.

2. The schematic diagrams may be modified at any time with the development of new technology.

## 13.1.2. Handset (Schematic Diagram (Handset))

#### Notes:

- 1. DC voltage measurements are taken with an oscilloscope or a tester with a ground.
- 2. The schematic diagram may be modified at any time with the development of new technology.

### 13.1.3. Charger Unit (Schematic Diagram (Charger Unit))

#### Notes:


1. DC voltage measurements are taken with voltmeter from the negative voltage line.

Important Safety Notice:


Components identified by  $\triangle$  mark have special characteristics important for safety. When replacing any of these components, use only the manufacturer's specified parts.

2. The schematic diagram may be modified at any time with the development of new technology.

# 13.2. Schematic Diagram (Base Unit)




NC: No Components




NC: No Components KX-TG6411/6412/6413BX SCHEMATIC DIAGRAM (Base Unit)

# 13.3. Schematic Diagram (Handset)




NC: No Components



NC: No Components KX-TGA641 SCHEMATIC DIAGRAM (Handset\_Main)

# 13.4. Schematic Diagram (Charger Unit)




SCHEMATIC DIAGRAM (Charger Unit)

# **14 Printed Circuit Board**


# 14.1. Circuit Board (Base Unit\_Main)

# 14.1.1. Component View



KX-TG6411/6412/6413 CIRCUIT BOARD (Base Unit\_Main (Component View))


## 14.1.2. Bottom View



KX-TG6411/6412/6413 CIRCUIT BOARD (Base Unit\_Main (Bottom View))


# 14.2. Circuit Board (Handset)

# 14.2.1. Component View



KX-TGA641 CIRCUIT BOARD (Handset\_Main (Component View))


## 14.2.2. Bottom View



KX-TGA641 CIRCUIT BOARD (Handset\_Main (Bottom View))


# 14.3. Circuit Board (Charger Unit)

## 14.3.1. Component View



CIRCUIT BOARD (Charger unit (Component View))


## 14.3.2. Bottom View



CIRCUIT BOARD (Charger unit (Bottom View))

# 15 Exploded View and Replacement Parts List

# 15.1. Cabinet and Electrical Parts (Base Unit)




Ref.No.	Figure
А	<b>Φ</b> 2.6 x 8 mm

#### Note:

(\*1) Refer to the spacer (No. 109) of Cabinet and Electrical Parts (Handset) (P.75).


# 15.2. Cabinet and Electrical Parts (Handset)



#### Note:


- (\*1) This cable is fixed by welding. Refer to How to Replace the Handset LCD (P.46).
- (\*2) The rechargeable Ni-MH battery HHR-4MPT is available through sales route of Panasonic.
- (\*3) Attach the spacer (No. 122) to the exact location described above.

# 15.3. Cabinet and Electrical Parts (Charger Unit)



# 15.4. Accessories and Packing Materials


## 15.4.1. KX-TG6411BXS/BXT



### Note:

(\*1) These pads are pieces of Ref No. P3 (GIFT BOX).


## 15.4.2. KX-TG6412BXS/BXT



### Note:

(\*1) These pads are pieces of Ref No. P104 (GIFT BOX).

## 15.4.3. KX-TG6413BXS/BXT



## 15.5. Replacement Part List

1. RTL (Retention Time Limited)

#### Note

The "RTL" marking indicates that its Retention Time is Limited.

When production is discontinued, this item will continue to be available only for a specific period of time. This period of time depends on the type of item, and the local laws governing parts and product retention. At the end of this period, the item will no longer be available.

#### 2. Important safety notice

Components identified by the  $\triangle$  mark indicates special characteristics important for safety. When replacing any of these components, only use specified manufacture's parts.

- 3. The S mark means the part is one of some identical parts. For that reason, it may be different from the installed part.
- ISO code (Example: ABS-94HB) of the remarks column shows quality of the material and a flame resisting grade about plastics.
- 5. RESISTORS & CAPACITORS

Unless otherwise specified;

All resistors are in ohms ( $\Omega$ ) k=1000  $\Omega$ , M=1000 k $\Omega$  All capacitors are in MICRO FARADS ( $\mu$ F)p= $\mu\mu$ F

\*Type & Wattage of Resistor

#### Type

ERDS:Carbon	PQ4R:Chip ERS:Fusible Resistor ERF:Cement Resistor

Wattage

10,16:1/8W 14,25	:1/4W 12:1/2W	1:1W 2:2	W 3:3W
------------------	---------------	----------	--------

<sup>\*</sup>Type & Voltage Of Capacitor
Type

ECFD:Semi-Conductor	ECCD,ECKD,ECBT,F1K,ECUV:Ceramic
	ECQE,ECQV,ECQG:Polyester
	ECEA,ECST,EEE:Electlytic
ECQMS:Mica	ECQP:Polypropylene

Voltage

TOILAGO						
ECQ Type	ECQG ECQV Type	ECSZ Type		Oth	ers	
1H:50V 2A:100V 2E:250V 2H:500V		0F:3.15V 1A:10V 1V:35V 0J:6.3V	0J 1A 1C 1E,2	:6.3V :10V :16V 5:25V	1V 50,1H 1J 2A	:35V 1:50V :16V :100V

#### 15.5.1. Base Unit

### 15.5.1.1. Cabinet and Electrical Parts

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	1	PNKM1073Y4	CABINET BODY (for KX- TG6411BXS)	PS-HB
	1	PNKM1073Y1	CABINET BODY (for KX-TG6411BXT)	PS-HB
	2	PNKE1030Z3	CASE, CHARGE TERMINAL (for KX-TG6411BXS)	PS-HB
	2	PNKE1030Z1	CASE, CHARGE TERMINAL (for KX-TG6411BXT)	PS-HB
	3	PNBC1268Z1	BUTTON, LOCATOR	ABS-HB
	4	K2ECYZ000001	JACK, DC	
	5	PQJJ1T039Y	JACK, MODULAR	
	6	PNJT1025Z	CHARGE TERMINAL	
	7	PNLA1002Z	ANTENNA	

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	8	PNYE1009Z	SPACER, ANTENNA	
	9	PNKF1055Z2	CABINET COVER (for KX-TG6411BXS)	PS-HB
	9	PNKF1055Z1	CABINET COVER (for KX-TG6411BXT)	PS-HB
	10	PQHA10023Z	RUBBER PARTS, FOOT CUSH- ION	
	11	PNGT2240Y	NAME PLATE (for KX- TG6411BXS)	
	11	PNGT2240Z	NAME PLATE (for KX- TG6411BXT)	

#### 15.5.1.2. Main P.C.Board Parts

#### Note:

- (\*1) When replacing IC7, IC401 or X1, make the adjustment using PNZZTG6411BX. Refer to **How to download the data** (P.54) of **Things to Do after Replacing IC or X'tal.**
- (\*2) When you removing E1, use special tools (ex. Hot air disordering tool).
- (\*3) Backside of this IC has a ground plate.
- (\*4) Supplied IC is Flat Package Type.

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	PCB1	PNWPG6411BXH	MAIN P.C.BOARD ASS'Y (RTL)	
			(ICs)	
	IC1	COCBAYG00016	IC	S
	IC7	C1CB00002906	IC (BBIC(FLASH)) (*1) (*3) (*4)	
	IC401	PQWID300NEHR	IC (EEPROM) (*1)	
	IC801	C1CB00001842	IC (*3)	
			(TRANSISTORS)	
	Q2	B1ABCE000009	TRANSISTOR (SI)	
	Q3	B1ACGP000007	TRANSISTOR(SI)	
	Q4	PQVTBF822T7	TRANSISTOR(SI)	
	Q5	2SD0874AS	TRANSISTOR (SI)	
	Q8	B1ADGE000004	TRANSISTOR (SI)	
	Q9	B1ADGE000004	TRANSISTOR (SI)	
			(DIODES)	
	D1	B0JCME000035	DIODE(SI)	
	D3	B0EDER000009	DIODE(SI)	
	D5	MA111	DIODE(SI)	S
	D6	MA111	DIODE(SI)	S
	D9	MA111	DIODE(SI)	S
	D21	POVDRLZ20A	DIODE(SI)	s
	D22	B0ECKM000008	DIODE(SI)	5
	D23	MA8220	DIODE(SI)	s
	DA801	B0DDCD000001	DIODE(SI)	3
	DA801	B0DDCD000001	DIODE(SI)	
	DAGUZ	BODDCDOOOOT	(COILS)	
	L1	PQLQXF330K	COIL	s
	L2	PQLQXF330K	COIL	S
	L801	G1C27NJ00010	COIL	٥
	L801			
	L802	G1C3N0ZA0063	COIL	
	T803	GIC3NUZAUU63		
	<b>D.1</b>	D1 1101 00 4000 4	(COMPONENT PARTS)	_
	RA1	D1H810240004	RESISTOR ARRAY	S
	RA402	D1H410320002	RESISTOR ARRAY	
	RA80	D1H422120001	RESISTOR ARRAY	
			(VARISTOR)	
	SA1	J0LF00000026	VARISTOR (SURGE ABSORBER)	
			(RESISTORS)	
	R3	PQ4R10XJ184	180k	S
	R4	PQ4R10XJ105	1M	s
	R5	PQ4R10XJ184	180k	S
	R6	PQ4R10XJ105	1M	S
	R7	ERJ3GEYJ565	5.6M	5
	R8	ERJ3GEYJ104	100k	
	R9	ERJ3GEYJ565	5.6M	
	R10	ERJ3GEYJ104	100k	
		ERJ3GE1J104 ERJ2GEJ103	10k	
	R12	ERUZGEU103	TUK	

Safety	Ref. No.	Part No.	Part Name & Description	Remark
	R13	ERJ2GEJ681	680	
	R14	ERJ3GEYJ104	100k	
	R15	PQ4R10XJ272	2.7k	S
	R16	ERJ2GEJ103	10k	
	R17	ERJ2GEJ222	2.2k	
	R18	ERJ2GEJ273X	27k	
	R19	ERJ2GEJ822	8.2k	
	R20	ERJ2GEJ392	3.9k	
	R21	ERJ12YJ120	12	
	R22	ERJ12YJ270	27	
	R23 R24	ERJ2GEJ104 ERJ2GEJ473	100k 47k	
	R24 R27	ERJ2GEJ104	100k	
	R28	ERJ2GEYJ474	470k	s
	R29	ERJ2GEJ121	120	3
	R30	ERJ3GEYJ820	82	
	R31	ERJ3GEYJ821	820	
	R32	ERJ2GEJ823	82k	
	R33	ERJ2GEJ102	1k	
	R34	ERJ2GEJ823	82k	
	R35	ERJ2GEJ102	1k	
	R36	ERJ2GEJ102	120k	-
	R37	ERJ2GEJ102	1k	1
	R38	ERJ2RKF1000	100	1
	R39	ERJ2RKF1400	140	1
	R42	PQ4R10XJ475	4.7M	s
	R43	PQ4R10XJ475	4 . 7M	s
	R55	ERJ1TYJ3R9U	3.9	-
	R56	ERJ1TYJ3R9U	3.9	
	R75	ERJ2GEJ101	100	
	R76	ERJ2GEJ102	1k	
	R77	ERJ2GEJ103	10k	
	R81	ERJ2GEJ332	3.3k	
	R106	ERJ2GEJ221	220	
	R109	ERJ2GEJ221	220	
	R116	ERJ2GEJ101	100	
	R117	ERJ2GEJ332	3.3k	
	R124	PQ4R18XJ100	10	s
	R129	ERJ2GEJ103	10k	-
	R130	ERJ2GEJ102	1k	
	R135	ERJ2GEJ103	10k	
	R430	ERJ2GEJ100	10	
	R511	ERJ2GE0R00	0	
	R615	D0GA563ZA006	56k	
	R657	ERJ2GEJ103	10k	
	R801	ERJ2GEJ152	1.5k	
	R802	ERJ2GEJ121	120	
	R803	ERJ2GEJ102	1k	
	R804	ERJ2GEJ102	1k	
	R805	ERJ2GEJ470	47	
	R806	ERJ2GEJ221	220	<u> </u>
	R807	ERJ2GEJ221	220	
	R808	ERJ2GEJ152	1.5k	1
		-	(CAPACITORS)	
	C3	F1K2H681A008	680p	1
	C4	F1K2H681A008	680p	1
	C5	ECUV1C103KBV	0.01	
	C6	ECUV1C103KBV	0.01	
	C7	ECUV1C104KBV	0.1	1
	C8	ECUV1C104KBV	0.1	
	С9	F1K2H681A008	680p	
	C10	F1K2H681A008	680p	
	C14	ECUE1E472KBQ	0.0047	
	C17	PQCUV1A225KB	2.2	1
	C18	ERJ3GEYJ682	6.8k	1
	C22	PQCUV1A105KB	1	1
	C23	ECJ0EB0J224K	0.22	s
	C25	ECUE1C103KBQ	0.01	
	C27	F2A1H100B132	10	
	C29	F1G1H5R0A480	5p	
	C30	F1G1H5R0A480	5p	1
	C31	PQCUV1A225KB	2.2	

Safety		Part No.	Part Name & Description	Remarks
	No.			
	C36	F2A1A3310040	330	
	C37	F1G1H5R0A480	5p	
	C42	ECUV1C103KBV ECUV1C103KBV	0.01	
	C51	ECUE1A104KBQ	0.1	
	C52	ECUE1H821KBQ	820p	
	C53	ECUE1H821KBQ	820p	
	C54	ECUE1A333KBQ	0.033	
	C55	ECUE1A823KBQ	0.082	
	C56	ECUV1C104KBV	0.1	
	C60	ECUE1A104KBQ	0.1	
	C61	ECUE1A104KBQ	0.1	
	C65	ECUE1H100DCQ	10p	
	C70	ECUE1H100DCQ	10p	
	C72	ECUE1A104KBQ ECUE1H100DCQ	0.1	
	C75	ECUE1A104KBQ	10p 0.1	
	C84	ECUV1A225KB	2.2	
	C136	ECUE1H100DCQ	10p	
	C137	ECUE1H100DCQ	10p	
	C141	ECJ0EB0J224K	0.22	S
	C157	ECUE1H102KBQ	0.001	
	C168	ECUE1H100DCQ	10p	
	C169	ECUE1H100DCQ	10p	
	C170	ECUE1H100DCQ	10p	
	C171	ECUE1H100DCQ	10p	
	C305	ECUE0J105KBQ	1	
	C501	ECUE1H102KBQ	0.001	
	C614	ECUV1A105KBV	1	
	C615	ECUV1A105KBV	1	
	C616 C617	ECUV1A105KBV ECUV1A105KBV	1	
	C625	ECUV1A105KBV	1	
	C630	ECUE1H100DCQ	10p	
	C631	ECUE1H100DCQ	10p	
	C802	F1G1H1R8A480	1.8p	
	C803	F1G1H1R5A480	1.5p	
	C804	F1G1H1R8A480	1.8p	
	C805	F1G1H3R3A480	3.3p	
	C806	F1G1H3R3A480	3.3p	
	C808	ECUE1A104KBQ	0.1	
	C809	ECUE1H100DCQ	10p	
	C810	F1G1H2R2A480 ECUE1H100DCQ	2.2p 10p	
	C812	ECUE1H100DCQ	10p	
	C813	F1G1H2R2A480	2.2p	
	C814	ECUE1H332KBQ	0.0033	
<b>—</b>	C819	ECUE1H100DCQ	10p	
	C820	F1G1HR75A480	0.75p	
	C822	ECUE1H100DCQ	10p	
	C823	ECUE1H101JCQ	100p	
	C825	ECUE1H100DCQ	10p	
	C826	F1G1HR90A480	0.9p	
	C827	ECUE1H100DCQ	10p	
	C834	F1G1HR50A480	0.5p	
	C851	F1G1H2R0A480	2p	
	C853 C855	F1G1H2R0A480 ECUE1H100DCQ	2p	
	C856	ECUE1H101JCQ	10p 100p	
	C857	ECUE1H101DCQ	10p	
<u> </u>	C858	ECUE1H101JCQ	100p	
	C859	ECUE1H100DCQ	10p	
	C860	F1G1H3R0A480	3p	
	C861	ECUE1H100DCQ	10p	
			(OTHERS)	
	E1	PNMC1013Z	CASE, MAGNETIC SHIELD	
			(*2)	
	X1	H0J103500027	CRYSTAL OSCILLATOR (*1)	
	F1	K5H302Y00003	FUSE	
	SW1	K0H1BA000259	SPECIAL, SWITCH	

### 15.5.2. Handset

### 15.5.2.1. Cabinet and Electrical Parts

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	101	PNGP1048Z3	PANEL, LCD (for KX- TGA641BXS)	РММА-НВ
	101	PNGP1048Z1	PANEL, LCD (for KX-TGA641BXT)	PMMA-HB
	102	PNYE1008Z	TAPE, DOUBLE SIDED	
	103	PNKM1080Y7	CABINET BODY (for KX- TGA641BXS)	PS-HB
	103	PNKM1080Y4	CABINET BODY (for KX-TGA641BXT)	PS-HB
	104	PNHR1105Z	OPTIC CONDUCTIVE PARTS, LED LENS	PS-HB
	105	PNHS1072Z	SPACER, RECEIVER NET	
	106	PQHS10467Z	COVER, SPEAKER NET	
	107	L0AD02A00028	RECEIVER	
	108	PQHG10729Z	RUBBER PARTS, RECEIVER	
	109	PNYE1009Z	SPACER, CUSHION LCD	
	110	PNBC1265Z1	BUTTON, VOLUME KEY	ABS-HB
	111	PNJK1050T	KEYBOARD SWITCH	
	112	PNHX1165Z	COVER, LCD SHEET	
	113	PNJT1027Z	CHARGE TERMINAL (L)	
	114	PNJT1026Z	CHARGE TERMINAL (R)	
	115	PQHR11315Z	GUIDE, SPEAKER HOLDER	ABS-HB
	116	L0AA02A00095	SPEAKER	
	117	PQHS10784Y	SPACER, SPEAKER NET	
	118	PNJC1014Z	BATTERY TERMINAL	
	119	PNKF1057Z3	CABINET COVER (for KX-TGA641BXS)	ABS-HB
	119	PNKF1057Z1	CABINET COVER (for KX-TGA641BXT)	ABS-HB
	120	PQQT23182Z	LABEL, ATTENTION	
	121	PNGT2251Y	NAME PLATE (for KX- TGA641BXS)	
	121	PNGT2251Z	NAME PLATE (for KX-TGA641BXT)	
	122	PNHS1079Z	SPACER, BATTERY COVER	
	123	PNKK1027Z3	LID, BATTERY COVER (for KX-TGA641BXS)	ABS-HB
	123	PNKK1027Z1	LID, BATTERY COVER (for KX-TGA641BXT)	ABS-HB
	124	PNHX1219Z	PET SHEET	

## 15.5.2.2. Main P.C.Board Parts

#### Note:

- (\*1) Reconfirm the model No. written on the handset's name plate when replacing PCB100. Because the model No. of the optional handset may differ from the included handset.
- (\*2) When replacing IC1, IC3 or X1, make the adjustment using PNZZTG6411BX. Refer to **Handset** (P.55) of **Things** to **Do after Replacing IC or X'tal.**
- (\*3) When you removing E105, use special tools (ex. Hot air disordering tool).
- (\*4) When replacing the handset LCD, See How to Replace the Handset LCD(P.46).
- (\*5) Backside of this IC has a ground plate.
- (\*6) Supplied IC is Flat Package Type.

Safety	Ref.	Part No.	Part Name & Description	Remarks
	No.			
	PCB100	PNWPGA641BXR	MAIN P.C.BOARD ASS'Y	
			(RTL) (*1)	
			(ICs)	
	IC1	C1CB00002906	IC (BBIC (FLASH)) (*2)	
			(*5) (*6)	
	IC3	PQWIA130EXRR	IC (EEPROM) (*2)	
	IC801	C1CB00001842	IC (*5)	
			(TRANSISTORS)	
	Q2	B1ADGE000004	TRANSISTOR(SI)	

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	Q4	B1ADGE000004	TRANSISTOR (SI)	
	Q7	UN9219J	TRANSISTOR (SI)	s
	Q9	2SC6054JSL	TRANSISTOR (SI)	
	Q10	UN9219J	TRANSISTOR (SI)	S
	Q11	B1ADCF000161	TRANSISTOR (SI)	
	Q12	B1ADCF000161	TRANSISTOR (SI)	
			(DIODES)	
	D1	MA2YD2120L	DIODE(SI)	
	D7	B0JCME000035	DIODE(SI)	
	D21	MA8043M	DIODE(SI)	S
	D22	MA8043M	DIODE(SI)	S
	DA801	B0DDCD000001	DIODE(SI)	
	LED1	B3ACB0000216	LED	
	LED2	B3ACB0000216	LED	
	LED3	B3ACB0000216	LED	
	LED4	B3ACB0000216	LED	
	LED5	B3ACB0000216	LED	
	LED6	B3ACB0000216	LED	
	LED7	B3ACB0000216	LED	
	LED8	B3ACB0000216	LED	
	LED9	B3ACB0000216	LED	
	LED12	B3ACB0000216	LED	+
-	22022	238020000216	(COILS)	+
	T 0 0 1	0100777700010		1
	L801	G1C27NJ00010	COIL	1
	L802	G1C3N6ZA0063	COIL	
	L803	G1C3N6ZA0063	COIL	
	F1	PQLQR2M5N6K	COIL	S
			(COMPONENTS PARTS)	
	RA1	D1H810240004	RESISTOR ARRAY	S
	RA2	D1H410220001	RESISTOR ARRAY	
	RA4	D1H433220001	RESISTOR ARRAY	
	RA61	D1H422120001	RESISTOR ARRAY	
			(VARISTORS)	
	D8	D4ED1270A014	VARISTOR	
	D13	D4ZZ00000024	VARISTOR	
	D14	D4ZZ00000024	VARISTOR	
			(RESISTORS)	
	R2	ERJ2GEJ392	(RESISTORS) 3.9k	
	R2 R6	ERJ2GEJ392 ERJ2GEJ102		
			3.9k	
	R6	ERJ2GEJ102	3.9k 1k	
	R6 R7	ERJ2GEJ102 ERJ2GEJ122	3.9k 1k 1.2k	
	R6 R7 R8	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101	3.9k 1k 1.2k 100	
	R6 R7 R8 R20	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100	3.9k 1k 1.2k 100	
	R6 R7 R8 R20 R27 R28	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821	3.9k 1k 1.2k 100 10 820 820	
	R6 R7 R8 R20 R27 R28 R30	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ3GEYJ273	3.9k 1k 1.2k 100 10 820 820 27k	
	R6 R7 R8 R20 R27 R28 R30 R40	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ3GEYJ273 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k	
	R6 R7 R8 R20 R27 R28 R30	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ3GEYJ273 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ3GEYJ273 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ3GEYJ273 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 0.1	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 1.1	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 470	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 470 1k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 0.1 10k 470 1k 3.3k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 1.1 10k 470 1k 3.3k 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 3.3k 10k 1k 1.2k 1.2k 1.2k 1.2k 1.2k 1.2k 1.2k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ103	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 3.3k 10k 1k 10o 1k 10k 10k 10k 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64 R66	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ101	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 3.3k 10k 1k 10c 1k 10c 1k 1k 10c 1k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64 R66 R73	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 10k 1k 1k 100 10k 1k 18	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64 R66 R73 R74	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 3.3k 10k 1k 1k 100 1k 1k 100 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64 R66 R73	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 10k 1k 1k 100 10k 1k 18	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R55 R63 R64 R66 R73 R74	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 3.3k 10k 1k 1k 100 1k 1k 100 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R63 R64 R66 R73 R74 R203	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ104 ERJ2GEJ105 ERJ2GEJ106 ERJ2GEJ107 ERJ2GEJ107 ERJ2GEJ108 ERJ2GEJ108 ERJ2GEJ109 ERJ2GEJ820 ERJ2GEJ820 DOGA563ZA006	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 3.3k 10k 1k 1k 100 1k 1k 100 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R63 R64 R66 R73 R74 R203 R215	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100	3.9k 1k 1.2k 100 10 820 820 27k 10k 10k 10k 10k 10k 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 10o 1k 1k 100 1k 1k 100 10k 1k 100 10k 1k 100 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248 R251	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 10o 1k 1k 100 10k	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248 R251 R300	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ104 ERJ2GEJ105 ERJ2GEJ106 ERJ2GEJ107 ERJ2GEJ107 ERJ2GEJ108 ERJ2GEJ108 ERJ2GEJ109 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 3.3k 10k 11k 100 10k 1k 100 10k 1k 100 10k 1k 100 10k 1k 82 82 82 56k 0	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301	ERJ2GEJ102 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ831	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 3.3k 10k 1k 100 10k 1k 100 10k 1k 00 00 00 00 00 00 00 00 00 00 00 00 00	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301 R302	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ100 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 0.1 10k 470 1k 3.3k 10k 1k 100 1k 1k 00 10k 1k 00 10k 1k 00 10k 1k 82 82 82 56k 0 0 0 0 330 330 330	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301 R302 R303	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ820 DOGA563ZA006 ERJ2GEJ820 ERJ2GEJ820 ERJ2GEJ831 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 0.1 1k 3.3k 10k 1k 100 1k 1k 82 82 82 56k 0 0 0 0 330 330 330 330 330	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R63 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301 R302 R303 R304 R305	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ121 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 0.1 10k 470 1k 3.3k 10k 1k 100 10k 1k 82 82 56k 0 0 0 0 330 330 330 330 330 330 330 33	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R63 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301 R302 R303 R304 R305 R308	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ121 ERJ2GEJ101 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ100 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ101 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ331	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 0.1 10k 470 1k 3.3k 10k 1k 100 10k 1k 82 82 82 56k 0 0 0 0 330 330 330 330 330 330 330 33	
	R6 R7 R8 R20 R27 R28 R30 R40 R41 R42 R45 R50 R51 R52 R53 R54 R63 R64 R66 R73 R74 R203 R215 R248 R251 R300 R301 R302 R303 R304 R305	ERJ2GEJ102 ERJ2GEJ122 ERJ2GEJ121 ERJ2GEJ100 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ821 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ103 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ102 ERJ2GEJ103 ERJ2GEJ100 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331 ERJ2GEJ331	3.9k 1k 1.2k 100 10 820 820 820 27k 10k 10k 10k 10k 0.1 10k 470 1k 3.3k 10k 1k 100 10k 1k 82 82 56k 0 0 0 0 330 330 330 330 330 330 330 33	

Safety		Part No.	Part Name & Description	Remarks
	No. R330	ERJ2GEJ105X	1M	
	R331	ERJ2GEJ273X	27k	
	R332	ERJ2GEJ273X	27k	
	R801	ERJ2GEJ681	680	
	R802	ERJ2GEJ101	100	
	R803	ERJ2GEJ102	1k	
	R804	ERJ2GEJ102	1k	
	R805	ERJ2GEJ470	47	
	R806	ERJ2GEJ221	220	
	R807	ERJ2GEJ221	220	
			(CAPACITORS)	
	C1	F2A0J3310067	330	
	C2	F2A0J3310067	330	
	C5	ECUE1A104KBQ	0.1	
	C10	ECUV1A225KB	2.2	
	C11	ECUE1A104KBQ	0.1	
		_		
	C12	PQCUV0J106KB	10	
	C13	ECUE1A104KBQ	0.1	
	C15	ECUV1A105KBV	1	
	C38	ECUE1H100DCQ	10p	
	C40	ECUE1A104KBQ	0.1	
	C43	ECUE1H100DCQ	10p	
	C44	ECUE1A104KBQ	0.1	
	C45	ECUE1A104KBQ	0.1	
	C46	ECUE1H100DCQ	10p	
	C47	ECUV1A105KBV	1	
	C49	ECUV1A105KBV	1	
	C50	ECUV1A105KBV	1	
	C51	ECUV1A105KBV	1	
	C52	PQCUV0J106KB	10	
	C53	PQCUV0J106KB	10	
	C54	ECUE1H100DCQ	10p	
	C55	ECUE1H100DCQ	10p	
	C70	ECUE1H100DCQ	10p	
	C71	ECUE1H100DCQ	10p	
	C72	ECUE1H100DCQ	10p	
	C73	ECUE1H100DCQ	10p	
	C96	ECUE1H100DCQ	10p	
	C97	ECUE1H100DCQ	10p	
	C103		100p	
	C104	ECUE1H100DCQ	10p	
	C105	ECUE1H101JCQ	100p	
	C113	ECUE1H100DCQ	10p	
	C138	ECUE1H100DCQ		
	C139	ECUE1H100DCQ		
	C147	ECUV1C105KBV	1	
	C152	ECUE1H102KBQ	0.001	
	C172	ECUV1C104KBV	0.1	
	C175	ECUV1C105KBV	1	
	C182	F1G1H3R0A480	Зр	
	C186	F1G1H2R0A480	2p	
	C187	F1G1H2R0A480	2p	
	C188	ECUE0J105KBQ	1	
	C331	ECUE0J105KBQ	1	
	C332	ECUE0J105KBQ	1	
	C580	ECUE1H100DCQ	10p	
_	C802	F1G1H2R0A480	2p	
	C803	F1G1H1R5A480	1.5p	
	C804	F1G1H2R0A480	2p	
	C805	F1G1H3R3A480	3.3p	
	C806	F1G1H3R3A480	3.3p	
	C808		0.1	
	C809	ECUE1H100DCQ	10p	
	C810	F1G1H1R6A480	1.6p	
	C811	ECUE1H100DCQ	10p	
				<u> </u>
	C812	ECUE1H100DCQ	10p	
	C813	F1G1H1R6A480	1.6p	
	C814	ECUE1H332KBQ	0.0033	
	C819	ECUE1H100DCQ		
	C820	F1G1HR70A480	0.7p	
	C822	ECUE1H100DCQ	10p	
•	C825	ECUE1H100DCQ	10p	
			2p	

Safety		Part No.	Part Name & Description	Remarks
	No.			
	C827	ECUE1H100DCQ	10p	
	C834	F1G1HR50A480	0.5p	
	C859	F1G1H3R0A480	3p	
	C860	ECUE1H100DCQ	10p	
	C861	F1G1H3R0A480	3p	
	C862	F1G1HR70A480	0.7p	
	C863	ECUE1H100DCQ	10p	
	C864	ECUE1H100DCQ	10p	
			(OTHERS)	
	MIC100	L0CBAY000032	MICROPHONE	
	E101	L5DYBYY00001	LIQUID CRYSTAL DISPLAY (*4)	
	E102	PNHR1114Z	TRANSPARENT PLATE, LCD PLATE	РММА-НВ
	E103	PNHR1113Z	GUIDE, LCD HOLDER	ABS-HB
	E104	PNHX1136Z	COVER, LCD COVER SHEET	
	E105	PNMC1013Z	CASE, MAGNETIC SHIELD (*3)	
	E106	PNLA1020Z	ANTENNA	
	E107	PNVE1002Z	BATTERY TERMINAL	
	X1	ној103500034	CRYSTAL OSCILLATOR (*2)	

# 15.5.3. Charger Unit

## 15.5.3.1. Cabinet and Electrical Parts

Safety	Ref. No.	Part No.	Part Name & Description Remarks
	200	PNLC1008YS	CHARGER UNIT ASS'Y with- out NAME PLATE (RTL) (for KX-TG6412BXS) (for KX-TG6413BXS)
	200	PNLC1008ZT	CHARGER UNIT ASS'Y with- out NAME PLATE (RTL) (for KX-TG6412BXT) (for KX-TG6413BXT)
	200-1	PNKM1077Z4	CABINET BODY (for KX-PS-HB TG6412BXS) (for KX- TG6413BXS)
	200-1	PNKM1077Z1	CABINET BODY (for KX-PS-HB TG6412BXT) (for KX- TG6413BXT)
	200-2	PNJT1010Z	CHARGE TERMINAL
	200-3	PNKF1012Z8	CABINET COVER (for KX- TG6412BXS) (for KX- TG6413BXS)
	200-3	PNKF1012Z1	CABINET COVER (for KX-PS-HB TG6412BXT) (for KX- TG6413BXT)
	200-4	PQHA10023Z	RUBBER PARTS, FOOT CUSH- ION
	201	PNGT1838Y	NAME PLATE (for KX- TG6412BXS) (for KX- TG6413BXS)
	201	PNGT1838Z	NAME PLATE (for KX- TG6412BXT) (for KX- TG6413BXT)

## 15.5.3.2. Main P.C.Board Parts

Safety	Ref.	Part No.	Part Name & Description	Remarks
	No.			
	PCB200	PNWPTGA641CH	MAIN P.C.BOARD ASS'Y	
			(RTL)	
			(JACK)	
	J1	K2ECYB000001	JACK	s
			(RESISTOR)	
	R1	ERG2SJ120	12	
			(FUSE)	
	F1	K5H302Y00003	FUSE	

## 15.5.4. Accessories and Packing Materials

#### Note:

(\*1) You can download and refer to the Operating Instructions (Instruction book) on TSN Server.

### 15.5.4.1. KX-TG6411BXS/BXT

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
⚠	A1	PQLV219BXZ	AC ADAPTOR	
	A2	PQJA10075Z	CORD, TELEPHONE	
	A3	PNQX1690Z	INSTRUCTION BOOK (*1)	
	A4	PNQW1538Z	LEAFLET, QUICK GUIDE (for Arabic)	
	<b>A</b> 5	PNQW1539Z	LEAFLET, QUICK GUIDE (for Persian)	
	P1	PQPP10152Z	PROTECTION COVER (for Base Unit)	
	P2	XZB08X25B02	PROTECTION COVER (for Handset)	
	P3	PNPK2315Z	GIFT BOX	

### 15.5.4.2. KX-TG6412BXS/BXT

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
⚠	A101	PQLV219BXZ	AC ADAPTOR	
	A102	PQJA10075Z	CORD, TELEPHONE	
	A103	PNQX1690Z	INSTRUCTION BOOK (*1)	
	A104	PNQW1538Z	LEAFLET, QUICK GUIDE (for Arabic)	
	A105	PNQW1539Z	LEAFLET, QUICK GUIDE (for Persian)	
	P101	PQPP10152Z	PROTECTION COVER (for Base Unit)	
	P102	XZB08X25B02	PROTECTION COVER (for Handset)	
	P103	XZB13X19C03	PROTECTION COVER (for Charger Unit)	
	P104	PNPK2324Z	GIFT BOX	
	P105	PNPD1296Z	CUSHION	

### 15.5.4.3. KX-TG6413BXS/BXT

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
⚠	A201	PQLV219BXZ	AC ADAPTOR	
	A202	PQJA10075Z	CORD, TELEPHONE	
	A203	PNQX1690Z	INSTRUCTION BOOK (*1)	
	A204	PNQW1538Z	LEAFLET, QUICK GUIDE (for Arabic)	
	A205	PNQW1539Z	LEAFLET, QUICK GUIDE (for Persian)	
	P201	PQPP10152Z	PROTECTION COVER (for Base Unit)	
	P202	XZB08X25B02	PROTECTION COVER (for Handset)	
	P203	XZB13X19C03	PROTECTION COVER (for Charger Unit)	
	P204	PNPK2330Z	GIFT BOX	
	P205	PNPD1297Z	CUSHION	

### 15.5.5. Screws

Safety	Ref. No.	Part No.	Part Name & Description	Remarks
	A	XTB26+8GFJ	TAPPING SCREW	
	В	XTB2+8GFJ	TAPPING SCREW	

### 15.5.6. Fixtures and Tools

#### Note:

- (\*1) See Equipment Required (P.47), and The Setting Method of JIG (Handset) (P.51).
- (\*2) When replacing the Handset LCD, See **How to Replace the Handset LCD** (P.46).

Safety	Ref. No.	Part No.	Part Name & Description Remarks
		PQZZ1CD300E	JIG CABLE (*1)
		PNZZTG6411BX	BATCH FILE CD-ROM (*1)
		PQZZ430PIR	TIP OF SOLDERING IRON (*2)
		PQZZ430PRB	RUBBER OF SOLDERING IRON (*2)

K.T KXTG6411BXS KXTG6411BXT KXTG6412BXS KXTG6412BXT KXTG6413BXS KXTG6413BXT KXTGA641BXS KXTGA641BXS