Service Manual

Caller ID Compatible **2LINE**







KX-TGA939T (Portable)

KX-TG9391T (Base Unit)



(Charger Unit)

Configuration for each model

| Model No | Base Unit | Handset | Charger Unit | Expandable |
|------------|------------|------------|--------------|------------|
| KX-TG9391 | 1 (TG9391) | 1 (TGA939) | 1 | Up to 6 |
| KX-TG9392 | 1 (TG9391) | 2 (TGA939) | 2 | Up to 6 |
| KX-TGA939* | | 1 (TGA939) | 1 | |

^{*} KX-TGA939 is also an optional accessory, which contains a handset and a charger.

Telephone Equipment Model No. KX-TG9391T **KX-TG9392T KX-TGA939T**

Digital Corded/Cordless Answering System Titanium Black Version (for U.S.A.)

MARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

IMPORTANT SAFETY NOTICE -

There are special components used in this equipment which are important for safety. These parts are marked by \triangle in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

· IMPORTANT INFORMATION ABOUT LEAD FREE, (PbF), SOLDERING

If lead free solder was used in the manufacture of this product, the printed circuit boards will be marked PbF. Standard leaded, (Pb), solder can be used as usual on boards without the PbF mark. When this mark does appear, please read and follow the special instructions described in this manual on the use of PbF and how it might be permissible to use Pb solder during service and repair work.

- When you note the serial number, write down all 11 digits. The serial number may be found on the bottom of the unit.
- The illustrations in this Service Manual may vary slightly from the actual product.

Note for TABLE OF CONTENTS:

Because sections 5, 6 and 7 of this manual are the extracts from the operating instructions for this model, they are subject to change without notice. You can download and refer to the original operating instructions on TSN Server for further information.

TABLE OF CONTENTS

| | | PAGE |
|----|--|-----------|
| 1 | Safety Precautions | 4 |
| | 1.1. For Service Technicians | |
| 2 | Warning | |
| | 2.1. Battery Caution | |
| | 2.2. About Lead Free Solder (Pbf: Pb free) | 4 |
| | 2.3. Discarding of P. C. Board | |
| | Specifications | |
| 4 | Technical Descriptions | 7 |
| | 4.1. Block Diagram (Base Unit) | 7 |
| | 4.2. Circuit Operation (Base Unit) | |
| | 4.3. Block Diagram (Portable) | 11 |
| | 4.4. Circuit Operation (Portable) | 12 |
| | 4.5. Circuit Operation (Charger Unit) | |
| | 4.6. Signal Route | 14 |
| 5 | Location of Controls and Components | |
| | 5.1. Controls | |
| 6 | Installation Instructions | 19 |
| | 6.1. Connections | |
| | 6.2. Battery | |
| 7 | Operating Instructions | |
| - | 7.1. Programmable settings | 22 |
| | 7.2. Registering a Portable to the Base Unit | |
| | 7.3. Copying Phonebook Entries | |
| | 7.4. Dialing Mode | 28 |
| | 7.5. Error Messages | |
| | 7.6. Troubleshooting | |
| Q | Service Mode | |
| U | 8.1. Engineering Mode | |
| | 8.2. Copying Phonebook Items when Repairing | |
| | 8.3. How to Clear User Setting | |
| ۵ | Troubleshooting Guide | 20 |
| 9 | 9.1. Troubleshooting Flowchart | 39 |
| | | |
| | 9.2. Troubleshooting by Symptom (Base Unit and Charger Unit) | J 50 |
| | , | |
| 40 | 9.3. Troubleshooting by Symptom (Portable) | |
| 10 | Disassembly and Assembly Instructions | |
| | 10.1. Disassembly Instructions | |
| | 10.2. Assembly Instructions | |
| 11 | Measurements and Adjustments | |
| | 11.1. The Setting Method of JIG (Base Unit) | |
| | 11.2. Adjustment Standard (Base Unit) | |
| | 11.3. Adjustment Standard (Charger Unit) | |
| | 11.4. The Setting Method of JIG (Portable) | |
| | 11.5. Adjustment Standard (Portable) | |
| | 11.6. Things to Do after Replacing IC or X'tal | |
| | 11.7. RF Specification | |
| | 11.8. How to Check the Portable Speaker of | |
| | Receiver | |
| | 11.9. Frequency Table (MHz) | |
| 12 | Schematic Diagram | |
| | 12.1. For Schematic Diagram | |
| | 12.2. Schematic Diagram (Base Unit_Main) | |
| | 12.3. Schematic Diagram (Base Unit_Operation) | |
| | 12.4. Schematic Diagram (Portable) | |
| | 12.5. Schematic Diagram (Charger Unit) | |
| 13 | Printed Circuit Board | |
| | 13.1. Circuit Board (Base Unit_Main) | 89 |
| | 13.2. Circuit Board (Base Unit_Operation) | |

| | PAGI |
|---|-----------------|
| 13.3. Circuit Board (Portable) | 92 |
| 13.4. Circuit Board (Charger Unit) | 94 |
| 14 Miscellaneous | 9 |
| 14.1. CPU Data (Base Unit) | 9 |
| 14.2. CPU Data (Portable) | 98 |
| 14.3. How to Replace the Flat Package IC | 100 |
| 14.4. How to Replace the LLP (Leadless Leadframe | Э |
| Package) IC | 102 |
| 14.5. Terminal Guide of the ICs, Transistors and | b |
| Diodes | 104 |
| 15 Exploded View and Replacement Parts List | 10 |
| 15.1. Cabinet and Electrical Parts (Base Unit) | 10 |
| 15.2. Cabinet and Electrical Parts (Portable) | 106 |
| 15.3. Cabinet and Electrical Parts (Charger Unit) | 107 |
| 15.4. Accessories and Packing Materials | 108 |
| 15.5. Replacement Parts List | 11 ⁻ |

1 Safety Precautions

1.1. For Service Technicians

- Repair service shall be provided in accordance with repair technology information such as service manual so as to prevent fires, injury or electric shock, which can be caused by improper repair work.
 - 1. When repair services are provided, neither the products nor their parts or members shall be remodeled.
 - 2. If a lead wire assembly is supplied as a repair part, the lead wire assembly shall be replaced.
 - 3. FASTON terminals shall be plugged straight in and unplugged straight out.
- · ICs and LSIs are vulnerable to static electricity.

When repairing, the following precautions will help prevent recurring malfunctions.

- 1. Cover plastic parts boxes with aluminum foil.
- 2. Ground the soldering irons.
- 3. Use a conductive mat on worktable.
- 4. Do not grasp IC or LSI pins with bare fingers.

2 Warning

2.1. Battery Caution

- 1. Danger of explosion if battery is incorrectly replaced.
- 2. Replace only with the same or equivalent type recommended by the manufacturer.
- 3. Dispose of used batteries according to the manufacturer's Instructions.

2.2. About Lead Free Solder (Pbf: Pb free)

Note:


In the information below, Pb, the symbol for lead in the periodic table of elements, will refer to standard solder or solder that contains lead

We will use PbF solder when discussing the lead free solder used in our manufacturing process which is made from Tin (Sn), Silver (Ag), and Copper (Cu).

This model, and others like it, manufactured using lead free solder will have PbF stamped on the PCB. For service and repair work we suggest using the same type of solder.

Caution


- PbF solder has a melting point that is 50 °F ~ 70 ° F (30 °C ~ 40 °C) higher than Pb solder. Please use a soldering iron with temperature control and adjust it to 700 °F ± 20 ° F (370 °C ± 10 °C).
- Exercise care while using higher temperature soldering irons.:
- Do not heat the PCB for too long time in order to prevent solder splash or damage to the PCB.
- PbF solder will tend to splash if it is heated much higher than its melting point, approximately 1100 °F (600 °C).
- When applying PbF solder to double layered boards, please check the component side for excess which may flow onto the opposite side (See the figure below).



2.2.1. Suggested PbF Solder

There are several types of PbF solder available commercially. While this product is manufactured using Tin, Silver, and Copper (Sn+Ag+Cu), you can also use Tin and Copper (Sn+Cu), or Tin, Zinc, and Bismuth (Sn+Zn+Bi). Please check the manufacturer's specific instructions for the melting points of their products and any precautions for using their product with other materials.

The following lead free (PbF) solder wire sizes are recommended for service of this product: 0.3 mm, 0.6 mm and 1.0 mm.



2.3. Discarding of P. C. Board

When discarding P. C. Board, delete all personal information such as telephone directory and caller list or scrap P. C. Board.

KX-TG9391T/KX-TG9392T/KX-TGA939T

3 Specifications

■ Standard:

DECT 6.0 (Digital Enhanced Cordless

Telecommunications 6.0)

■ Number of channels:

60 Duplex Channels

■ Frequency range: 1.92 GHz to 1.93 GHz

■ Duplex procedure:

TDMA (Time Division Multiple Access)

■ Channel spacing:

1,728 kHz

■ Bit rate:

1,152 kbit/s

■ Modulation:

GFSK (Gaussian Frequency Shift Keying)

■ RF transmission power:

115 mW (Max.)

■ Voice coding:

ADPCM 32 kbit/s

| | Base Unit | Portable | Charger |
|------------------------------|--|--|--|
| Power source | AC Adaptor | Rechargeable Ni-MH battery | AC Adaptor |
| | (PQLV207T, 120 V AC, 60 Hz) | AAA (R03) size (1.2 V 630 mAh) | (PQLV209T, 120 V AC, 60 Hz) |
| Receiving Method | Super Heterodyne | Super Heterodyne | |
| Oscillation Method | PLL synthesizer | PLL synthesizer | |
| Detecting Method | Quadrature Discriminator | Quadrature Discriminator | |
| Tolerance of OSC Frequency | 13.824 MHz ±100 Hz | 13.824 MHz ±100 Hz | |
| Modulation Method | Frequency Modulation | Frequency Modulation | |
| ID Code | 40 bit | 40 bit | |
| Ringer Equivalence No. (REN) | 0.1B | | |
| Dialing Mode | Tone (DTMF)/Pulse | Tone (DTMF)/Pulse | |
| Redial | Up to 48 digits | Up to 48 digits | |
| Speed Dialer | Up to 24 digits (Phonebook) | Up to 24 digits (Phonebook) | |
| Power Consumption | Standby: Approx. 1.1 W | 11 days at Standby, | Standby: Approx. 0.6 W, |
| | Maximum: Approx. 2.0 W | 5 hours at Talk | Maximum: Approx. 3.6 W |
| Operating Conditions | 5 °C - 40 °C (41 °F – 104 °F) | 5 °C - 40 °C (41 °F – 104 °F) | 5 °C - 40 °C (41 °F – 104 °F) |
| | 20 % – 80 % relative air humidity | 20 % – 80 % relative air humidity | 20 % – 80 % relative air humidity |
| | (dry) | (dry) | (dry) |
| Dimensions (H x W x D) | Approx. 127mm×216 mm×155 mm | Approx. 156 mm \times 49 mm \times 32 mm | Approx. 51 mm × 75 mm × 88 mm |
| | $(5 \times 8^{-1}/2" \times 6^{-3}/32")$ | $(6^{1}/8" \times 1^{15}/16" \times 1^{1}/4")$ | $(2" \times 2^{15}/_{16}" \times 3^{15}/_{32}")$ |
| Mass (Weight) | Approx. 720 g (1.59 lb) | Approx. 130 g (0.29 lb) | Approx. 60 g (0.13 lb) |

Note:


Note for service:

• Optional headset: KX-TCA60, KX-TCA86, KX-TCA92, KX-TCA93, KX-TCA94, KX-TCA95

[•] Design and specifications are subject to change without notice.

4 Technical Descriptions

4.1. Block Diagram (Base Unit)



4.2. Circuit Operation (Base Unit)

4.2.1. **Outline**

Base unit consists of the following ICs as shown in **Block Diagram (Base Unit)** (P.7).

- DECT BBIC (Base Band IC): IC501
 - Handling all the audio, signal and data processing needed in a US DECT base unit
 - Controlling the US DECT specific physical layer and radio section (Burst Module Controller section)
 - ADPCM code filter for speech encoding and speech decoding (DSP section)
 - Echo-cancellation and Echo-suppression (DSP section)
 - Any tones (tone, sidetone, ringing tone, etc.) generation (DSP section)
 - DTMF receiver (DSP section)
 - Clock Generation for RF Module
 - ADC, DAC, timer, and power control circuitry
 - All interfaces (ex: RF module, EEPROM, LED, Analog Front End, etc.)
- RF Module: IC801
 - PLL Oscillator
 - Detector
 - Compress/Expander
 - First Mixer
 - Amplifier for transmission and reception
- EEPROM: IC551
 - Temporary operating parameters (for RF, etc.)
- FLASH MEMORY 1: IC761
 - Voice Prompt (TAM) D/L Area
 - ICM/OGM/MEMO Recording Area
- TAM Companion: IC701
 - Voice data compression and decompression
 - Speaker Amp
- Additionally,
 - Power Supply Circuit (+4.0 V, +3.3 V, +2.5 V, +1.8 V output)
 - Crystal Circuit (10.368 MHz)
 - Charge Circuit
 - Telephone Line Interface Circuit
- FLASH MEMORY 2: IC561
 - Program DL
- LED Driver: IC641
- LCD Driver: IC641
- · Key Matrix: IC631
- Handset Amplified
 - MIC Amp: IC441
 - Receiver Amp: IC451
 - Analog sw: IC431

4.2.2. Power Supply Circuit

The power is supplied to the DECT BBIC, RF Module, EEPROM, TAM Companion, OP Amp, and Charge Contact from AC Adaptor (+6.5 V) as shown in Fig.101. The power supply is as follows;

• DECT BBIC (IC501):

```
CN301 (+6.5 V) \rightarrow F301 \rightarrow D301\rightarrow IC311 \rightarrow IC326 \rightarrow D382 \rightarrowQ386 \rightarrow IC501 CN301 (+6.5 V) \rightarrow F301 \rightarrow D301\rightarrow IC311 \rightarrow IC326 \rightarrow D382 \rightarrowQ381 \rightarrow IC501
```

• RF Module (IC801):

CN301 (+6.5 V) \rightarrow F301 \rightarrow D301 \rightarrow IC311 \rightarrow IC321 \rightarrow IC801 (PLL) (Power AMP)

• EEPROM (IC551)/FLASH MEMORY 1 (IC761)/FLASH MEMORY 2 (IC561)/Latch (IC631/641)/OP Amp (IC441/451): Analog SW (IC431)

CN301 (+6.5 V) \to F301 \to D301 \to IC311 \to IC326 \to D382 \to Q381 \to IC761, IC561, IC431, IC631, IC641, IC411, IC451, IC551

• TAM Companion (IC701):


```
CN301 (+6.5 V) \to F301 \to D301 \to IC311 \to IC326 \to D382 \to IC701 CN301 (+6.5 V) \to F301 \to D301 \to IC311 \to IC326 \to D382 \to Q386 \to IC701 CN301 (+6.5 V) \to F301 \to D301 \to IC311 \to IC326 \to D382 \to Q381 \to IC701
```

• OP Amp (IC161, IC261):

CN301 (+6.5 V) \rightarrow F301 \rightarrow D301 \rightarrow IC311 \rightarrow IC336 \rightarrow IC161/IC261

• OP Amp (IC171):

 $\text{CN301 (+6.5 V)} \rightarrow \text{F301} \rightarrow \text{D301} \rightarrow \text{IC311} \rightarrow \text{IC331} \rightarrow \text{IC171}$



KX-TG9391T/KX-TG9392T/KX-TGA939T

4.2.3. Telephone Line Interface

Note:

[]: Line 2

<Function>

- · Bell signal detection
- · Clip signal detection
- · ON/OFF hook circuit

Bell & Clip (: Calling Line Identification Presentation: Caller ID) signal detection:

In the standby mode, Q101 [Q201] is open to cut the DC loop current and decrease the ring load.

When ring voltage appears at the L1T (A) [L2T (C)] and L1R (B) [L2R (D)] leads (when the telephone rings), the AC ring voltage is transferred as follows:

ON/OFF hook circuit:

In the standby mode, Q101 [Q201] is open, and connected as to cut the DC loop current and to cut the voice signal. The unit is consequently in an **on-hook condition**.

When IC501 detects a ring signal or press the TALK Key onto the portable, Q103 [Q203] turns on and then Q101, PC102, Q102 [Q201, PC202] turns on, thus providing an **off-hook condition** (DC current flows through the circuit) and the following signal flow makes the loop current.

 $A \ [C] \rightarrow D101 \ [D201] \rightarrow Q101 \ [Q201] \rightarrow Q191 \ [-] \rightarrow Q131 \ [Q231] \rightarrow R124 \ [R224] \rightarrow R125 \ [R225] \rightarrow D125 \ [D225] \rightarrow Q102 \ [-] \rightarrow D101 \ [D201] \rightarrow B \ [D]$

4.2.4. Transmitter/Receiver

· Audio Circuits and DTMF tone signal circuits.

Base unit and portable mainly consist of RF Module and DECT BBIC.

Base unit and portable transmit/receive voice signal and data signal through the antenna on carrier frequency.

Signal Path:

*Refer to Signal Route (P.14).

4.2.4.1. Transmitter Block

The voice signal input from the TEL LINE interface goes to RF Module (IC801) through DECT BBIC (IC501) as shown in **Block Diagram (Base Unit)** (P.7)

The voice signal passes through the analog part of IC501 where it is amplified and converted to a digital audio stream signal. The burst switch controller processes this stream performing encryption and scrambling, adding the various other fields to produce the GAP (**G**eneric **A**ccess **P**rofile) standard DECT frame, assigning to a time slot and channel etc.

In IC801, the carrier frequency is changing, and frequency modulated RF signal is generated and amplified, and radiated from antenna. Portable detects the voice signal or data signal in the circuit same as the following explanation of Receiver Block.


4.2.4.2. Receiver Block

The signal of 1900 MHz band (1920 MHz \sim 1930 MHz) which is input from antenna is input to IC801 as shown in **Block Diagram (Base Unit)** (P.7).

In IC801, the signal of 1900 MHz band is downconverted to 864 kHz signal and demodulated, and goes to IC501 as GAP (Generic Access Profile) standard DECT frames. It passes through the decoding section burst switch controller where it separates out the frame information and performs de-encryption and de-scrambling as required. It then goes to the DSP section where it is turned back into analog audio. This is amplified by the analog front end, and goes to the TEL LINE Interface.

KX-TGA939 BLOCK DIAGRAM (PORTABLE)

4.3. Block Diagram (Portable)



11

4.4. Circuit Operation (Portable)

4.4.1. Outline

Portable consists of the following ICs as shown in Block Diagram (Portable) (P.11).

- DECT BBIC (Base Band IC): IC1
 - All data signals (forming/analyzing ACK or CMD signal)
 - All interfaces (ex: Key, Detector Circuit, Charge, DC/DC Converter, EEPROM, LCD, RF Power Amp.)
 - PLL Oscillator
 - Detector
 - Compress/Expander
 - Reception
- RF Power Amp: IC801
 - Amplifier for transmission
- EEPROM: IC3
 - Temporary operating parameters (for RF, etc.)


4.4.2. Power Supply Circuit/Reset Circuit

Circuit Operation:

When power on the Portable, the voltage is as follows;

BATTERY(2.2 V ~ 2.6 V: BATT+) \rightarrow F1 \rightarrow Q2 (1.8 V), IC1-43pin (2.5V)

The Reset signal generates IC1 (61 pin) and 1.8 V.



4.4.3. Charge Circuit

Circuit Operation:

When charging the portable on the Base Unit, the charge current is as follows;

 $DC+(6.5 \text{ V}) \rightarrow R57 \rightarrow D22 \rightarrow R56 \rightarrow R55 \rightarrow CHARGE+(Base) \rightarrow CHARGE+(Portable) \rightarrow L4 \rightarrow Q4 \rightarrow D7 \rightarrow F1 \rightarrow BAT-TERY+... \ Battery...$

 $\mathsf{BATTERY-} \to \mathsf{L8} \to \mathsf{R45} \to \mathsf{GND} \to \mathsf{L5} \to \mathsf{CHARGE-}(\mathsf{Portable}) \to \mathsf{CHARGE-}(\mathsf{Base}) \to \mathsf{GND} \to \mathsf{DC-}(\mathsf{GND})$

In this way, the BBIC on Portable detects the fact that the battery is charged.

The charge current is controlled by switching Q9 of Portable.

Refer to Fig.101 in Power Supply Circuit (P.9).

4.4.4. Battery Low/Power Down Detector

Circuit Operation:

"Battery Low" and "Power Down" are detected by BBIC which check the voltage from battery.

The detected voltage is as follows;

· Battery Low

Battery voltage: V(Batt) ≤ 2.25 V ± 50 mV

The BBIC detects this level and " starts flashing.

Power Down

Battery voltage: V(Batt) ≤ 2.0 V ± 50 mV

The BBIC detects this level and power down.


4.4.5. Speakerphone

The hands-free loudspeaker at SP+ and SP- is used to generate the ring alarm.

4.5. Circuit Operation (Charger Unit)


4.5.1. Power Supply Circuit

The power supply is as shown.




AC Adaptor


4.6. Signal Route




```
SIGNAL
                                                                ROUTE
SIGNAL ROUTE
                              IN -
                                                                                                        OUT
                       (BASE UNIT)
Base Unit
                       SP-PHONE TX
(to Tel Line)
                       MIC (-) - C723 - R723- IC701 (31)
                       -IC501 (100) - R142 - R141 - C128 - Q131- Q191 - D105 - Q101 - D101 — A
                       Line 2
                      -IC501 (110) - C246 - T246 (1) - T246 (4) - R228 - C228 - Q231 -Q201 - D201 -
Base Unit
                       (BASE UNIT)
SP-PHONE RX
                       Line 1
                       A __ D101 - Q101 - D105 - Q191 - R121 - C121 - R120 - IC501 (102) -
(from Tel Line)
                       Line 2
                       C __ D201 - Q201 - R221 - C221 - R241 -T241 (4)
                                - T241 (1) - C243 - IC431(13) - IC431 (14) - R427 - C427 - R428 - IC501 (118) -
                       IC501 (94) - IC701 (9) __ IC701 (16) - L746 - L742 - SP (-)
                                             LIC701 (14) - L745 - L741 - SP (+)
Portable
                        (PORTABLE)
                        MIC(+) - L10 - C11 - RA4 - IC1(20) - IC1(77) - IC801(4) - IC801(9) - L802 - MIC(-) - L11- C13- RA4- IC1(19) - IC801(3) - IC801(3)
SP-PHONE TX
(to Tel Line)
                         L804 - C812 - D801 - C801 - C803 - DA1 R107- ANT1 to BASE UNIT
                                                                          R108 - ANT2 to BASE UNIT
                        (BASE UNIT)
                                                                 T D801 - C809 - IC801 (31) - IC801 (16) - IC501 (26) -
                        from PORTABLE - ANT1 - R812 - C803 -
                                           — ANT2 - R811 - C802 🖳
                        Line 1
                        IC501 (100) - R142 - R141 - C128 - Q131 - Q191 - D105 - Q101 - D101 -
                    ı
                                                                                                L_B
                    1
                        Line 2
                      L IC501 (110) - C246 - T246 (1) - T246 (4) - R228 - C228 - Q231 - Q201 - D201 -
                        (BASE UNIT) [ ]: Line 2
Portable
                        A [C] - C153 [C253] - R153 [R253] - IC161 (6) [IC261 (6)] — IC161 (7) [IC261 (7)] -
SP-PHONE RX
(from Tel Line)
                        B [D] - C158 [C258] - R156 [R256] - IC161 (5) [IC261 (5)]
                        R167 [R268] - IC501 (101) [IC501 (114)] - IC501 (28) -
                        IC801 (18) T IC801(21) - R809 - C803 - R812 - ANT2 to PORTABLE IC801(2) - R801 - C802 - R811 - ANT1 to PORTABLE
                       (PORTABLE)
                       from BASE UNIT - ANT1 - R107 TDA1
                                          ANT2 - R108 -
                                                      C832 - IC1(3) | IC1(33) - SP(+)
C833 - IC1(2) | IC1(35) - SP(-)
                       - C803 - C801 - D802 - C826
```



Powered




Power Failed



5 Location of Controls and Components


5.1. Controls

5.1.1. Base Unit



- Corded handset
- Receiver
- Speaker
- **④** [LINE 1] LINE1 indicator
- (LINE 2) LINE2 indicator
- (HOLD)
- @ [REDIAL] [PAUSE]
- (FLASH) [CALL WAIT]
- O Display
- Soft keys
- **MIC** (Microphone)
- Dial keypad ([*]: TONE)
- (SP-PHONE) (Speakerphone) SP-PHONE indicator
- ([ERASE]
- (STOP) (EXIT)
- ([ANSWER SELECT]
- (B) ANSWER ON indicator
- ([ANSWER ON]
- ([LOCATOR] [INTERCOM]
- ② Navigator key ([▲]/[▼]/[↦]) VOL. (Volume: [▲]/[▼])

5.1.2. Portable



- Speaker
- Soft keys
- Headset jack
- **②** [**↑**] (TALK)
- **⑤** [♣] (SP-PHONE: Speakerphone)
- O Dial keypad ([*]: TONE)
- (FLASH) [CALL WAIT]
- 3 Charge indicator Ringer indicator
- Receiver
- Display
- ① [OFF]
- (PAUSE) [REDIAL]
- (HOLD) [INTERCOM]
- Microphone
- (6) Charge contacts

6 Installation Instructions


6.1. Connections

6.1.1. Connecting the AC Adaptor/Corded Handset

Connect the AC adaptor cord (1) by pressing the plug firmly (2). Connect the corded handset cord (3) to the corded handset and the base unit.


Base unit

• Use only the supplied Panasonic AC adaptor PQLV207T or PQLV219T.



Charger

 Use only the supplied Panasonic AC adaptor PQLV209T or PQLV219T.



Note:

- The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)
- The AC adaptor should be connected to a vertically oriented or floor-mounted AC outlet. Do not connect the AC adaptor to a ceiling-mounted AC outlet, as the weight of the adaptor may cause it to become disconnected.

During a power failure

The base unit will work as a standard telephone using power from the telephone line. Line 1 on the corded handset can be used to make and answer calls. The base unit speakerphone and the cordless handset will not function during a power failure.


6.1.2. Connecting the Telephone Line Cord

Refer to one of the following methods depending on your situation:

- To connect to a 2-line telephone jack
- To connect to 2 single-line telephone jacks
- If you use the unit as a single-line telephone only


Connect the telephone line cord until it clicks into the base unit and telephone line jack.

To connect to a 2-line telephone jack



To 2-line telephone jack (RJ14C)


To connect to 2 single-line telephone jacks



If you use the unit as a single-line telephone only

Be sure to connect the telephone line cord to LINE 1/2 to allow usage of the unit during a power failure.

Change the line selection mode from "Auto" to "Line1".



To single-line telephone jack (RJ11C)

Note:

 "Check tel line 2" is displayed on the unit. To erase it, see Error Messages (P.28)

KX-TG9391T/KX-TG9392T/KX-TGA939T

If you subscribe to a DSL/ADSL service


Please attach a DSL/ADSL filter (contact your DSL/ADSL provoder) to the telephone line between the base unit and the telephone line jack in the event of the following:

- -noise is heard during conversations.
- -Caller ID features do not function properly.

To connect to a 2-line telephone jack


For this connection, please purchase a Panasonic 2-line splitte.

Example: DSL/ADSL line is line 2



To connect to 2 single-line telephone jacks

Example: DSL/ADSL line is line 2



6.2. Battery


6.2.1. Battery Installation and Replacement

Important:

- Use only the supplied rechargeable batteries (Part No. HHR-55AAABU).
- · When installing the batteries:
- -Wipe the battery ends (①, ②) with a dry cloth.
- -Avoid touching the battery ends (\bigoplus, \bigcirc) or the unit contacts.
- -Confirm correct polarities (⊕, ⊝).
- · When replacing the batteries:
- -USE ONLY rechargeable Ni-MH batteries AAA (R03) size.
- -Do NOT use Alkaline/Manganese/Ni-Cd batteries.
- -We recommend using the panasonic rechargeable batteries HHR-4DPA.
- 1 Press the notch on the handset cover firmly and slide it in the direction of the arrow.



2 Insert the batteries negative (⊕) end first. Close the handset cover.



Note:

• When replacing batteries, remove the old batteries.



Attention:



A nickel metal hydride battery that is recyclable powers the product you have purchased. Please call 1-800-8-BATTERY (1-800-822-8837) or information on how to recycle this battery.

6.2.2. Battery Charge

Place the portable on the base unit or charger for about 7 hours before initial use.

When charging, "Charging" is displayed and the charge indicator on the portable lights up.

When the batteries are fully charged, "Charge Completed" is displayed.

Charger



Note:

- It is normal for the portable to feel warm during charging.
- If you want to use the portable immediately, charge the batteries for at least 15 minutes.
- Clean the charge contacts of the portable and charger with a soft, dry cloth. Clean if the unit is exposed to grease, dust, or high humidity.

6.2.3. Battery Level

| Battery icon | Battery level |
|--------------|---|
| •••• | High |
| | Medium |
| | LowWhen flashing: Needs to be charged. |
| | Empty |

Note:

 The batteries need to be charged if the portable beeps while you are engaged in a call or operating the answering system remmotely.

6.2.4. Panasonic Ni-MH Battery Performance (supplied batteries)

| Operation | Operating time | |
|----------------------|----------------|--|
| In continuous use | 12 hours max. | |
| Not in use (standby) | 6 days max. | |

Note

- Actual battery performance depends on a combination of how often the handset is in use and how often it is not in use (standby).
- Even after the handset is fully charged, the handset can be left on the charger without any ill effect on the batteries.
- The battery level may not be displayed correctly after you replace the batteries. In this case, place the handset on the charger and let it charge for at least 7 hours.

7 Operating Instructions

7.1. Programmable settings

You can customize the unit by programming the following features.

To access the features, there are 2 methods:

- scrolling through the display menus.
- using the direct commands.

Programming by scrolling through the display menus

Base unit / Portable

- 1 (MENU)
- 2 Proceed with the operation for your unit.

 Base unit: Press [▼], [▲], [◄◄], or [►►I] to select the desired main menu. → [SELECT]

 Handset: Press [▼], [▲], [◄], or [►] to select the desired menu. → [SELECT]
- 3 Press [\mathbf{v}] or [\mathbf{A}] to select the desired item in sub-menu 1. \longrightarrow [SELECT]
 - In some cases, you may need to select from sub-menu 2. → [SELECT]
- **4** Press [v] or [A] to select the desired setting. \longrightarrow [SAVE]
 - This step may vary depending on the feature being programmed
 - To exit the operation, press **[■]**(EXIT) on the base unit or **[OFF]** on the handset.

Note:

• See Programming using the direct commands for the default settings. Base unit

| Menu | Sub-menu 1 | Sub-menu 2 |
|---|--------------------------|-------------------|
| View Caller ID | - | _ |
| → 3 | | |
| Phonebook | _ | _ |
| | | |
| Set answering | Record greeting | Line1&Line2 |
| | Record greeting | Line1 |
| <u> </u> | | Line2 |
| | Play greeting | Line1&Line2 |
| | riay greeting | Line1 |
| | | Line2 |
| | Ring count ^{*1} | |
| | Recording time*1 | _ |
| | Remote code*1 | _ |
| | Call screening | _ |
| Ringer settings | Ringer volume | Linel |
| J | | Line2 |
| | Ringer tone | Linel |
| | | Line2 |
| | Interrupt tone | _ |
| | Night mode | Start/End |
| | | On/Off |
| Initial settings | Set date & time | Date and time *1 |
| % | | Time adjustment*1 |
| | Contrast | - |
| | Line select | - |
| | Set tel line | Caller ID edit |
| | | Set dial mode*1 |
| | | Set flash time*1 |
| | | - Line1 |
| | | - Line2 |
| | | Set line mode*1 |
| | | - Line1 |
| | | VM tone detect*1 |
| | Change language | Display language |
| | | Voice prompt*1 |
| Customer support | _ | |
| 79 | | |
| <u> • </u> | | |

^{*1} If you program these settings using the base unit, you do not need to program the same item using a handset.

Portable

| Menu | Sub-menu 1 | Sub-menu 2 |
|------------------|-----------------|-----------------------------|
| View Caller ID | _ | _ |
| →] | | |
| Phonebook | _ | _ |
| \square | | |
| Answering device | Play new msg. | _ |
| | Play all msg. | _ |
| മ | Erase all | |
| | Settings | Ring count*1 |
| | becerngs | Recording time*1 |
| | | Remote code*1 |
| | | Call screening |
| Ringer settings | Ringer volume | Line1 |
| | 3 | Line2 |
| • | Ringer tone | Line1 |
| | | Line2 |
| | Interrupt tone | _ |
| | Night mode | Start/End |
| | | On/Off |
| Initial settings | Set date & time | Date and time*1 |
| 2=9 | | Alarm |
| ~ | | Time adjustment |
| | Contrast | _ |
| | Key tone | _ |
| | Auto talk | _ |
| | Line select | _ |
| | Set tel line | Caller ID edit |
| | | Set dial mode ^{*1} |
| | | Set flash time*1 |
| | | - Line1 |
| | | - Line2 |
| | | Set line mode *1 |
| | | - Line1 |
| | | - Line2 |
| | | VM tone detect*1 |
| | Registration | HS registration |
| | | Deregistration |
| | Change language | Display language |
| G | | Voice prompt*1 |
| Customer support | _ | _ |
| ?₿ | | |

^{*1} If you program these settings using one of the handsets, you do not need to program the same item using another unit.

Cross Reference:

 $\begin{tabular}{ll} \textbf{Programming using the Direct Commands} & (P.24) \end{tabular}$

7.1.1. Programming using the Direct Commands

- 1 [MENU] \rightarrow [\ddagger]
- 2 Enter the desired feature code.
- 3 [v]/[A]: Select the desired setting. \rightarrow [SAVE]
 - This step may vary depending on the feature being programmed.
 - To exit the operation, press [**II**](EXIT) on the base unit or [OFF] on the portable.

Note:

- The operating unit column shows the unit(s) that can be used to program the item.
 - (In): Only the base unit can program the item.
 - Only the portable can program the item.
 - *I* Both the base unit and portable can program the item.
- In the following table, < > indicates the default settings.

| Operating unit | Feature | Feature code | Setting | System setting*1 |
|----------------|--|--------------|---------------------|------------------|
| ₽ | Alarm | [7][2][0] | <off></off> | _ |
| | | | Once | |
| | | | Daily | |
| ₽ | Auto talk*2 | [2][0][0] | On | _ |
| | | | <off></off> | |
| IN A | Caller ID edit | [2][1][4] | <0n> | _ |
| | (Caller ID number auto edit) | | Off | |
| 10010 | Call screening | [3][1][0] | <0n> | - |
| | | | Off | |
| Star 1 E | Contrast (Display contrast) | [1][4][5] | Level 1–6 <3> | _ |
| 10010 | Customer support | [6][8][0] | _ | - |
| 10010 | Date and time | [1][0][1] | _ | • |
| ₽ | Deregistration | [1][3][1] | _ | - |
| 100 1 Q | Display language | [1][1][0] | <english></english> | - |
| | | | Español | |
| Ø | Erase all (Erasing all messages) | [3][2][5] | _ | _ |
| ₽ | HS registration (Handset registration) | [1][3][0] | - | _ |
| 10010 | Interrupt tone*3 | [2][0][1] | <on></on> | _ |
| | | | Off | |
| Ø | Key tone*4 | [1][6][5] | <on></on> | - |
| | | | Off | |
| 110 10 | Line select | [2][5][0] | <auto></auto> | _ |
| | | | Line1 | |
| | | | Line2 | |
| III Q | Night mode | [2][3][8] | On | _ |
| | (On/Off) | | <off></off> | |

| Operating unit | Feature | Feature code | Setting | | System setting*1 |
|----------------|---|--------------|-------------------------------|--|------------------|
| 100 1 Q | Night mode (Start/End) | [2][3][7] | <11:00 PM/06:00 AM> | | _ |
| 10010 | Phonebook | [2][8][0] | | _ | _ |
| ₽ | Play all msg. | [3][2][4] | | _ | _ |
| 150 | Play greeting | [3][0][3] | | _ | _ |
| Ø | Play new msg. | [3][2][3] | | _ | _ |
| 100 | Record greeting | [3][0][2] | | _ | _ |
| III I P | Recording time | [3][0][5] | 1min 2min <3min> | | • |
| 10010 | Remote code | [3][0][6] | <111> | | • |
| /## F | Ring count | [2][1][1] | Toll sav 2-7 rings | | • |
| fin D | Ringer tone*5,*6 | [1][6][1] | Line 1 Line 2 | Line 1: <tone 1=""> Line 2: <tone 2=""> Base unit: Tone 1-3 Melody 1-3 Handset: Tone 1-5 Melody 1-10</tone></tone> | _ |
| film & | Ringer volume*7 | [1][6][0] | Line 1 Line 2 | Base unit: Level 1-<3>, Off Handset: Level 1-<6>, Off | _ |
| In 12 | Set dial mode | [1][2][0] | <tone></tone> | | • |
| Star 1 47 | Set flash time ^{*8} | [1][2][1] | Line 1 Line 2 | 80ms 90ms 100ms 110ms 160ms 200ms 250ms 300ms 400ms 600ms <700ms>900ms | • |
| SEE LE | Set line mode *9 | [1][2][2] | Line 1 Line 2 | A | • |
| Ing Q | Time adjustment*10 (Caller ID subscribers only) | [2][2][6] | <caller Manual</caller | ID[auto]> | • |
| 10018 | View Caller ID | [2][1][3] | _ | | |
| May 1 D | VM tone detect | [3][3][2] | <on> Off</on> | | • |
| IND Q | Voice prompt | [1][1][2] | <english> Español</english> | | |

- *1 If "System setting" column is checked, you do not need to program the same item using another unit.
- *2 If you subscribe to Caller ID service and want to view the caller's information after lifting up the handset to answer a call, turn off this feature.
- *3 This tone lets you know when you receive an outside call while you are on the other line or an intercom call. If you select "on", the tone sounds 2 times.
- *4 Turn this feature off if you prefer not to hear key tones while you are dialing or pressing any keys, including confirmation tones and error tones.
- *5 If you subscribe to a distinctive ring service (such as IDENTA-RING), select a tone (base unit: tone 1 to 3/handset: tone 1 to 5). If you select a melody, you cannot distinguish lines by their ringers.
- *6 If you select one of the melody ringer tones, the ringer tone will continue to play for several seconds even if the caller has already hung up. You may either hear a dial tone or no one on the line when you answer the call
- *7 When the ringer volume is turned off, $\cancel{\mathbb{Z}}$ is displayed followed by the selected line number(s) and the base unit and/or handset do not ring for outside calls.
- *8 The flash time depends on your telephone exchange or host PBX. Contact your PBX supplier if necessary. The setting should stay at "700ms" unless pressing [FLASH] fails to pick up the waiting call.
- *9 Generally, the line mode setting should not be adjusted. If the LINE1 indicator or LINE2 indicator does not light when another phone connected to the same line is in use, you need to change the line mode to "A".
- *10This feature allows the unit to automatically adjust the date and time setting when caller information is received. To use this feature, set the date and time first.

KX-TG9391T/KX-TG9392T/KX-TGA939T

7.1.2. Answering System Settings

| Setting (default setting) | Remarks (Selectable options) |
|-------------------------------------|------------------------------|
| Answering system on/off (Answer On) | Answer On/Answer Off |
| Remote access code (111) | 000~999 |
| Number of rings (4 Rings) | Toll saver/2 to 7 Rings |
| Caller's recording time (3 Minutes) | 1 Minute/2 Minutes/3 Minutes |
| Call screening (On) | On/Off |

7.2. Registering a Portable to the Base Unit

The supplied handset and base unit are pre-registered. If for some reason the handset is not registered to the base unit, register the handset.

1 Portable:

 $[MENU] \rightarrow [\ddagger][1][3][0]$

2 Base unit:

Press and hold **[LOCATOR]** for 5 seconds until the registration tone sounds.

- If all registered handsets start ringing, press the same button to stop. Then repeat this step.
- The next step should be completed within 90 seconds.

3 Portable:

Press [OK], then wait until a long beep sounds.

Note:

• When you purchase an additional handset, refer to the additional handset's installation manual for registration.

7.2.1. Deregistering a Portable

A handset can cancel its own registration (or the registration of another handset) that is stored in the base unit. This allows the handset to end its wireless connection with the system.

Portable

- 1 [MENU] \rightarrow [\pm][1][3][1]
- 2 [3][3][5] \rightarrow [OK]
- 3 Select the handset you want to cancel by pressing the desired handset(s) number.
 - The selected handset number(s) flashes.
 - To cancel a selected handset number, press the number again. The number will stop flashing.
- 4 [OK] \rightarrow [\checkmark]/[\land]: "Yes" \rightarrow [SELECT]
 - When you cancel a different handset than the one you are now using, press [OFF] to exit.

7.3. Copying Phonebook Entries

You can copy phonebook entries from the base unit to a portable or vice versa.

Important:

- Group ringer tones are not copied.
- You cannot copy the phonebook entries between portables.

7.3.1. Copying All Entries

/ Base unit

- 1 $[\ \] \rightarrow [MENU]$
- 2 [v]/[A]: "Copy all" \rightarrow [SELECT]
- **3** [▼]/[▲]: Enter the handset number to copy to.
 - When all entries have been copied, "Completed" is displayed.
- 4 [■] (EXIT)

Portable

- 1 $[MENU] \rightarrow [\ddagger][2][8][0] \rightarrow [MENU]$
- 2 [\mathbf{v}]/[\mathbf{A}]: "Copy all to base" \rightarrow [SELECT]
 - When all entries have been copied, "Completed" is displayed.
- 3 [OFF]

7.4. Dialing Mode

If you cannot make calls, change this setting according to your telephone line service.

The default setting is "Tone".

"Tone": For tone dial service.

"Pulse": For rotary/pulse dial service.

Program this setting using either the base unit or one of the handsets.

Base unit / Portable

- 1 [MENU] \rightarrow [\pm][1][2][0]
- **2** [▼]/[▲]: Select the desired setting.
- 3 [SAVE]
- 4 Proceed with the operation for your unit.

Base unit: [■] (EXIT) Handset: [OFF]

7.5. Error Messages

If the unit detects a problem, one of the following messages is shown on the display.

| Display message | Cause/solution |
|--|--|
| Busy | The called handset or base unit is in use. |
| | Other units are in use and the system is busy. Try again later. |
| | Privacy mode is on for the call you tried to join. |
| | The handset you are using is too far from the base unit. Move closer and try again. |
| | The handset's registration may have been canceled. Re-register the handset. |
| Check tel line 1 Check tel line 2 | The supplied telephone line cord has not been connected yet or not connected properly. Check the connections. |
| | If you use the unit as a single-line telephone only, erase the message as follows: |
| | To erase "Check tel line 1", press [MENU]. \rightarrow [\ddagger][1][8][9] |
| | To erase "Check tel line 2", press [MENU]. \rightarrow [\ddagger][1][9][0] |
| | When a power failure occurs, the message is displayed again. Erase again as above. |
| Error!! | The handset's registration has failed. Move the base unit and handset away from all electrical appliances and try again. Recording was too short. Try again. |
| Failed | Phonebook copy failed. Confirm the other unit (the receiver) is in standby mode and try again. |
| Incomplete | Phonebook copy is incomplete. The receiver's phonebook memory is full. Erase the unnecessary phonebook entries from the other unit (the receiver) and try again. |
| Memory full | The phonebook memory is full. Erase unnecessary entries. |
| | Message memory is full. Erase unnecessary messages. |
| Messages full | Message memory is full. Erase unnecessary messages. |
| No link to base. | The handset has lost communication with the base unit. Move closer |
| Reconnect AC adaptor. | to the base unit and try again. |
| | Unplug the base unit's AC adaptor to reset the unit. Reconnect the |
| | adaptor and try again. |
| | The handset's registration may have been canceled. Re-register the handset. |
| Use rechargeable battery. | A wrong type of batteries such as Alkaline or Manganese was inserted. Use only the rechargeable Ni-MH batteries. |
| You must first subscribe to Caller ID. | You must subscribe to Caller ID service. Once you receive caller information after subscribing to Caller ID service, this message will not be displayed. |

7.6. Troubleshooting

If you still have difficulties after following the instructions in this section, disconnect the base unit's AC adaptor, then reconnect the base unit's AC adaptor. Remove the batteries from the portable, and then insert the batteries into the portable again.

General use

| Problem | Cause/solution | |
|----------------------------|--|--|
| The unit does not work. | Make sure the batteries are installed correctly. Fully charge the batteries. Check the connections. Unplug the base unit's AC adaptor to reset the unit. Reconnect the adaptor and try again. The handset has not been registered to the base unit. Register the handset. | |
| I cannot hear a dial tone. | The base unit's AC adaptor or telephone line cord is not connected. Check the connections. If you are using a splitter to connect the unit, remove the splitter and connect the unit to the wall jack directly. If the unit operates properly, check the splitter. Disconnect the base unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your service provider/telephone company. | |
| ♥ is flashing. | The handset has not been registered to the base unit. Register the handset. The handset is too far from the base unit. Move closer. The base unit's AC adaptor is not connected. Check the connections. You are using the base unit or handset in an area with high electrical interference. Re-position the base unit and use the handset away from interference sources. | |

Programmable settings

| Problem | Cause/solution |
|--|--|
| I have changed the display language to a language I cannot read. | Change the display language. |
| While programming, the unit starts to ring. | A call is being received. Answer the call and start again after hanging up. |
| I cannot register a handset to a base unit. | The maximum number of handsets (6) is already registered to the base unit. Cancel unused handset registrations from the base unit. |
| | Place the handset and the base unit away from other electrical appliances. |

Battery recharge

| Problem | Cause/solution |
|--|---|
| The handset beeps and/or I flashes. | Battery charge is low. Fully charge the batteries . |
| I fully charged the batteries, but still flashes or is displayed. | Clean the charge contacts and charge again.It is time to replace the batteries. |
| I fully charged the batteries, but the operating time seems to be shorter. | Clean the battery ends (⊕, ⊖) and the charge contacts with a dry cloth, and charge again. |

Making/answering calls, intercom

| Problem | Cause/solution |
|---|---|
| Noise is heard, sound cuts in and out. | You are using the base unit or handset in an area with high electrical interference. Re-position the base unit and use the handset away from sources of interference. Move closer to the base unit. If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details. |
| The base unit and/or handset does not ring. | The ringer volume is turned off. Adjust the ringer volume.Night mode is turned on. Turn it off. |
| I cannot make a call. | The dialing mode may be set incorrectly. Change the setting. The handset is too far from the base unit. Move closer and try again. |
| I cannot make long distance calls. | Make sure that you have long distance service. |

Caller ID

| Problem | Cause/solution |
|--------------------------------------|--|
| Caller information is not displayed. | You must subscribe to Caller ID service. Contact your service provider/telephone company for details. |
| | If your unit is connected to any additional telephone equipment such as a Caller ID box or cordless telephone line jack, plug the unit directly into the wall jack. If you use a DSL/ADSL service, we recommend connecting a DSL/ADSL filter between the base unit and the telephone line jack. Contact your DSL/ADSL provider for details. |
| | The name display service may not be available in some areas. Contact your service provider/telephone company for details. |
| | Other telephone equipment may be interfering with this unit. Disconnect the other equipment and try again. |

| Problem | Cause/solution |
|---|---|
| Caller information is displayed late. | Depending on your service provider/telephone company, the unit may display the caller's information at 2nd ring or later. Move closer to the base unit. |
| The caller list/incoming phone numbers are not edited automatically. | The Caller ID number auto edit feature is turned off. Turn it on and try again. You need to call back the edited number to activate Caller ID number auto edit. |
| I cannot dial the phone number edited in the caller list. | The phone number you dialed might have been edited incorrectly (for example, the long distance "1" or the area code is missing). Edit the phone number with another pattern. |
| Time on the unit is shifted. | Incorrect time information from incoming Caller ID changes the time. Set the time adjustment to "Manual" (off). |
| The 2nd caller's information is not displayed during an outside call. | In order to use Caller ID, call waiting, or Call Waiting Caller ID (CWID), you must first contact your service provider/telephone company and subscribe to the desired service. |
| | After subscribing, you may need to contact your service provider/telephone company again to activate this specific service, even if you already subscribed to both Caller ID and Call Waiting with Caller ID services (CWID). |

Answering system

| Problem | Cause/solution |
|--|---|
| The unit does not record new messages. | The answering system is not turned on for the line you wish to record messages from. Select the desired line or both lines, then turn the answering system on. The message memory is full. Erase unnecessary messages. The answering system is activated for both lines, and the 1st caller is leaving a voice message. The 2nd caller cannot leave a message, but the caller information will be stored. If you subscribe to the voice mail service, messages are recorded by your service provider/telephone company not your telephone. Change the unit's number of rings setting or contact your service provider/telephone company. |
| I cannot operate the answering system. | Someone is using the unit. Wait for the other user to finish. A caller is leaving a message. Wait for the caller to finish. The handset is too far from the base unit. Move closer. |
| I cannot operate the answering system remotely. | You are entering the wrong remote access code. If you forgot the remote access code, store a new remote access code. Press each key firmly. The answering system is turned off. Turn it on. You are using a rotary/pulse telephone. Try again using a touch-tone phone. |
| While recording a greeting message or listening to messages, the unit rings and recording stops. | A call is being received. Answer the call and try again later. |

Liquid damage

| Problem | Cause/solution |
|---|--|
| Liquid or other form of moisture has entered the base unit/handset. | Disconnect the AC adaptor and telephone line cord from the base unit. Remove the batteries from the handset and leave to dry for at least 3 days. After the base unit/handset are completely dry, reconnect the AC adaptor and telephone line cord. Insert the batteries and charge fully before use. |

Caution

• To avoid permanent damage, do not use a microwave oven to speed up the drying process.


8 Service Mode

8.1. Engineering Mode

8.1.1. Base Unit

Important:

Make sure the address on LCD is correct when entering new data. Otherwise, you may ruin the unit.



B/U key operation


1). Press " MENU " (middle soft key).




BACK SELECT


- 2). Enter "7", "2", "6", "2", "7", "6", "6", "4".

 Note: 7262 7664 = PANA SONI
 - (see letters printed on dial keys)
- 3). Select "Write EEPROM" by Navigator key.
- 4). Press "SELECT" (middle soft key).
- 5). Enter "●", "●", "●", "●" (Address). (*2)










6). Enter "*", "*" (New Data). (*2)



7). Press " **OK** " (middle soft key).

A long confirmation beep will be heard.



8). Press "[(STOP) (EXIT) " to return to standby mode.

After that, turn the base unit power off and then power on.

Frequently Used Items (Base Unit)

ex.)

| Items | Address(*1) | Default Data | New Data | | Remarks |
|-----------|-------------|--------------|----------|---|---|
| Frequency | 00 01 | 75 | - | - | Use these items in a READ-ONLY mode to confirm |
| ID | 00 10~00 14 | Given value | - | - | the contents. Careless rewriting may cause serious |
| | | | | | damage to the computer system. |

Note:


(*1) When you enter the address or New Data, please refer to the table below.

| Desired Number (hex.) | Input Keys | Desired Number (hex.) | Input Keys |
|-----------------------|------------|-----------------------|-------------|
| 0 | 0 | A | [FLASH] + 0 |
| 1 | 1 | В | [FLASH] + 1 |
| · | • | С | [FLASH] + 2 |
| | · | D | [FLASH] + 3 |
| | • | E | [FLASH] + 4 |
| 9 | 9 | F | [FLASH] + 5 |

8.1.2. Portable

Important:

Make sure the address on LCD is correct when entering new data. Otherwise, you may ruin the unit.



H/S key operation

H/S LCD


1). Press "MENU" (middle soft key).



2). Enter "7", "2", "6", "2", "7", "6", "6", "4".

Note: 7262 7664 = PANA SONI

(see letters printed on dial keys)




3). Select "Write EEPROM" by Navigator key.




4). Press "SELECT" (middle soft key).



5). Enter "●", "●", "●", "●" (Address). (*1)



6). Enter " * ", " * " (New Data). (*1)



7). Press " **OK** " (middle soft key). A long confirmation beep will be heard.



8). Press " [OFF] " to return to standby mode.
After that, remove and reinsert the batteries.
Press the Power button for about 1 second if the power is not turned on.

Frequently Used Items (Portable)

ex.)

| Items | Address | Default Data | New Data | Possible Adjusted Value MAX (hex) | Possible Adjusted Value MIN (hex) | Remarks |
|-------------|-------------|--------------|----------|--------------------------------------|--------------------------------------|---------|
| Battery Low | 00 04 | 70 | - | - | - | |
| Frequency | 00 01~00 02 | F6 02 | - | - | - | (*2) |
| ID | 00 10~00 14 | Given value | - | - | - | |

Note:

(*1) When you enter the address or New Data, please refer to the table below.

| Desired Number (hex.) | Input Keys | Desired Number (hex.) | Input Keys |
|-----------------------|------------|-----------------------|-------------|
| 0 | 0 | A | [FLASH] + 0 |
| 1 | 1 | В | [FLASH] + 1 |
| | | С | [FLASH] + 2 |
| | • | D | [FLASH] + 3 |
| | • | E | [FLASH] + 4 |
| 9 | 9 | F | [FLASH] + 5 |

(*2) Use these items in a READ-ONLY mode to confirm the contents. Careless rewriting may cause serious damage to the portable.


8.2. Copying Phonebook Items when Repairing

You can copy the base unit (Maximum number of contacts is 100.) phonebook to another (compatible Panasonic) portable. This will help to save the original phonebook data which the customer has registered.


* You cannot copy the base unit phonebook to another base unit.


Available models: KX-TG9391/KX-TG9392

Refer to the following procedures.



Case 1: A base unit has a defect.
(Replacing a base unit PCB etc...)







Register P (A) to BS (B).
 P (A) is normal, therefore no need to copy the phonebook data.

Case 2: A base unit has a defect.

(Replacing both a base unit and a portable)






- 1. Register P (A) to BS (B) as a handset no. 2.
- Copy the phonebook data from P (A) to BS (B) then copy the phonebook data from BS (B) to P (B).
- 3. Cancel the P 2 (P (A)).

Note:

- BS=Base Unit , P=Portable
- If the max number of portables are already registered to the base unit, a new portable cannot be registered.
- To register the portable, refer to Registering a Portable to the Base Unit (P.27)
- To cancel the portable, refer to Deregistering a Portable (P.27)
- To copy the portable phonebook, refer to Copying Phonebook Entries (P.27)


Case 3: A Portable has a defect.


(Radio transmission is functioning.)



- 1. Cancel P (A).
- 2. Register P (B) as a handset no. 1.
- 3. Register P (A) as a handset no. 2.
- 4. Copy the phonebook data from P (A) to BS (A) then copy the phonebook data from BS (A) to P (B).
- 5. Cancel P 2 (P (A)).

Case 4: A portable has a defect.
(Radio transmission is functioning.)





- 1. Register P (A) as a portable no. 2.
- 2. Copy the phonebook data from P (A) to BS (B) then copy the phonebook data from BS (B) to P (B).
- 3. Cancel P 2 (P (A)).

Note:

- BS=Base Unit , P=Portable
- If the max number of portables are already registered to the base unit, a new portable cannot be registered.
- To register the portable, refer to **Registering a Portable to the Base Unit** (P.27)
- To cancel the portable, refer to **Deregistering a Portable** (P.27)
- To copy the portable phonebook, refer to Copying Phonebook Entries (P.27)

8.3. How to Clear User Setting


Units are reset to the Factory settings by this operation (Erase recorded voice messages, stored Phone numbers, Caller list and etc.)

Note:

- Some menus are not reset. Refer to Operating Instructions (P.22).
- The reset menus differ depending on the following operations.
- This operation should not be performed for a usual repair.

8.3.1. Resetting both base unit and portable

Both the base unit and the registered portable which you did the following steps ① to ④ are reset. Other registered portables will not be reset.




- (1) Connect the AC adaptor to the base unit and install the charged batteries into the portable.
- ② Confirm the handset is registered to the base unit (♥ lights).
 If the portable is not registered to the base unit (♥ is flashing), register it. (*1)
- (3) Lift the portable and press [OFF] to put the portable in standby mode.
- 4 Press 1, 5, 9 and \times key of the portable simultaneously until a confirmation tone is heard.
- 5 Disconnect the AC adaptor, then remove the battery.

Note:

(*1) Refer to Registering a Portable to the Base Unit (P.27).

8.3.2. Resetting only portable

The only portable is reset by doing the following steps ① to ④.



- 1 Install the charged batteries into the Portable.
- (2) Lift the portable and press (OFF) to put the portable in standby mode.
- (3) Press (3), (5), (7) and (#) key of the portable simultaneously until a confirmation tone is heard. (*2)
- 4 Remove the battery.


Note: (*2)

- The portable registration to the base unit is cancelled.
- If the portable needs to be registered to the base unit, refer to Registering a Portable to the Base Unit (P.27).
- If users do not bring the base unit with them, the registration procedure has to be done by users themselves.

9 Troubleshooting Guide

9.1. Troubleshooting Flowchart


Flow Chart



9.1.1. Check Power

9.1.1.1. Base Unit

Is the AC Adaptor inserted into AC outlet? (*1)




Cross Reference:

Power Supply Circuit (P.9)

Note:

(*1) Refer to **Specifications** (P.6) for part number and supply voltage of AC adaptor.

9.1.1.2. Portable




Cross Reference:

Power Supply Circuit/Reset Circuit (P.12)

9.1.2. Check Battery Charge

9.1.2.1. Portable




Cross Reference:

Check Power (P.40)

Charge Circuit (P.12)

9.1.2.2. Charger Unit




Cross Reference:

Power Supply Circuit (P.9)

9.1.3. Check Link

9.1.3.1. Base Unit



Cross Reference:


Power Supply Circuit (P.9)

Check Point (Base Unit) (P.52)

Note:

(*1) Refer to Troubleshooting by Symptom (Base Unit and Charger Unit) (P.52).

KX-TG9391T/KX-TG9392T/KX-TGA939T




Cross Reference:

Check Point (Base Unit) (P.52)

KX-TG9391T/KX-TG9392T/KX-TGA939T

9.1.3.2. Portable




Cross Reference:

Power Supply Circuit/Reset Circuit (P.12)

Check Point (Portable) (P.56)

Note:

(*1) Refer to Troubleshooting by Symptom (Portable) (P.56).



Cross Reference:

Check Point (Portable) (P.56)


9.1.4. Check the RF part

9.1.4.1. Finding out the Defective part

- 1. Prepare Regular P (Portable) and Regular BU (Base unit).
- 2. a. Re-register regular P (Normal mode) to Base Unit (to be checked).
 - If this operation fails in some ways, the Base Unit is defective.
 - b. Re-register Portable (to be checked) to regular BU (Normal mode). If this operation fails in some ways, the Portable is defective.

After All the Checkings or Repairing

1. Re-register the checked Portable to the checked Base Unit, and Regular P to Regular BU.




Note:

If you need to register a Portable, refer to Registering a Portable to the Base Unit (P.27)50

9.1.4.2. RF Check Flowchart

Each item (1 \sim 4) of RF Check Flowchart corresponds to **Check Table for RF part** (P.48). Please refer to the each item.



Note:

- (*1) Base unit refer to (H) of Check Point (Base Unit) (P.52)
- (*2) Portable refer to (J) of Check Point (Portable) (P.56)

KX-TG9391T/KX-TG9392T/KX-TGA939T


9.1.4.3. Check Table for RF part

| No. | Item | BU (Base Unit) Check | P (Portable) Check |
|-----|------------------------------|--|---|
| 1 | Link Confirmation Normal | Register Regular P to BU (to be checked). (*1) Press [Talk] key of the Regular HS to | 1. Register P (to be checked) to Regular BU. (*1) 2. Press [Talk] key of the P to establish link. |
| 2 | Control signal confirmation | establish link. 1. Check BBIC interface. (*2) | Check BBIC interface. (*2) |
| | · · | ` ' | ` , |
| 3 | X'tal Frequency confirmation | Check X'tal Frequency. (*3) (10.368 MHz ± 100 Hz) | 1. Check X'tal Frequency. (*4) (10.368 MHz ±100 Hz) |
| 4 | Range Confirmation Normal | Register Regular P to BU (to be checked). (*1) | Register P (to be checked) to Regular BU. (*1) |
| | | Press [Talk] key of the Regular P to establish link. | Press [Talk] key of the P to establish link. Compare the range of the P (being) |
| | | Compare the range of the BU (being checked) with that of the Regular BU. | checked) with that of the Regular P. |


Note:

- (*1) Refer to Registering a Portable to the Base Unit (P.27)
- (*2) Refer to RF-BBIC Interface Signal Wave Form (P.49)
- (*3) Refer to Adjustment Standard (Base Unit) (P.69)
- (*4) Refer to Adjustment Standard (Portable) (P.73)

9.1.4.4. RF-BBIC Interface Signal Wave Form




9.1.5. Check Portable Transmission



Cross Reference: Signal Route (P.14)

9.1.6. Check Portable Reception



Cross Reference:

How to Check the Portable Speaker or Receiver (P.77). Signal Route (P.14)

9.1.7. Check Caller ID


Check Caller ID in Signal Route.

Cross Reference:


Signal Route (P.14)

9.1.8. Bell Reception

9.1.8.1. Base Unit



9.1.8.2. Portable




Cross Reference:

Telephone Line Interface (P.10)

Check Link (P.42)

How to Check the Portable Speaker or Receiver (P.77)

9.1.9. Check TAM Operation




Cross Reference:

Power Supply Circuit (P.9)

Note:


(*1) When replacing FLASH MEMORY 1 (IC761), TAM data needs to be written to it. Refer to **Base Unit** (P.74) of **Things to Do after Replacing IC**.

9.1.10. Check SP-phone Transmission



Cross Reference: Signal Route (P.14)

9.1.11. Check SP-phone Reception



Cross Reference: Signal Route (P.14)

9.2. Troubleshooting by Symptom (Base Unit and Charger Unit)

9.2.1. Check Point (Base Unit)

Please follow the items below when BBIC, EEPROM or FLASH is replaced.

Note:

After the measuring, suck up the solder of TP.

*: **PC Setting** (P.67) is required beforehand.

The connections of simulator equipments are as shown in Adjustment Standard (Base Unit) (P.69).

| (A) | Items | Check Point | Procedure | Check or |
|---------------|--------------------------------|----------------|---|------------------------------------|
| (A) | 101/0 | | | Replace Parts |
| (A) | | TP4V | 1. Confirm that the voltage between test point TP4V and GND is $4.0 \text{ V} \pm 0.2 \text{ V}$. | IC311, Q311, |
| | 4.0 V Supply Confirma- tion | 1740 | 1. Commit that the voltage between test point 1P4V and GND is 4.0 V ± 0.2 V. | R311, R312, |
| | | | | R313, D311, L311, C315 |
| (B) | 3.6 V Supply Confirma- | TP3.6 V | 1. Confirm that the voltage between test point TP3.6 V and GND is 3.3 V \pm 0.2 V. | IC326, C326, |
| (-) | tion | | | C327 |
| (C) | 2.5 V Supply Confirma- tion | TP2.5 V | 1. Confirm that the voltage between test point TP2.5 V and GND is 2.5 V ± 0.2 V. | IC321, C321, R322, R321 |
| (D) | 3.0 V Supply Confirma- tion | TP3.0 V | 1. Confirm that the voltage between test point TP3.0 V and GND is 3 V \pm 0.2 V. | Q381, R381, R382, R383, C382 |
| (E) | 1.8 V Supply Confirma- tion | TP1.8 V | 1. Confirm that the voltage between test point TP1.8 V and GND is 1.8 V \pm 0.1 V. | Q386, R386, C388 |
| (F)* | BBIC Confirmation | - | BBIC Confirmation (Execute the command "getchk"). | IC501, X501, |
| | | | Confirm the returned checksum value. | R511, C511, |
| | | | Connection of checksum value and program number is shown below. | C512, IC561, Q502 |
| | | | checksum value program number | Q502 |
| | | | ex.) C8D7 DB01AC | |
| (G)* | EEPROM Confirmation | - | EEPROM Confirmation (Execute the command "ChkTG9391XXrevYY.bat"). | IC551, R552, |
| | | | XX: country code | R553, R554, |
| | | | YY: revision number 2. Confirm the returned checksum value. | C551 |
| | | | The checksum is displayed in the last output line. | |
| | | | Note: | |
| | | | "XX" "YY" and "checksum" vary depending on the country version. You can find them in the batch file, PNZZ- mentioned in JIG and PC (P.67). | |
| (H)* | BBIC Clock Adjustment | CLK | 1. Check X'tal Frequency. (10.368 MHz ± 100 Hz). | IC501, X501, |
| (••) | BBIO Glock / kajadiment | OLIK | Input Command "rdeeprom 00 01 01", then you can confirm the current value. | R511, C511, |
| | | | 2. If the frequency is not 10.368 MHz ± 100 Hz, Adjust the frequency of CLK exe- | C512 |
| | | | cuting the command "setfreq xx (where xx is the value)" so that the reading of | |
| | | | the frequency counter is 10.368000 MHz ± 20 Hz. | |
| (I)* | Hookswitch Check with | - | 1. Connect CN101 (Line 1)/CN201 (Line 2) (Telephone Socket) to Tel-simulator | <line 1=""></line> |
| | DC Characteristics | | which is connected with 600 Ω . | PO101, L101, |
| | | | Set line voltage to 48 V and line current to 40 mA at off-hook condition of nor- mal telephone. | L102, RL185, D101, Q101, |
| | | | 3. Execute the command "hookoff" | R102, PC102, |
| | | | 4. Confirm that the line current is 40 mA ± 5 mA. | Q102, D105, |
| | | | 5. Execute the command "hookon". | Q191, Q131, |
| | | | 6. Confirm that the line current is less than + 0.8 mA. | R124, R125, |
| | | | | D125, C126 |
| | | | | <line 2=""></line> |
| | | | | PO201, L201, |
| | | | | L202, D201, |
| | | | | Q201, D202, PC202, D231, |
| | | | | R224, R225, |
| | | | | D225, C226 |
| (J) | DTMF Generator Check | - | 1. Connect CN101 (Line 1)/CN201 (Line 2) (Telephone Socket) to DTMF tester. | <line 1=""></line> |
| - | | | (Road=600 Ω) | IC501, R141, |
| | | | 2. Link Portable and push dial key. | R142, C128, |
| | | | 3. Confirm DTMF character. | Q131, R136, |
| | | | 4. Confirm that the high Group is -6 dBm ± 2 dBm. | R134, R133 |
| | | | 5. Confirm that the low Group is -8 dBm ± 2 dBm. | <line 2=""> IC501, C246,</line> |
| | | | | T246, R228, |
| | | | | C228, Q231, |
| | | | | R236, R232, |
| | | | | R234, R233 |

| | Items | Check | Procedure | Check or |
|----------------|-------------------------|-------|--|--------------------------------|
| (K)* | Transmitted Power Con- | Point | Remove the Antenna before starting step from 1 to 7. | Replace Parts IC501, IC801, |
| (K) | firmation | - | 1. Configure the DECT tester (CMD60) as follows; | R807, R806, |
| | IIIIIation | | Setting> | R804, R808, |
| | | | • Short A_1 and GND. | C809, D801, |
| | | | • Test mode: FP | R801, R804, |
| | | | Traffic Carrier: 5 | L803, L812, |
| | | | • Traffic Slot: 4 | C802, C811 |
| | | | Mode: Loopback | |
| | | | • PMID: 00000 | |
| | | | • RF LEVEL = -70 dBm. | |
| | | | Execute the command "testmode". | |
| | | | 3. Execute the command "sendchar dmv 2 2". | |
| | | | 4. Check that "Signalling Status" has been set to "Locked", then press "ACCEPT | |
| | | | RFPI". | |
| | | | Initiate connection from Dect tester ("set up connect") | |
| | | | 6. Execute the command "ANT1". | |
| | | | 7. Confirm that the NTP value at ANT is 20 dBm ~ 25 dBm. | |
| (L)* | Modulation Check and | - | Follow steps 1 to 6 of (K). | IC501, IC801, |
| | Adjustment | | 7.Confirm that the B-Field Modulation is -350 ~ -400/+320 ~ +370 kHz/div using | R807, R806, |
| | | | data type Fig31. | R804, R808, |
| | | | 8.Adjust the B-Field Modulation if required. (Execute the command "readmod" | C809, D801, |
| | | | and "wrtmod xx", where xx is the value.) | R801, R804, |
| | | | | L803, L812, |
| /B.B\4 | 5 0% (0) | | | C802, C811 |
| (M)* | Frequency Offset Check | - | Follow steps 1 to 6 of (K) . | IC501, IC801, |
| | | | 7.Confirm that the frequency offset is < ± 45 kHz. | R807, R806, |
| | | | | R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, L803, L812, |
| | | | | C802, C811 |
| (N)* | Frequency Dirft Confir- | | Follow steps 1 to 6 of (K). | IC501, IC801, |
| (14) | mation | - | 7.Confirm that the frequency drift is < ± 30 kHz/ms. | R807, R806, |
| | mation | | 7. Committe that the frequency unit is < 1.50 km2/ms. | R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, |
| | | | | L803, L812, |
| | | | | C802, C811 |
| (O)* | Sensitivity Receiver | - | Follow steps 1 to 6 of (K). | IC501, IC801, |
| ` ′ | Confirmation | | 7.Set DECT tester power to -90 dBm. | R807, R806, |
| | | | 8.Confirm that the BER is < 1000 ppm. | R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, |
| | | | | L803, L812, |
| | | | | C802, C811 |
| (P)* | Timing Confirmation | - | Follow steps 1 to 6 of (K). | IC501, IC801, |
| | | | 7.Confirm that the Timing accuracy is < ± 2.0 ppm. | R807, R806, |
| | | | | R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, |
| | | | | L803, L812, |
| <u> </u> | D0011 10 5 11 | | | C802, C811 |
| (Q)* | RSSI Level Confirmation | - | Follow steps 1 to 6 of (K). | IC501, IC801, |
| | | | 7. Execute the command "readrssi". | R807, R806, |
| | | | 8. Confirm that the returned value is 22 ± A (hex). | R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, |
| | | | | L803, L812, |
| / D * | Dower BAMD Confirms | | Follow stops 1 to 6 of (M) | C802, C811 IC501, IC801, |
| (R)* | | - | Follow steps 1 to 6 of (K) . 7.Confirm that Power RAMP is matching. | |
| | tion | | 7. Committed tower RAINE IS Matchilly. | R807, R806, R804, R808, |
| | | | | C809, D801, |
| | | | | R801, R804, |
| | | | | L803, L812, |
| | | | | C802, C811 |
| | | | | C802, C8 |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| | Items | Check Point | Procedure | Check or Replace Parts |
|---------------|----------------------------|----------------|---|--|
| (S) | Audio Check | Point | Link with Portable. Input -45 dBm/1kHz to MIC of Portable. Measure the Level at Line I/F and distortion level. Confirm that the level is -8 dBm ± 2 dBm and that the distortion level is < 5 % at TEL Line (600 Ω Load). Input -20 dBm/1 kHz to Line I/F. Measure the level at Receiver of Portable and distortion level (*Receive volume set to second position from minimum). Confirm that the level is -25 dBm ± 2 dBm and that the distortion level is < 5 % at Receiver (Volume Middle, 150 Ω Load). | Replace Parts <line 1=""> PO101, L101, L102, RL185, D101, Q101, R102, PC102, Q102, D105, Q191, Q131, R124, R125, D125, C126 <line 2=""> PO201, L201, L202, D201, Q201, D202, PC202, D231, R224, R225, D225, C226</line></line> |
| (U)* | TAM Operation Confirmation | - | TAM Confirmation (Execute the command "sendchar_VPI") Confirm the returned Value (Value is "DB07AA 01"). | IC701, IC761, Q772, Q773 |

9.2.2. Check Point (Charger Unit)

| | Items | Check Point | Procedure | Check or Replace Parts |
|--------------|----------------|----------------|--|---------------------------|
| (A) | Charging Check | - | Connect Charge Contact 12 Ω/2 W resistor between charge+ and charge Measure and confirm voltage across the resistor is 3.3 V ± 0.2 V. | R2, R1, R3, R4 |

Note:

After the measuring, suck up the solder of TP.

The connection of adjustment equipment is as shown in Adjustment Standard (Charger Unit) (P.70).

9.3. Troubleshooting by Symptom (Portable)

If your unit has below symptoms, follow the instructions in remedy column. Remedies depend on whether you have DECT tester (*1) or not

Note:

- (*1) A general repair is possible even if you don't have the DECT tester because it is for confirming the levels, such as Acoustic level in detail.
- (*2) Refer to Check Point (Portable) (P.56)

9.3.1. Check Point (Portable)

Please follow the items below when BBIC or EEPROM is replaced.

Note:

After the measuring, suck up the solder of TP.

*: PC Setting (P.71) is required beforehand.

The connections of adjustment equipments are as shown in Adjustment Standard (Portable) (P.73).

| | Items | Check | Procedure | Check or |
|---------------|-------------------------|-------|---|-----------------|
| | | Point | | Replace Parts |
| (A)* | 1.8 V Supply Adjustment | VDD1 | 1. Confirm that the voltage between test point VDD1 and GND is 1.8 V \pm 0.02 V. | IC1, Q2, C48, |
| | | | Execute the command "VDD", then check the current value. | D1, C1, C44, |
| | | | 3. Adjust the 1.8V voltage of VDD1 executing command "VDD XX"(XX is the | R12, C3, R45, |
| | | | value). | C40, C45, F1, |
| | | | | L8 |
| (B)* | BBIC Confirmation | - | BBIC Confirmation (Execute the command "getchk"). | IC1, X1, RA61, |
| | | | Confirm the returned checksum value. | R64, R66 |
| | | | Connection of checksum value and program number is shown below. | |
| | | | checksum value program number | |
| | | | ex.) EB48 DB02AA | |
| (C)* | EEP-ROM Confirmation | - | EEP-ROM Confirmation (Execute the command "ChkTGA939XXrevYY.bat"). | IC1, IC3, |
| | | | XX: country code | R40~R42, |
| | | | YY: revision number | C172 |
| | | | Confirm the returned checksum value. | |
| | | | Note: | |
| | | | "XX", "YY", and "checksum" vary depending on the country version. You can find | |
| | | | them in the batch file, PQZZ- mentioned in JIG and PC (P.71). | |
| (D) | Charge Control Check & | - | 1. Apply 3.5 V between CHG(+) and CHG(-) with DC power supply and set cur- | IC1, Q4 Q9, |
| | Charge Current Monitor | | rent limit to 250 mA. | D7, D8, L4, L5, |
| | Check | | Confirm the indication of "charging" on LCD. | R6, R7, F1, |
| | | | Confirm that the current limit LED of DC power supply is ON/OFF. | C1, C3, R2, |
| | | | Confirm it after waiting over 1 minute at least. | R30, R31, R8, |
| | | | 3. Decrease current limit of DC power supply to 100 mA. | C147, R45, |
| | | | Confirm that the current limit LED of DC power supply is stable. (Current limiter is ON.) | C15, L8 |
| | | | (If charge control cannot be confirmed by this procedure, please use battery to porta- | |
| | | | ble power supply and try again.) | |
| (E)* | Charge Detection (OFF) | - | 1. Stop supplying 3.5 V to CHG (+) and CHG (-). | IC1, Q4 Q9, |
| | Check | | Confirm the indication of "charging" has been cleared. | D7, D8, L4, L5, |
| | | | | R6, R7, F1, |
| | | | | C1, C3, R2, |
| | | | | R30, R31, R8, |
| | | | | C147, R45, |
| | | | | C15 |

| | Items | Check Point | Procedure | Check or Replace Parts |
|--------------|------------------------------------|----------------|--|--|
| (F)* | Battery Monitor Check | - | 1. Apply 2.25 V between BATT+ and BATT- 2. Execute the command sendchar PAD sendchar LED 0 sendchar CRX 0 1 sendchar AD1 It assumes that the return value is XX. a) 6c ≤ XX ≤ 71: No need to adjust b) XX: 6A ~ 6B: Need to adjust XX: 72 ~ 74: Need to adjust Write AD value of 2.25 V to EEPROM. ex) read data: XX = 6A, write data: YY = 6A read data: XX = 73, write data: YY = 73 EEPROM = 0004(Low Voltage) write "YY" Execute the command "wreeprom 00 04 01 YY". EEPROM = 0005(No Voltage) write "YY - 1D" Execute the command "×wreeprom 00 05 01 ZZ". EEPROM = 000A(Low Voltage BL) write "YY - 16" Execute the command "wreeprom 00 0A 01 WW". Note: ZZ = YY - C No Voltage writing data limit is '00'. c) XX: 00 ~ 69: Reject | IC1, F1, C1 C3, R12, R45 |
| (2) | D # 1 0 # | | XX: 75 ~ FF: Reject | 101 51 01 |
| (G) | Battery Low Confirma- tion | - | Apply 2.40 V between BATT+ and BATT Confirm that there is no flashing of Battery Icon. Apply 2.25 V ± 0.08 V between BATT+ and BATT Confirm that there is flashing of Battery Icon. | IC1, F1, C1 C3, R12, R45 |
| (H)* | BBIC Clock Adjustment | CLK | Apply 2.6 V between BATT+ and BATT- with DC power. Input Command "sendchar sfr", then you can confirm the current value. Check X'tal Frequency. (10.368 MHz ± 100 Hz). If the frequency is not 10.368 MHz ± 100 Hz, adjust the frequency of CLK executing the command "sendchar sfr xx xx (where xx is the value)" so that the reading of the frequency counter is 10.368000 MHz ± 5 Hz. Note: Clear the registered information for Base Unit before measurement, because the Frequency will not possibly get stable due to the registered information. Pressing the button of "3" "7" "9" "#" clears the registration. Register to it on Base Unit after measurement. | IC1, X1, C47 |
| (I)* | Transmitted Power Confirmation | - | Remove the Antenna before starting step from 1 to 4. 1. Configure the DECT tester (CMD60) as follows; | IC1, C808~C814, L802~L804, C825, C834, C819, IC801, R107, R108, C117, C118, C841, C125, C842, DA1, C801~C804, D801,D802, C837, C826, C822, C820, C832, C833, R801~R807 |
| (J)* | Modulation Check and Adjustment | - | Follow steps 1 to 3 of (K) . 4.Confirm that the B-Field Modulation is -370±30/ +370±30 kHz/div & Modulated width ≥ 690 kHz using data type Fig 31. | IC1, C808~C814, L802~L804, C825, C834, C819, IC801, R107, R108, C117, C118, C841, C125, C842, DA1, C801~C804, D801,D802, C837, C826, C822, C820, C832, C833, R801~R807 |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| | Items | Check | Procedure | Check or |
|---------------|--------------------------|-------|--|----------------|
| | Romo | Point | 110004410 | Replace Parts |
| / K * | Frequency Offset Confir- | - | Follow steps 1 to 3 of (I). | IC1, |
| (r C) | - | - | , ,, | |
| | mation | | 4.Confirm that the frequency Offset is < ± 50 kHz. | C808~C814, |
| | | | | L802~L804, |
| | | | | C825, C834, |
| | | | | C819, IC801, |
| | | | | R107, R108, |
| | | | | C117, C118, |
| | | | | C841, C125, |
| | | | | C842, DA1, |
| | | | | C801~C804, |
| | | | | D801,D802, |
| | | | | C837, C826, |
| | | | | C822, C820, |
| | | | | C832, C833, |
| | | | | |
| /1 \4 | 5 5 5 | | | R801~R807 |
| (L)* | Frequency Drift Confir- | - | Follow steps 1 to 3 of (I). | IC1, |
| | mation | | 4.Confirm that the frequency Drift is < ± 35 kHz/ms. | C808~C814, |
| | | | | L802~L804, |
| | | | | C825, C834, |
| | | | | C819, IC801, |
| | | | | R107, R108, |
| | | | | C117, C118, |
| | | | | C841, C125, |
| | | | | C842, DA1, |
| | | | | C801~C804, |
| | | | | D801,D802, |
| | | | | |
| | | | | C837, C826, |
| | | | | C822, C820, |
| | | | | C832, C833, |
| | | | | R801~R807 |
| $(M)^*$ | Sensitivity Receiver | - | Follow steps 1 to 3 of (I). | IC1, |
| | Confirmation | | 4.Set DECT tester power to -88 dBm. | C808~C814, |
| | | | 5.Confirm that the BER is < 1000 ppm. | L802~L804, |
| | | | •• | C825, C834, |
| | | | | C819, IC801, |
| | | | | R107, R108, |
| | | | | C117, C118, |
| | | | | C841, C125, |
| | | | | C842, DA1, |
| | | | | |
| | | | | C801~C804, |
| | | | | D801,D802, |
| | | | | C837, C826, |
| | | | | C822, C820, |
| | | | | C832, C833, |
| | | | | R801~R807 |
| (N)* | Power RAMP Confirma- | - | Follow steps 1 to 3 of (I). | IC1, |
| ' | tion | | 4.Confirm that Power RAMP is matching. | C808~C814, |
| | | | | L802~L804, |
| | | | | C825, C834, |
| | | | | C819, IC801, |
| | | | | R107, R108, |
| | | | | |
| | | | | C117, C118, |
| | | | | C841, C125, |
| | | | | C842, DA1, |
| | | | | C801~C804, |
| | | | | D801,D802, |
| | | | | C837, C826, |
| | | | | C822, C820, |
| | | | | C832, C833, |
| | | | | R801~R807 |
| (0) | Audio Check and Confir- | | Link to BASE which is connected to Line Simulator. | IC1, R23, C12, |
| (0) | mation | - | | |
| | mation | | 2. Set line voltage to 48 V and line current to 40 mA. | D19, D20, |
| | | | 3. Input -45 dBm/1KHz to MIC and measure Line output level. | C96, C97, |
| | | | 4. Confirm that the level is -8 dBm ± 2 dBm and that the distortion level is < 5% at | |
| | | | TEL Line (600 Ω Load). | RA4, C11, |
| | | | 5. Input -20 dBm/1KHz to Line I/F and measure Receiving level at REV+ and | |
| | | | REV | D4, L10, L11, |
| | | | 6. Confirm that the level is -22 dBm ± 2 dBm and that the distortion level is < 5% | MIC, L9 |
| | | | at Receiver. (vol = 2) | |
| | | | · · · | ļ |

| | Items | Check Point | Procedure | Check or Replace Parts |
|--------------|---|----------------|---|---|
| (P) | SP phone Audio Check and Confirmation | - | Link to Base which is connected to Line Simulator. Set line voltage to 48 V and line current to 40 mA. Set the portable off-hook using SP-Phone key. Input -25 dBm/1KHz to Line I/F and measure Receiving level at SP+ and SP Confirm that the level is -14 dBm ± 2 dBm and that the distortion level is < 5%. (vol = 3) | IC1, R23, C12, C73, D13, D14, R152, C80, L10, L11, MIC, C11, C13, RA4, R27, R28, R208, R209, C96, C97, R215, C72 |
| (Q) | Charge Pump 2.5V Sup- ply Confirmation | CP2.5V | Confirm that the voltage between testpoint and CP2.5V and GND is 2.5V -0.1/ +0.3V. | C52, C53, C49 |
| (R) | Change Pump 4.0V Supply Confirmation | CP4.0V | Confirm that the voltage between testpoint CP4.0V and GND is 4.0V I0.2V. | C50, C51 |

9.3.2. Troubleshooting for Speakerphone

When the customer's telephone line corresponds to the following conditions, and the transmission signal of SP-Phone is interrupted, performing the next set up to a cordless portable will improve it to some extent.

Conditions

- 1. When customer's line has less line loss.
 - ex.) The customer is using optical fiber, ISDN terminal adaptor, or PBX.
 - In this case, receiving signal is strong and it may affect transmission signal.
- 2. When the other party is talking from noisy place.
 - ex.) The other party is using cellular phone. The background noise is very loud.
 - In this case, the noise from the other party (i.e. surrounding noise) may affect transmission signal.

Setting Method

• Change the portable address of EEPROM (0129) from 00 to 01 by Engineering Mode.


10 Disassembly and Assembly Instructions

10.1. Disassembly Instructions


10.1.1. Base Unit

(1) Remove the 5 screws to remove the cabinet cover.

*1~*5 is the order to remove the screws.




(2) Remove 2 screws, then unhook the P.C. Board.




(3) Remove the 3 screws to remove the cabinet cover.

*1~*3 is the order to remove the screws.



(3) Remove the 5 screws to remove the cabinet cover.


*1~*5 is the order to remove the screws.



KX-TG9391T/KX-TG9392T/KX-TGA939T

(5) Remove the hook lever and the 8 screws to remove the operational P.C. Board.


*1~*8 is the order to remove the screws.




10.1.2. Portable

(1) Remove the 2 screws.

- 2 screws
- ② Insert a JIG (PQDJ10006Y) between the cabinet body and the cabinet cover, then pull it along the gap to open the cabinet.




③ Likewise, open the other side of the cabinet.






- (5) Remove the tapes and solders.
- (6) Remove the 2 screws to remove the 2 charge terminals.
- (7) Remove the screw to remove the main P. C. board.



10.1.3. Charger Unit


(1) Remove the screw to remove the cabinet cover.




- 2 Remove the solders to remove the 2 charge terminals.
- (3) Remove the screw to remove the main P.C. board.

10.2. Assembly Instructions

10.2.1. How to Replace the Base unit LCD






(3) Attach the hooks to A.


10.2.2. How to Replace the Portable LCD

- Attach LCD to P.C.B.


 *When attaching the LCD holder,
 don't pull the FPC (Flexible Print Circuit).
- 2 Locate the Flat Cable inside as shown.



Solder the narrow Cable to the P.C.B.
*When soldering, don't give the load to the FPC.



<Details of step 1 above>



11 Measurements and Adjustments

11.1. The Setting Method of JIG (Base Unit)

11.1.1. Preparation

11.1.1.1. Equipment Required

- DECT tester: Rohde & Schwarz, CMD 60 is recommended.
- Frequency counter: It must be precise enough to measure intervals of 1 Hz (precision; ±4 ppm).
 Hewlett Packard, 53131A is recommended.
- Digital multi-meter (DMM): it must be able to measure voltage and current.
- Oscilloscope

11.1.1.2. JIG and PC

Serial JIG

JIG Cable: PQZZ1CD300E*
• PC which runs in DOS mode

• Batch file CD-ROM for setting: PNZZTG9391T

Note:


*: If you have the JIG Cable for TCD500 series (PQZZ1CD505E), change the following values of resistance. Then you can use it as a JIG Cable for both TCD300 and TCD500 series. (It is an upper compatible JIG Cable.)

| Resistor | Old value (kΩ) | New value (kΩ) |
|----------|----------------|----------------|
| R2 | 22 | 3.3 |
| R3 | 22 | 3.3 |
| R4 | 22 | 4.7 |
| R7 | 4.7 | 10 |

11.1.2. PC Setting

11.1.2.1. Connections

- ① Connect the AC adaptor to DC-JACK (base unit).
- 2 Connect the JIG Cable GND (black) to GND.
- 3 Connect the JIG Cable RX (red) to URX and TX (yellow) to UTX.



Base unit P. C. board

Note:

*: COM port names may vary depending on what your PC calls it.

11.1.2.2. Batch file Setting

- **1.** Insert the Batch file CD-ROM into CD-ROM drive and copy PNZZTG**** folder to your PC (example: D drive).
- 2. Open an MS-DOS mode window.

<Example for Windows>

On your computer, click [Start], select Programs (All Programs for Windows XP/Windows Server 2003), then click

MS-DOS Prompt. (for Windows 95/Windows 98)

Accessories-MS-DOS Prompt. (for Windows Me)

Or

Command Prompt. (for Windows NT 4.0)

Or

Accessories-Command Prompt.

(for Windows 2000/Windows XP/Windows Server 2003)

- **3.** At the DOS prompt, type "D:" (for example) to select the drive, then press the **Enter** key.
- **4.** Type "CD ¥PNZZTG****", then press the Enter key.
- Type "SET_COM=X", then press the Enter key
 (X: COM port number used for the serial connection on your PC).
- **6.** Type "READID", then press the Enter key.
 - •If any error messages appear, change the port number or check the cable connection.
 - ·If any value appear, go to next step.
- 7. Type "DOSKEY", then press the Enter key.

- <Example: correct setting>
- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PNZZTG****
- D: ¥PNZZTG**** >SET_COM=X
- D: ¥PNZZTG****>READID
- 00 52 4F A8 A8
- D: ¥PNZZTG****>DOSKEY
- D: ¥PNZZTG****>_
 - <Example: incorrect setting>
- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PNZZTG****
- D: ¥PNZZTG**** >SET COM=X
- D: ¥PNZZTG****>READID CreateFile error

ERROR 10: Can't open serial port

D: ¥PNZZTG ****>_

Note:

• "****" varies depending on the country.

11.1.2.3. Commands


See the table below for frequently used commands.

| Command name | Function | Example |
|-------------------|-------------------------------------|--|
| rdeeprom | Read the data of EEPROM | Type "rdeeprom 00 00 FF", and the data from address "00 00" to "FF" is read out. |
| readid | Read ID (RFPI) | Type "readid", and the registered ID is read out. |
| writeid | Write ID (RFPI) | Type "writeid 00 18 E0 0E 98", and the ID "0018 E0 0E 98" is written. |
| setfreq | Adjust Frequency of RFIC | Type "setfreq nn". |
| hookoff1/hookoff2 | Off-hook mode on Base Line1 & Line2 | Type "hookoff1" for Line1. |
| hookon1/hookon2 | On-hook mode on Base Line1 & Line2 | Type "hookon1" for Line1. |
| getchk | Read checksum | Type "getchk". |
| wreeprom | Write the data of EEPROM | Type "wreeprom 01 23 45". "01 23" is address and "45" is data to be written. |
| bursttx | Burst TX mode | Type "bursttx" |
| textrx | Test RX mode | Type "testrx" |
| tph | High TX mode | Type "tph" |
| tpl | Low TX mode | Type "tpl" |

11.2. Adjustment Standard (Base Unit)

When connecting the simulator equipments for checking, please refer to below.

11.2.1. Bottom View




Note:

(A) - (S) is referred to Check Point (Base Unit) (P.52)

11.3. Adjustment Standard (Charger Unit)

When connecting the simulator equipment for checking, please refer to below.

11.3.1. Bottom View



Note:

(A) is referred to Check Point (Charger Unit) (P.55)

11.4. The Setting Method of JIG (Portable)

11.4.1. Preparation

11.4.1.1. Equipment Required

- DECT tester: Rohde & Schwarz, CMD 60 is recommended.
- Frequency counter: It must be precise enough to measure intervals of 1 Hz (precision; ±4 ppm). Hewlett Packard, 53131A is recommended.
- DC power: it must be able to output at least 1 A current under 2.4 V for Portable.
- Digital multi-meter (DMM): it must be able to measure voltage and current.
- Oscilloscope

11.4.1.2. JIG and PC

Serial JIG

JIG Cable: PQZZ1CD300E*

- · PC which runs in DOS mode.
- Batch file CD-ROM for setting: PNZZTG9391T

Note:


*: If you have the JIG Cable for TCD500 series (PQZZ1CD505E), change the following values of resistance. Then you can use it as a JIG Cable for both TCD300 and TCD500 series. (It is an upper compatible JIG Cable.)

| | Resistor | Old value (kΩ) | New value (kΩ) |
|---|----------|----------------|----------------|
| | R2 | 22 | 3.3 |
| | R3 | 22 | 3.3 |
| ļ | R4 | 22 | 4.7 |
| | R7 | 4.7 | 10 |

11.4.2. PC Setting

11.4.2.1. Connections

- ①Connect the DC Power or Battery to BATT+ and BATT-.
- ②Connect the JIG cable GND (black) to GND.
- 3 Connect the JIG cable UTX (yellow) to UTX and URX (red) to URX.



Note:

*: Com port names may vary depending on what your PC calls it.

11.4.2.2. Batch file Setting

- Insert the Batch file CD-ROM into CD-ROM drive and copy PQZZTG***** folder to your PC (example: D drive).
- 2. Open an MS-DOS mode window.

<Example for Windows>

On your computer, click [Start], select Programs (All Programs for Windows XP/Windows Server 2003), then click

MS-DOS Prompt. (for Windows 95/Windows 98)

Or

Accessories-MS-DOS Prompt. (for Windows Me)

0-

Command Prompt. (for Windows NT 4.0)

Or

Accessories-Command Prompt.

(for Windows 2000/Windows XP/Windows Server 2003)

- **3.** At the DOS prompt, type "D:" (for example) to select the drive, then press the **Enter** key.
- **4.** Type "CD \(\forall \text{PQZZTG*****"}\), then press the **Enter** key.
- **5.** Type "SET RTX_COM=X", then press the Enter key (X: COM port number used for the serial connection on your PC).
- **6.** Type "READID", then press the Enter key.
 - •If any error messages appear, change the port number or check the cable connection.
 - •If any value appear, go to next step.
- **7.** Type "DOSKEY", then press the Enter key.

- <Example: correct setting>
- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PQZZTG*****
- D: ¥PQZZTG***** >SET RTX_COM=X
- D: ¥PQZZTG*****>READID
- 00 52 4F A8 A8
- D: ¥PQZZTG*****>DOSKEY
- D: ¥PQZZTG*****> _
 - <Example: incorrect setting>
- C: ¥Documents and Settings>D:
- D: ¥>CD ¥PQZZTG*****
- D: \text{PQZZTG***** > SET RTX_COM=X}
- D: ¥PQZZTG*****>READID CreateFile error

ERROR 10: Can't open serial port

D: ¥PQZZTG*****> _

Note:

• "****" varies depending on the country.

11.4.2.3. Commands


See the table below for frequently used commands.

| Command name | Function | Example |
|--------------|--------------------------|--|
| rdeeprom | Read the data of FLASH | Type "rdeeprom 00 00 FF", and the data from address "00 00" to "FF" is read out. |
| readid | Read ID (RFPI) | Type "readid", and the registered ID is read out. |
| writeid | Write ID (RFPI) | Type "writeid 00 18 E0 0E 98", and the ID "0018 E0 0E 98" is written. |
| setfreq | Adjust Frequency of RFIC | Type "setfreq nn". |
| getchk | Read checksum | Type "getchk". |
| wreeprom | Write the data of FLASH | Type "wreeprom 01 23 45". "01 23" is address and "45" is data to be written. |
| bursttx | Burst TX mode | Type "bursttx" |
| textrx | Test RX mode | Type "testrx" |
| tph | High TX mode | Type "tph" |
| tpl | Low TX mode | Type "tpl" |

11.5. Adjustment Standard (Portable)

When connecting the simulator equipments for checking, please refer to below.

11.5.1. Component View



Note:

(A) - (R) is referred to Check Point (Portable) (P.56)

KX-TG9391T/KX-TG9392T/KX-TGA939T

11.6. Things to Do after Replacing IC or X'tal

Cautions:

Some of the content on this page may not apply to models from some countries.

11.6.1. Base Unit

Before making the following adjustment, ensure you have carried out **PC Setting** (P.67) in **The Setting Method of JIG (Base Unit)**.

| | Items | Necessary Adjustment |
|-----------------|--|--|
| BBIC (IC501) | Programs for Voice processing, interface for RF and EEPROM | Clock adjustment: Refer to Check Point (D). (*1) |
| EEPROM (IC551) | Adjustment parameter data (country version batch file, default batch file, etc.) | |
| X'tal (X501) | System clock | |

Note:

(*1) Refer to Check Point (Base Unit) (P.52)

11.6.2. Portable

Before making the following adjustment, ensure you have carried out PC Setting (P.71) in The Setting Method of JIG (Portable).

| | Items | Necessary Adjustment |
|--------------|--|--|
| BBIC | Programs for Voice processing, interface for RF | Clock adjustment: Refer to Check Point (F). (*2) |
| (IC1) | and EEPROM | 2. 1.8 V setting and battery low detection: Refer to Check |
| EEPROM (IC3) | Adjustment parameter data | Point (A), (B) and (C). (*2). |
| | (country version batch file, default batch file, | |
| | etc.) | |
| X'tal (X1) | System clock | |

Note:

(*1) Refer to Check Point (Portable) (P.56)

11.7. RF Specification

11.7.1. Base Unit

| Item | Value | Refer to * |
|------------------|--|-----------------------------|
| TX Power | 19 dBm ~ 25 dBm | Check Point (Base Unit) (J) |
| Modulation | $-370\pm30/+370\pm30$ kHz/div & Modulated width \geq 690 kHz | Check Point (Base Unit) (K) |
| Frequency Offset | -50 kHz ~ +50 kHz | Check Point (Base Unit) (L) |
| Frequency Drift | < ± 35 kHz / ms | Check Point (Base Unit) (M) |
| RX Sensitivity | < 1000 ppm | Check Point (Base Unit) (N) |
| Timing Accuracy | < ± 5.0 ppm/<±15.0ppm | Check Point (Base Unit) (O) |
| Power RAMP | Power RAMP is matching | Check Point (Base Unit) (P) |

^{*:} Refer to Check Point (Base Unit) (P.52)


11.7.2. Portable

| Item | Value | Refer to ** |
|------------------|---|---------------------------------|
| TX Power | 19 dBm ~ 25 dBm | Check Point (Portable) (I) |
| Modulation | $-370\pm30/+370\pm30$ kHz/div & Modula width \geq 690 kHz | ated Check Point (Portable) (J) |
| Frequency Offset | -50 kHz ~ +50 kHz | Check Point (Portable) (K) |
| Frequency Drift | < ± 35 kHz / ms | Check Point (Portable) (L) |
| RX Sensitivity | < 1000 ppm | Check Point (Portable) (M) |
| Power RAMP | Power RAMP is matching | Check Point (Portable) (N) |

^{**:} Refer to Check Point (Portable) (P.56)

11.8. How to Check the Portable Speaker or Receiver

- 1. Prepare the digital voltmeter, and set the selector knob to ohm meter.
- 2. Put the probes at the speaker terminals as shown below.



11.9. Frequency Table (MHz)

| Ch. (hex) | TX/RX Frequency (MHz) |
|-----------|--|
| 00 | 1928.448 |
| 01 | 1926.720 |
| 02 | 1924.992 |
| 03 | 1923.264 |
| 04 | 1921.536 |
| 05 | 1919.808 |
| 06 | 1918.080 |
| 07 | 1916.352 |
| 08 | 1914.624 |
| 09 | 1912.896 |
| | 00 01 02 03 04 05 06 07 |

12 Schematic Diagram

12.1. For Schematic Diagram

12.1.1. Base Unit (Schematic Diagram (Base Unit_Main))

Notes:

1. DC voltage measurements are taken with voltmeter from the negative voltage line.

Important Safety Notice:

Components identified by \triangle mark have special characteristics important for safety. When replacing any of these components, use only the manufacturer's specified parts.

2. The schematic diagrams may be modified at any time with the development of new technology.

12.1.2. Portable (Schematic Diagram (Portable))

Notes:

- 1. DC voltage measurements are taken with an oscilloscope or a tester with a ground.
- 2. The schematic diagrams may be modified at any time with the development of new technology.

12.1.3. Charger Unit (Schematic Diagram (Charger Unit))

Notes:

1. DC voltage measurements are taken with voltmeter from the negative voltage line.


Important Safety Notice:

Components identified by \triangle mark have special characteristics important for safety. When replacing any of these components, use only the manufacturer's specified parts.

2. This schematic diagram may be modified at any time with the development of new technology.

Memo


12.2. Schematic Diagram (Base Unit_Main)




KX-TG9391/9392 SCHEMATIC DIAGRAM (Base Unit_Main) (1/4)

KX-TG9391/9392 SCHEMATIC DIAGRAM (Base Unit_Main) (2/4)


81



 $\equiv \equiv$



12.3. Schematic Diagram (Base Unit_Operation)





NC: No Components

KX-TG9391/9392 SCHEMATIC DIAGRAM (Base Unit_Operation)

Memo


12.4. Schematic Diagram (Portable)





NC: No Components KX-TGA939 SCHEMATIC DIAGRAM (Portable_Main)

12.5. Schematic Diagram (Charger Unit)




SCHEMATIC DIAGRAM (Charger Unit)

13 Printed Circuit Board


13.1. Circuit Board (Base Unit_Main)

13.1.1. Component View




KX-TG9391/9392 CIRCUIT BOARD (Base Unit_Main (Component View))

13.1.2. Bottom View



13.2. Circuit Board (Base Unit_Operation)


13.2.1. Component View



91


13.3. Circuit Board (Portable)

13.3.1. Component View



KX-TGA939 CIRCUIT BOARD (Portable_Main (Component View))


13.3.2. Flow Solder Side View



KX-TGA939 CIRCUIT BOARD (Portable_Main (Bottom View))


13.4. Circuit Board (Charger Unit)

13.4.1. Component View



CIRCUIT BOARD (Charger unit (Component View))

13.4.2. Bottom Side View



CIRCUIT BOARD (Charger unit (Bottom View))

14 Appendix Information of Schematic Diagram

14.1. CPU Data (Base Unit)

14.1.1. IC501 (BBIC)

| Pin No. | Description | I/O | Connection | at Normal mode | at Reset mode |
|---------|-------------------------|------------|--------------|----------------|---------------|
| 1 | VDDIO | - | VDDIO | - | - |
| 2 | VSS | - | VSS | - | - |
| 3 | AD8 | D_O | AD8 | O_0/1 | O_0/1 |
| 4 | AD9 | D_O | AD9 | O_0/1 | O_0/1 |
| 5 | AD10 | D_O | AD10 | O_0/1 | O_0/1 |
| 6 | AD11 | D_O | AD11 | O_0/1 | O_0/1 |
| 7 | AD12 | D_O | AD12 | O_0/1 | O_0/1 |
| 8 | AD13 | D_O | AD13 | O_0/1 | O_0/1 |
| | AD14 | D_O | AD14 | O_0/1 | O_0/1 |
| | P3[7]/PD7 | D_O | P3[7] | O_0/1 | O-Hi-Z |
| 11 | P3[1]/PD1 | D_I | P3[1] | I(Digital) | O-Hi-Z |
| | P3[5]/PD5 | D_I | P3[5] | I(Digital) | O-Hi-Z |
| 13 | P3[4]/PD4 | D_O | P3[4] | O_0/1 | O-Hi-Z |
| 14 | P3[3]/PD3 | D_I | P3[3] | I(Digital) | O-Hi-Z |
| 15 | P3[2]/PD2 | D_O | P3[2] | O_0/1 | O-Hi-Z |
| 16 | VDD | | VDD | - | - |
| 17 | VSS | - | VSS | _ | - |
| 18 | RFCLK | D_O | RFCLK | O_0/1 | O-0 |
| 19 | VDDRF | - | VDDRF | - | - |
| 20 | VSSRF | _ | VSSRF | - | - |
| | Xtal1 | A_I | Xtal1 | _ | |
| 22 | ICAP | A_I | CAP | - | <u>'</u> |
| 23 | AVS | | AVS | - | - |
| 24 | AVD | - | AVD | - | - |
| 25 | RSSI | <u>-</u> | RSSI | - | - |
| | RDI | D_I | RDI | I(Digital) | l(dig) |
| 27 | CMPREF | A_I | CMPREF | i(Digital) | I(dig) |
| 28 | TDO | DO/AO | TDO | O(Analog) | Hi-Z(dig) |
| 29 | AD15 | D_O | AD15 | O_0/1 | O-0/1 |
| | AD16 | D_O | AD15 | O_0/1 | O-0/1 |
| | AD17 | D_O | AD17 | O_0/1 | O-0/1 |
| | AD18 | D_O | AD17 | O_0/1 | O-0/1 |
| | AD19 | D_O | AD18 | O_0/1 | O-0/1 |
| | AD20 | D_O | AD19 AD20 | - | O-0/1 |
| 35 | AD21 | D_O | AD20 AD21 | - | O-0/1 |
| | AD21 AD22 | D_O | AD21 | - | O-0/1 |
| 37 | AD23 | | AD23 | - | O-0/1 |
| 38 | LE | D_O D_O | LE | O_0/1 | O-0/1 |
| 39 | SIO | | SIO | I/O(Dig) | O-Hi-Z |
| 40 | | D_0 | SK | | O-ni-2 |
| | SK DAC/ADC2 | D_O | ADC2 | O_0/1 | |
| | DAC/ADC2 | A_I | | I(Ana) | l O Hi 7 |
| | P3[6]/PD6 RDN | D_O D_O | P3[6] RDN | O_0/1 O_0/1 | O-Hi-Z |
| 43 | WRN | | WRN | | O-1 O-1 |
| | | D_0 | | O_0/1 | |
| | MI/READY | D_IPU | READY | I_PU | I-PU |
| | SCLK | D_O | SCLK | O_0/1 | 0-1 |
| 47 | UTX/P0[0] | D_O | UTX | O_0/1 | I-PU |
| 48 | URX/P0[1] | D_I | URX | I(Digital) | I DU |
| 49 | JTIO/P0[2] | D_IPU | JTIO | I/O(Dig) | I-PU |
| 50 | PCM_FSC1/P0[3] | D_I/O | P0[3] | O_0/1 | I-PU |
| | PCM_FSC0/P0[4] | D_I/O | PCM_FSC0 | O_0/1 | I-PU |
| | PCM_CLK/P0[5] | D_I/O | PCM_CLK | O_0/1 | I-PU |
| | PCM_DOUT/P0[6] | D_I/O | PCM_DOUT | O_0/1 | I-PU |
| 54 | PCM_DIN/P0[7] | D_I/O | PCM_DIN | I(Digital) | I-PU |
| 55 | VDDIO | - | VDDIO | - | - |
| 56 | VSS | - | VSS | - | - |
| 57 | DREQ0n/INT0n/P1[0] | D_O | P1[0] | O_0/1 | I-PU |
| 58 | DACK0n/INT1n/P1[1] | D_I | P1[1] | I(Digital) | I-PU |
| 59 | ACS1/DREQ1n/INT2n/P1[2] | D_O | ACS1 | O_0/1 | I-PU |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| Pin No. | Description | I/O | Connection | at Normal mode | at Reset mode |
|--|---|---|--|--|--|
| | ACS0 | D_O | ACS0 | O_0/1 | 0-1 |
| | ACS2/DACK1n/INT3n/P1[3] | D_O | P1[3] | I(Digital) | I-PU |
| | HOLDn/INT4n/P1[4] | D I | P1[4] | I(Dig) | I-PU |
| 63 | VDDE/HOLDACKn/INT5n/P1[5] | D_I/O | P1[5] | I(Dig) | 0-1 |
| | BE1n | D_O | BE1n | O_0/1 | 0-1 |
| | BE0n | D_O | BE0n | O_0/1 | 0-1 |
| | SCL2/P3[0] | D_I/O | SCL2 | O_0/1 | 0-1 |
| | SDA2 | D_I/O | SDA2 | I/O(Dig) | |
| | DAB0 | D_I/O | D0 | O_0/1 | 0-1 |
| | DAB8 | D_I/O | D8 | O_0/1 | 0-1 |
| | DAB1 | D_I/O | D1 | O_0/1 | 0-1 |
| | DAB9 | D_I/O | D9 | O_0/1 | 0-1 |
| | DAB2 | D_I/O | D2 | O_0/1 | 0-1 |
| | DAB10 | D_I/O | D10 | O_0/1 | 0-1 |
| | DAB3 | D_I/O | D3 | O_0/1 | 0-1 |
| | DAB11 | D_I/O | D11 | O_0/1 | 0-1 |
| 76 | VSS | | VSS | - | - |
| 77 | VDD | _ | VDD | _ | - |
| 78 | VDDIO | - | VDDIO | - | - |
| | P2[0]/PWM0/SPIDI | | SPIDI | I(Dig) | 1 |
| | P2[1]/PWM1/SPICLK | D_I/O | SPICLK | O_0/1 | ' |
| | P2[2]/ADC0/CLK100 | D_1/O | ADC0 | I(Ana) | 1 |
| | P2[3]/ADC1 | D_O | Reset_Val | O_0 | 1 |
| | P2[4]/SCL1 | D_O | P2[4] | O_0/1 | 1 |
| | P2[5]/SDA1 | D_O | P2[4] | O_0/1 | <u>'</u> |
| | DAB4 | D_I/O | DAB4 | O_0/1 | O-1 |
| | DAB12 | D_I/O | DAB4 DAB12 | O_0/1 | 0-1 |
| | | | | | _ |
| | DAB5 | D_I/O | DAB5 | O_0/1 | O-1 O-1 |
| | DAB13 | D_I/O | DAB13 | O_0/1 | 0-1 0-1 |
| | DAB6 | D_I/O | DAB6 | O_0/1 | _ |
| | DAB14 | D_I/O | DAB14 | O_0/1 | 0-1 0-1 |
| | DAB7 | D_I/O | DAB7 | O_0/1 | _ |
| | | 7 | DADAE | 0 0/4 | |
| | DAB15 | D_I/O | DAB15 | O_0/1 | 0-1 |
| 93 | ТМ | D_I/O | TM | 0_0 | O-0 |
| 93 94 | TM P2[7]/DC_CTRL/SPIDO | D_I/O D_O | TM SPIDO | O_0 O_0/1 | O-0 O-Hi-Z |
| 93 94 95 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 | D_I/O D_O D_O | TM SPIDO P1[6] | O_0 O_0/1 O_0/1 | O-0 O-Hi-Z I-PD(160k pull down) |
| 93 94 95 96 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 | D_I/O D_O D_O A_I | TM SPIDO P1[6] INT7 | O_0 O_0/1 O_0/1 A_I(160k_PD) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) |
| 93 94 95 96 97 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge | D_I/O D_O D_O A_I D_O | TM SPIDO P1[6] INT7 P2[6] | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 | O-0 O-Hi-Z I-PD(160k pull down) |
| 93 94 95 96 97 98 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING | D_I/O D_O D_O A_I D_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I |
| 93 94 95 96 97 98 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF | D_I/O D_O D_O A_I D_O A_I A_O | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I |
| 93 94 95 96 97 98 99 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT | D_I/O D_O D_O A_I D_O A_I A_O | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I |
| 93 94 95 96 97 98 99 100 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ | D_I/O D_O D_O A_I D_O A_I A_O A_O A_O | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I |
| 93 94 95 96 97 98 99 100 101 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I |
| 93 94 95 96 97 98 99 100 101 102 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_O A_I A_I A_I A_I A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I A_O A_I A_I A_I A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O O I I O O O I I O O O O |
| 93 94 95 96 97 98 99 100 101 102 103 104 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I A_O A_I A_I A_I A_I A_I A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I O-1 O-0 I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ | O_0 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O I I I I O O I I I I O O I I I I O O I I I I O O I I I I O O O I I I I O O O I I I I I O O O I I I I I O O O I I I I I O O O I I I I I O O O I I I I I O O O I I I I I O O O I I I I I I O O O I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I I O-1 O-0 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 | D_I/O D_O D_O A_I D_O A_I A_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 | O_0 O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O I I I I O O O I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I I O-1 O-0 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF | D_I/O D_O D_O A_I D_O A_I A_O A_I A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O O I I O O O O O O O O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I O-0 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR-/REF | D_I/O D_O D_O A_I D_O A_I A_O A_I A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- | O_0 O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O I I I I O O O I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I I O-1 O-0 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- | D_I/O D_O D_O A_I D_O A_I A_O A_I A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O O I I O O O O O O O O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I O-0 I I O-1 O-0 I I O-1 O-0 I I I I O-1 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 111 112 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O O I I O O O O O O O O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I O-0 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 111 112 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O O I I O O O O O O O O | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-0 I I O-1 O-0 I I O-1 O-0 I I I O-1 O-0 I I I I O-1 I I I O-1 I I I O-1 I I I I O-1 |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 111 112 113 114 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN- LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- | O_0 O_0, O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I I O-1 O-0 I I O-0 I I O-1 O-0 I I O-0 I O-0 I I O-0 I O-0 I I O-0 I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN- LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O I I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-0 I I O-1 O-0 I I I I O-1 O-0 I I I O-1 O-0 O O O O O O O O O O O O O O O O O O |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN- LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O I I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O-1 O-1 O-0 I I O-1 O-0 I I O-1 O-0 I I O-0 I I O-1 O-0 I I O-0 I O-0 I I O-0 I O-0 I I O-0 I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VBEF- VBUF AGND MIC+ | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN- LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-0 I I O-1 O-0 I I I I O-1 O-0 I I I O-1 O-0 O O O O O O O O O O O O O O O O O O |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O I I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-0 I I O-1 O-0 I I I O-1 O-0 I I I I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR-/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-1 O-0 I I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn AD0/EXT_MEMORY | D_I/O D_O D_O D_O A_I D_O A_I D_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn EXT_MEMORY | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I I O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O I I O O I I I O-1 O-0 I I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR-/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn AD0/EXT_MEMORY AD1 | D_I/O D_O D_O D_O A_I D_O A_I A_O A_I A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn EXT_MEMORY AD1 | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O I I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O O I I O O O I I O-1 O-0 I I O-1 O-0 I I I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn AD0/EXT_MEMORY AD1 AD2 | D_I/O D_O D_O D_O A_I D_O A_I A_O A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn EXT_MEMORY AD1 AD2 | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O O I I O-1 O-1 O-0 I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn AD0/EXT_MEMORY AD1 AD2 AD3 | D_I/O D_O D_O D_O D_O A_I D_O A_I A_O A_I A_O A_I A_I A_I A_I A_I A_I A_I A_I A_I A_O A_O A_O A_O A_I A_O A_O A_O A_I O O O O D_O D_O | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn EXT_MEMORY AD1 AD2 AD3 | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O O I I O-1 O-1 O-0 I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |
| 93 94 95 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120 121 122 123 124 125 | TM P2[7]/DC_CTRL/SPIDO P1[6]/PON/INT6 P1[7]/CHARTGE/INT7 P2[6]/stop_charge VBAT3/RINGING LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+/REF LSR_HS/CIDIN- VREF_HS/CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn AD0/EXT_MEMORY AD1 AD2 | D_I/O D_O D_O D_O A_I D_O A_I A_O A_O A_I | TM SPIDO P1[6] INT7 P2[6] VBAT3 LINEREF LINEOUT LINEIN+ LINEIN- LDO1_Sense LDO1_CTRL LDO2_CTRL VBAT2 CIDIN+ AVS2 AVD2 LSR+ LSR- /CIDIN- CIDOUT MIC- VREF- VBUF AGND MIC+ VREF+ RSTn EXT_MEMORY AD1 AD2 | O_0 O_0/1 O_0/1 O_0/1 A_I(160k_PD) O_0 I(Dig) O I I I I O O O I I I I I I I I I I I | O-0 O-Hi-Z I-PD(160k pull down) I-PD(160k pull down) O-0 I O O O I I O-1 O-1 O-0 I I O-1 O-0 I I I I I I I I I I I I I I I I I I I |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| Pin No. | Description | I/O | Connection | at Normal mode | at Reset mode |
|---------|-------------|-----|------------|----------------|---------------|
| 127 | AD6 | D_O | AD6 | O_0/1 | O-0/1 |
| 128 | AD7 | D_O | AD7 | O_0/1 | O-0/1 |

14.2. CPU Data (Portable)

14.2.1. IC1 (BBIC)

| Pin No. | Description | 1/0 | Connection | at Normal mode | at Reset mode |
|----------|------------------------|------------|-------------|----------------|---------------|
| 1 | VSS_LNA1 | - | GND | - | - |
| 2 | RF_RXp | A.I | RF_RXp | A.I | A.I |
| 3 | RF_RXn | A.I | RF_RXn | A.I | A.I |
| 4 | VSS_LNA2 | - | GND | - | - |
| 5 | RFP1 | D.O | RXON | O_0/1 | Hi-Z |
| 6 | RFP0 | D.O | ANT1 | O_0/1 | Hi-Z |
| 7 | REF_RES | A.O | REF_RES | A.O | A.O |
| 8 | AVS_XTAL | - | GND | - | - |
| 9 | XTAL2 | A.I | XTAL2 | A.I | A.I |
| 10 | XTAL1 | A.I | XTAL1 | A.I | A.I |
| 11 | AVD_XTAL | - | AVD_XTAL | - | - |
| 12 | RF_SUPPLY1 | _ | RF_SUPPLY1 | | - |
| 13 | LDO_CTRL | A.O | LDO_CTRL | A.O | 0-1 |
| 14 | AVD | - | +1.8V | - | - |
| 15 | LSRn | A.O | LSRn | A.O | A.O |
| 16 | LSRp | A.O | LSRp | A.O | A.O |
| 17 | VREFm | | GND | | |
| | | - | MICh | - | - |
| 18 | MICh | A.I | | A.I | A.I |
| 19 | CIDOUT/MICn | A.I | MICn | A.I | A.I |
| 20 | CIDINn/MICp | A.I | MICp | A.I | A.I |
| 21 | CIDINp/VREFp | A.O | VREFp | A.O | A.I |
| 22 | RINGp/P3_7 | D.O | COL4 | O_0/1 | A.I |
| 23 | RINGn/P3_6 | D.O | COL3 | O_0/1 | A.I |
| 24 | RINGOUT/RINGING/P3_5 | D.O | COL2 | O_0/1 | A.I |
| 25 | PARADET/P3_4 | D.O | COL1 | O_0/1 | A.I |
| 26 | ADC0/P3_3 | D.O | COL0 | O_0/1 | A.I |
| 27 | ADC1/INT0/P1_0 | D.I | ROW0 | I_0/1 | I-PU |
| 28 | NTC/ADC2 | A.I | ADC2 | I_0 | A.I |
| 29 | SOCp | A.I | SOCp | A.I | A.I |
| 30 | SOCn | A.I | SOCn | A.I | A.I |
| 31 | CHARGE_CTRL | A.O | CHARGE_CTRL | A.O | O-0 |
| 32 | P1_7/CHARGE | A.I | CHARGE | A.I | I-PD |
| 33 | PAOUTp/P3_1 | A.O | PAOUTp | A.O | O-0 |
| 34 | VDDPA | - | VDDPA | - | - |
| 35 | PAOUTn/P3_0 | A.O | PAOUTn | A.O | O-0 |
| 36 | VBAT1 | - | VBAT1 | - | - |
| 37 | CP_C1x | A.I/O | CP_C1x | A.I/O | A.I |
| 38 | CP_C2x | A.I/O | CP_C2x | A.I/O | A.I |
| 39 | CP_C1y | A.I/O | CP_C1y | A.I/O | A.I |
| 40 | VBAT2 | - | VBAT2 | - | - |
| 41 | CP_C2y | A.I/O | CP_C2y | A.I/O | A.I |
| 42 | CP_VOUT1/LED1 | A.O | CP_VOUT1 | A.O | A.I |
| 43 | CP_VOUT2/LED2 | A.O | CP_VOUT2 | A.O | A.I |
| 44 | PON/P1_6 | A.I | PON | A.I | I-PD |
| 45 | VDD1 | - | +1.8V | - | - |
| 46 | P2_7/BXTAL | D.O | COL5 | O_0/1 | I-PU |
| 47 | P1_5/INT5/RDI/VDDE | D.O | N.C. | 0_0 | 0-1 |
| 48 | P1_4/INT4/TDOD | D.O | N.C. | O_0 | I-PD |
| 49 | P1_3/INT3/SIO | D.I | ROW3 | I_0/1 | I-PD |
| 50 | P1_2/INT2/SK | D.I | ROW2 | I_0/1 | I-PU |
| 51 | P1_1/INT1/LE | D.I | ROW1 | I_0/1 | I-PU |
| 52 | P2_6/WTF_IN | D.O | KEY_LED | O_0/1 | I-PU |
| 53 | P0_7/SPI_DI | D.O | EEPROM_WP | O_0/1 | I-PU |
| 54 | P0_6/SPI_DO | D.O | LCD_SDA | O_0/1 | I-PU |
| 55 | P0_5/SPI_CLK | D.O | LCD_SCL | O_0/1 | I-PU |
| 56 | P0_4/SPI_EN | D.O | LCD_CD | O_0/1 | I-PU |
| 57 | P0_3/SCL2 | D.O | SCL | O_0/1 | I-PU |
| 58 | P0_3/SCL2 P0_2/SDA2 | D.I/O | SDA | I/O_0/1 | I-PU |
| 58 59 | P0_2/SDA2 P0_1/URX | | URX | I_0/1 | I-PU |
| 60 | | D.I D.O | UTX | O_0/1 | I-PU |
| | P0_0/UTX | | | | |
| 61 | RSTn | D.O | RSTn | O_0/1 | I-PU |
| 62 | JTAG | D.I/O | JTAG | I/O_0/1 | I-PU |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| Pin No. | Description | I/O | Connection | at Normal mode | at Reset mode |
|---------|----------------------|-----|-------------|----------------|---------------|
| 63 | P2_5/PCM_FSC/SF | D.O | LCD_CSB | O_0/1 | I-PU |
| 64 | P2_4/SCL1/PCM_DO/DP3 | D.O | N.C. | 0_0 | I-PU |
| 65 | P2_3/SDA1/PCM_DI/DP2 | D.O | LCD_BACKLIT | 0_0 | I-PU |
| 66 | P2_2/PCM_CLK/CLK100 | D.O | LCD_RESET | O_0/1 | I-PU |
| 67 | P2_1/ECZ2/PWM1/LED4 | D.I | N.C. | 0_0 | A.I |
| 68 | P2_0/ECZ1/PWM0/LED3 | D.O | BELL_LED | A.I | A.I |
| 69 | VDD2 | - | +1.8V | - | - |
| 70 | LDORF_CTRL | A.I | N.C. | A.I | A.I |
| 71 | RF_SUPPLY2 | - | RF_SUPPLY2 | - | - |
| 72 | RF0n | D.O | ANT2 | O_0/1 | Hi-Z |
| 73 | RFP4 | D.O | PON | O_0/1 | Hi-Z |
| 74 | RFP3 | D.O | PSEL | O_0/1 | Hi-Z |
| 75 | VDD_PADR | A.O | VDD_PADRV | A.O | A.O |
| 76 | VSS_PADR1 | - | GND | - | - |
| 77 | RF_TXp | A.O | TXp | A.O | A.O |
| 78 | RF_TXn | A.O | TXn | A.O | A.O |
| 79 | VSS_PADR2 | - | GND | - | - |
| 80 | RFP2 | D.O | TXON | O_0/1 | Hi-Z |
| 81 | GND | - | GND | - | - |

14.3. How to Replace the Flat Package IC

Even if you do not have the special tools (for example, a spot heater) to remove the Flat IC, with some solder (large amount), a soldering iron and a cutter knife, you can easily remove the ICs that have more than 100 pins.

14.3.1. Preparation

- PbF (: Pb free) Solder
- · Soldering Iron

Tip Temperature of 700 °F \pm 20 °F (370 °C \pm 10 °C)

Note: We recommend a 30 to 40 Watt soldering iron. An expert may be able to use a 60 to 80 Watt iron where someone with less experience could overheat and damage the PCB foil.

• Flux

Recommended Flux: Specific Gravity \rightarrow 0.82. Type \rightarrow RMA (lower residue, non-cleaning type)


Note: See About Lead Free Solder (Pbf: Pb free) (P.4).

14.3.2. How to Remove the IC


1. Put plenty of solder on the IC pins so that the pins can be completely covered.

Note:


If the IC pins are not soldered enough, you may give pressure to the P.C. board when cutting the pins with a cutter.



2. Make a few cuts into the joint (between the IC and its pins) first and then cut off the pins thoroughly.




3. While the solder melts, remove it together with the IC pins.




When you attach a new IC to the board, remove all solder left on the board with some tools like a soldering wire. If some solder is left at the joint on the board, the new IC will not be attached properly.

14.3.3. How to Install the IC


1. Temporarily fix the FLAT PACKAGE IC, soldering the two marked pins.



- *Check the accuracy of the IC setting with the corresponding soldering foil.
 - 2. Apply flux to all pins of the FLAT PACKAGE IC.




3. Solder the pins, sliding the soldering iron in the direction of the arrow.



14.3.4. How to Remove a Solder Bridge

- 1. Lightly resolder the bridged portion.
- 2. Remove the remaining solder along the pins using a soldering iron as shown in the figure below.



14.4. How to Replace the LLP (Leadless Leadframe Package) IC

14.4.1. Preparation

- PbF (: Pb free) Solder
- · Soldering Iron

Tip Temperature of 700 °F ± 20 °F (370 °C ± 10 °C)

Note:

We recommend a 30 to 40 Watt soldering iron. An expert may be able to use a 60 to 80 Watt iron where someone with less experience could overheat and damage the PCB foil.

Hot Air Desoldering Tool


Temperature: 608 °F ± 68 °F (320 °C ± 20 °C)

14.4.2. Caution

- To replace the IC efficiently, choose the right sized nozzle of the hot air desoldering tool that matches the IC package.
- Be careful about the temperature of the hot air desoldering tool not to damage the PCB and/or IC.

14.4.3. How to Remove the IC


1. Heat the IC with a hot air desoldering tool through the P.C.Board.




2. Pick up the IC with tweezers, etc. when the solder is melted completely.

Note:

• Be careful not to touch the peripheral parts with tweezers, etc. They are unstable.




When it is hard to melt the solder completely, heat it with a hot air desoldering tool through the IC besides through the P.C.Board.




3. After removing the IC, clean the P.C.Board of residual solder.

14.4.4. How to Install the IC


1. Place the solder a little on the land where the radiation GND pad on IC bottom is to be attached.



- 2. Place the solder a little on the land where IC pins are to be attached, then place the IC.
 - When placing the IC, the positioning should be done very carefully.




- 3. Heat the IC with a hot air desoldering tool through the P.C.Board until the solder on IC bottom is melted. **Note:**
 - Be sure to place it precisely, controlling the air volume of the hot air desoldering tool.



4. After soldering, confirm there are no short and open circuits with visual inspection.


14.4.5. How to Remove a Solder Bridge

When a Solder Bridge is found after soldering the bottom of the IC, remove it with a soldering iron.




14.5. Terminal Guide of the ICs, Transistors and Diodes


14.5.1. Base Unit



14.5.2. Portable




14.5.3. Charger




15 Exploded View and Replacement Parts List

15.1. Cabinet and Electrical Parts (Base Unit)




Cabinet and Electrical Parts (Portable)




- Note: (*1) This cable is fixed by soldering. Refer to **How to Replace the Portable LCD** (P.66).
 - (*2) Attach the spacer (No. 127) to the exact location described above.
 - (*3) The rechargeable Ni-MH battery HHR-4DPA is available through sales route of Panasonic.

15.3. Cabinet and Electrical Parts (Charger Unit)



Accessories and Packing Materials


15.4.1. KX-TG9391T



Note:

- (*1) This pad is a piece of Ref No. P4 (GIFT BOX). (*2) These pads are pieces of Ref No. P5 (CUSHION).


15.4.2. KX-TG9392T



Note:

- (*1) This pad is a piece of Ref No. P104 (GIFT BOX).
- (*2) These pads are pieces of Ref No. P105 (CUSHION).

15.4.3. KX-TGA939T



Note:

(*1) These pads are pieces of Ref No. P203 (GIFT BOX).

15.5. Replacement Parts List

1. RTL (Retention Time Limited)

Note:

The "RTL" marking indicates that its Retention Time is Limited.

When production is discontinued, this item will continue to be available only for a specific period of time. This period of time depends on the type of item, and the local laws governing parts and product retention. At the end of this period, the item will no longer be available.

2. Important safety notice

Components identified by the \triangle mark indicates special characteristics important for safety. When replacing any of these components, only use specified manufacture's parts.

- 3. The S mark means the part is one of some identical parts. For that reason, it may be different from the installed part.
- 4. ISO code (Example: ABS-94HB) of the remarks column shows quality of the material and a flame resisting grade about plastics.
- 5. RESISTORS & CAPACITORS

Unless otherwise specified;

All resistors are in ohms (Ω) k=1000 Ω , M=1000k Ω All capacitors are in MICRO FARADS (μF) p= $\mu \mu F$

*Type & Wattage of Resistor

Type

| ERC:Solid | ERX:Metal Film | PQ4R:Chip |
|-------------|-----------------|----------------------|
| ERDS:Carbon | ERG:Metal Oxide | ERS:Fusible Resistor |
| ERJ:Chip | ER0:Metal Film | ERF:Cement Resistor |
| Wattane | | |

1:1W

2:2W 3:3W

10,16:1/8W 14,25:1/4W 12:1/2W *Type & Voltage Of Capacitor

*Type & Voltage Of Capacitor Type

| ECFD:Semi-Conductor ECQS:Styrol | ECCD,ECKD,ECBT,F1K,ECUV:Ceramic ECQE,ECQV,ECQG:Polyester |
|------------------------------------|--|
| ECUV,PQCUV,ECUE:Chip ECQMS:Mica | ECEA,ECST,EEE:Electlytic ECQP:Polypropylene |

Voltage

| ECQ Type | ECQG ECQV Type | ECSZ Type | Others | | | |
|----------|-------------------|-----------|--------|-------|------|-------|
| 1H:50V | | 0F:3.15V | 0J | :6.3V | 1V | :35V |
| 2A:100V | | 1A:10V | 1A | :10V | 50,1 | H:50V |
| 2E:250V | | 1V:35V | 1C | :16V | 1J | :16V |
| 2H:500V | | 0J:6.3V | 1E,2 | 5:25V | 2A | :100V |

15.5.1. Base Unit

15.5.1.1. Cabinet and Electrical Parts

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|------|--------------|-------------------------|---------|
| | | PNGP1034Y1 | 22777 | 3.0 775 |
| | 1 | PNGP1034Y1 | PANEL | AS-HB |
| | 2 | PNHS1055Z | TAPE, DOUBLESIDED | |
| | 3 | PNKM1054Z1 | UPPER CABINET | PS-HB |
| | 4 | PNBH1007Z1 | HOOKLEVER | ABS-HB |
| | 5 | L0AA04A00028 | SPEAKER | |
| | 6 | PQHR11082Z | GUIDE, SPEAKER | POM-HB |
| | 7 | PNBC1002Z2 | BUTTON, NAVIGATOR | ABS-HB |
| | 8 | PNBC1004Y2 | BUTTON, ANSWER ON | ABS-HB |
| | 9 | PNBC1005Y2 | BUTTON, ERASE | ABS-HB |
| | 10 | PNBC1006Y2 | BUTTON, STOP | ABS-HB |
| | 11 | PNBC1007Y2 | BUTTON, LOCATOR | ABS-HB |

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|------|--------------|---|---------|
| | No. | | | |
| | 12 | PNHR1001Z | GUIDE, BUTTON | PS-HB |
| | 13 | PNBC1001Z2 | BUTTON, MESSAGE | AS-HB |
| | 14 | PNJK1033Z | KEYBOARD SWITCH | |
| | 15 | PNHR1063Z | GUIDE, BUTTON | PS-HB |
| | 16 | PNBC1246Z1 | BUTTON, LINE1 | AS-HB |
| | 17 | PNBC1247Z1 | BUTTON, LINE2 | AS-HB |
| | 18 | PNHR1066Z | PLASTIC PARTS, LENS | PS-HB |
| | 19 | PNBX1028Z1 | RUBBER, SWITCH | PMMA-HB |
| | 20 | PNJK1032Z | KEYBOARD SWITCH | |
| | 21 | PNHS1030Z | LCD, CUSHION | |
| | 22 | PNKF1040Z1 | CABINET COVER | PS-HB |
| | 23 | PNKM1053Z1 | CABINET BODY | PS-HB |
| | 24 | L0DDFD000002 | SPEAKER | |
| | 25 | PQMG10025W | RUBBER PARTS, MIC COVER | |
| | 26 | PNKF1039Z1 | CABINET COVER | PS-HB |
| | 27 | PQHA10023Z | RUBBER PARTS, FOOT CUSH- ION | |
| | 28 | PQXDZLDRS1 | MAGNET ELECTRIC TRAN- SCUCER, SECURITY TAG | |
| | 29 | PQSH2B105Z | PUSH SWITCH | S |
| | 30 | PQHG10734Z | CUSHION | |
| | 31 | PQJJ1T030W | JACK, SOCKET | |

15.5.1.2. Main P.C.Board Parts

Note:

- (*1) Whren replacing IC551, IC561, IC761 or X501, data needs to be written to them with PNZZTG9391T. Refer to Base Unit (P.74) of Things to Do after Replacing IC or X'tal (P.74).
- (*2) When replacing IC701, refer to **How to Replace the LLP (Leadless Leadframe Package) IC** (P.102).
- (*3) IC561 and IC761 need software downloading. Refer to Base Unit (P.74) of Things to Do after Replacing IC or X'tal.

| Safety | | Part No. | Part Name & Description | Remarks |
|--------|-------|--------------|-------------------------------|---------|
| | No. | | | |
| | PCB1 | PNWPTG9391TH | | |
| | | | (RTL) | |
| | | | (ICs) | |
| | | C0ABBA000233 | | |
| | IC171 | C0BBBA000022 | IC | |
| | IC186 | C1CB00002903 | IC | |
| | IC261 | C0ABBA000233 | IC | |
| | IC311 | C0DBAGZ00023 | IC | S |
| | IC321 | COCBAYG00016 | IC | |
| | IC326 | COCBABD00036 | IC | |
| | IC331 | C0CBABD00040 | IC | |
| | IC336 | C0DBGYY00335 | IC | |
| | IC341 | COCBADE00031 | IC | |
| | IC411 | C0ABEB000023 | IC | |
| | IC431 | PQVIBU4053BC | IC | |
| | IC451 | C0ABEB000023 | IC | |
| | IC501 | C1CB00002704 | IC | |
| | IC551 | PNWITG9391TH | IC (EEPROM) (*1) | |
| | IC561 | C3FBLY000058 | IC (FLASH MEMORY 1) (*1) | |
| | | | (*3) | |
| | IC631 | C0JBAF000223 | IC | |
| | IC641 | C0JBAF000223 | IC | |
| | IC701 | C1CB00002427 | IC (*2) | |
| | IC761 | C3FBMY000195 | IC (FLASH MEMORY 2) (*1) (*3) | |
| | Q541 | C0EBE0000528 | IC | |
| | | | (TRANSISTORS) | |
| | Q101 | B1ADGP000008 | TRANSISTOR(SI) | |
| | Q102 | 1 | TRANSISTOR(SI) | |
| | Q103 | UN5113 | TRANSISTOR(SI) | s |
| | Q131 | 2SD0874AS | TRANSISTOR(SI) | |
| | Q184 | UN5213 | TRANSISTOR(SI) | s |
| | Q185 | PQVTBF822T7 | TRANSISTOR(SI) | |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| | | 393921/KX-1GA939 | <u>의</u> - | |
|--------|---------------------|------------------------------|-------------------------|---------|
| Safety | | Part No. | Part Name & Description | Remarks |
| | No. Q191 | P13DCD00000 | TRANSISTOR(SI) | |
| | Q191 Q192 | | TRANSISTOR (SI) | |
| | Q194 | UN5213 | TRANSISTOR (SI) | |
| | Q201 | | TRANSISTOR(SI) | |
| | Q203 | UN5113 | TRANSISTOR(SI) | S |
| | Q231 | 2SD0874AS | TRANSISTOR (SI) | s |
| | Q311 | B1CHND00004 | TRANSISTOR (SI) | |
| | Q371 | 2SD1819A | TRANSISTOR(SI) | |
| | Q376 | B1ADGE000004 | TRANSISTOR (SI) | |
| | Q381 | B1ADGE000004 | TRANSISTOR (SI) | |
| | Q386 | B1ADGE000004 | TRANSISTOR (SI) | |
| | Q389 | | TRANSISTOR (SI) | |
| | Q621 | | TRANSISTOR(SI) | S |
| | Q761 | | TRANSISTOR(SI) | S |
| | Q772 | | TRANSISTOR(SI) | |
| | Q773 | UN5213 | TRANSISTOR (SI) | |
| | D101 | B0EDER000009 | (DIODES) | |
| | D101 | MA1Z300 | DIODE(SI) | s |
| | D104 | B0JCME000035 | | 5 |
| | D106 | B0JCME000035 | | |
| | D125 | MAZY04700L | | |
| | D181 | B0EDER000009 | | |
| | D185 | B0JCME000035 | DIODE(SI) | |
| | D196 | 188355 | DIODE(SI) | S |
| | D201 | B0EDER000009 | DIODE(SI) | |
| | D202 | MA1Z300 | DIODE(SI) | S |
| | D225 | MAZY04700L | DIODE(SI) | |
| | D301 | B0JCME000035 | DIODE(SI) | S |
| | D311 | B0JCNE000008 | | |
| | D372 | MA21D3400L | DIODE(SI) | |
| | D382 | MA21D3400L | DIODE(SI) | |
| | D401 | MAZ805100L | DIODE(SI) | |
| | D402 D403 | MAZ805100L MAZ805100L | DIODE(SI) DIODE(SI) | |
| | D403 | MAZ805100L | DIODE(SI) | |
| | D461 | MA21D3400L | DIODE(SI) | |
| | D462 | MA21D3400L | DIODE(SI) | |
| | D505 | B0JCDD000002 | DIODE(SI) | |
| | D631 | 1SS355 | DIODE(SI) | S |
| | D632 | 188355 | DIODE(SI) | s |
| | D633 | 188355 | DIODE(SI) | S |
| | D634 | 188355 | DIODE(SI) | S |
| | D636 | 1SS355 | DIODE(SI) | S |
| | D637 | 1SS355 | DIODE(SI) | S |
| | D638 | 1SS355 | DIODE(SI) | S |
| | D645 | 1SS355 | DIODE(SI) | S |
| | D741 | MAZ805100L | DIODE(SI) | |
| | D742 D801 | MAZ805100L B0DDCM000001 | DIODE(SI) | |
| | DOUL | BODDEMOUGUT | (JACKS) | |
| | CN101 | K2LB1YYB0001 | JACK, MODULAR | |
| | CN201 | | JACK, MODULAR | |
| | CN301 | K2ECYB000001 | JACK, DC | |
| | | | (COILS) | |
| | L311 | G1C470M00025 | COIL | |
| | L401 | PQLQR2KA20T | COIL | S |
| | L402 | PQLQR2KA20T | COIL | S |
| | L403 | PQLQR2KA20T | COIL | s |
| | L404 | PQLQR2KA20T | COIL | S |
| | L611 | PQLQR4F601ST | | S |
| | L612 | PQLQR4F601ST | | S |
| | L613 | PQLQR4F601ST | | S |
| | L614 | PQLQR4F601ST | | S |
| | L615 | PQLQR4F601ST | | S |
| | L616 L617 | PQLQR4F601ST PQLQR4F601ST | | s s |
| | L618 | PQLQR4F601ST | | s |
| | L619 | PQLQR4F601ST | | S |
| | L620 | PQLQR4F601ST | | s |
| | L621 | PQLQR4F601ST | COIL | S |
| | L741 | PQLQR1WT | COIL | s |
| | L742 | PQLQR1WT | COIL | S |
| | , - · · | | - | 1 |

| Safety | | Part No. | Part Name & Description | Remarks |
|--------|---------------|----------------------------|-----------------------------------|----------|
| | No. | PQLQR1RS241 | COIL | s |
| | L746 | PQLQR1RS241 | COIL | S |
| | L803 | ELJRF33NJFB | COIL | s |
| | C801 | MQLRF6N8JFB | COIL | |
| | C804 | MQLRF6N8JFB | COIL | |
| | C809 | ELJRF1N5ZFB | COIL | s |
| | | | (COMPONENTS PARTS) | |
| | L101 | EXCELDR35 | COMPONENTS PARTS | |
| | L102 | EXCELDR35 | COMPONENTS PARTS | |
| | L201 | EXCELDR35 | COMPONENTS PARTS | |
| | L202 | EXCELDR35 | COMPONENTS PARTS | |
| | | | (PHOTO ELECTRIC TRANSDUC- ERS) | |
| | PC102 | B3PBB0000039 | PHOTO ELECTRIC TRANSDUCER | |
| | PC202 | B3PBB0000039 | PHOTO ELECTRIC TRANSDUCER | |
| | | | (VARISTORS) | |
| | SA101 | J0LE00000047 | | |
| | 63.100 | 707 700000047 | ABSORBER) VARISTOR (SURGE | |
| | SAIUZ | J0LE00000047 | ABSORBER) | |
| | SA201 | J0LE00000047 | | |
| | | | ABSORBER) | |
| | SA202 | J0LE00000047 | VARISTOR (SURGE ABSORBER) | |
| | | | (TRANSFORMERS) | |
| | T241 | G5AZA0000001 | , | |
| | T246 | G5AZA0000001 | | |
| | * | | (RESISTORS) | |
| | R101 | ERJ3GEYJ104 | 100k | |
| | R102 | PQ4R10XJ222 | 2.2k | S |
| | R103 | ERJ3GEYJ106 | 10M | |
| | R104 | ERJ3GEYJ106 | 10M | |
| | R105 | ERJ2GEJ222 | 2.2k | |
| | R106 | ERJ3GEYJ104 | 100k | |
| | R111 | ERJ3GEYJ825 | 8.2M | |
| | R112 | ERJ3GEYJ825 | 8.2M | |
| | R113 | ERJ3GEYJ564 | 560k | |
| | R114 | ERJ3GEYJ564 | 560k | |
| | R120 | ERJ2GEJ222 | 2.2k | |
| | R121 | ERJ3GEYJ273 | 27k | |
| | R122 | ERJ3GEYJ472 | 4.7k | |
| | R123 | ERJ3GEYJ822 ERJ12YJ120 | 8.2k 12 | |
| | R124 | ERJ12YJ120 ERJ12YJ270 | 27 | |
| | R126 | ERJ3GEYJ104 | 100k | |
| | R133 | ERJ3GEYJ820 | 82 | |
| | R134 | ERJ3GEYJ821 | 820 | |
| | R136 | ERJ3GEYJ682 | 6.8k | |
| | R141 | ERJ3GEYJ560 | 56 | |
| | R142 | ERJ3GEYJ180 | 18 | |
| | R151 | PQ4R10XJ475 | 4.7M | S |
| | R152 | PQ4R10XJ184 | 180k | s |
| | R153 | PQ4R10XJ105 | 1M | s |
| | R156 | PQ4R10XJ475 | 4.7M | s |
| | R157 | PQ4R10XJ184 | 180k | s |
| | R158 | PQ4R10XJ105 | 1M | S |
| | R161 | ERJ2GEJ100 | 10 | |
| | R162 | ERJ3GEYJ104 | 100k | |
| | R165 | ERJ3GEYJ104 | 100k | |
| | R167 | ERJ2GE0R00 | 0 | |
| | R168 | ERJ2GEJ222 | 2.2k | |
| | R171 | ERJ3GEYJ683 | 68k | |
| | R172 R173 | ERJ3GEYJ104 ERJ3GEYJ103 | 100k 10k | |
| | R174 | ERJ3GEYJ103 ERJ3GEYJ273 | 27k | |
| | R175 | ERJ3GEYJ223 | 22k | |
| | R176 | ERJ3GEYJ472 | 4.7k | |
| | R181 | D0GG682JA007 | | |
| | R183 | ERJ2GEJ472X | 4.7k | |
| | R184 | ERJ2GEJ103 | 10k | |
| | | | | <u> </u> |
| | R185 | ERJ2GE0R00 | 0 | |
| | | ERJ2GE0R00 ERJ3GEYJ153 | 0 15k | |
| | R185 | | | |

| Cafotir | Pof | Part No. | Part Name & Degariation | Remarks |
|---------|--------------|----------------------------|-------------------------|---------|
| Safety | No. | Part No. | Part Name & Description | Remarks |
| | R191 | ERJ3GEYJ104 | 100k | |
| | R192 | ERJ3GEYJ104 | 100k | |
| | R193 | PQ4R10XJ472 | 4.7k | S |
| | R194 | ERJ3GEYJ473 | 47k | |
| | R195 | ERJ3GEYJ103 | 10k | |
| | | | 10k | |
| | R197 | ERJ3GEYJ183 | 18k | |
| | R198 | ERJ3GEY0R00 | 0 | |
| | R201 | | 100k | |
| | | PQ4R10XJ472 ERJ3GEYJ106 | 4.7k | S |
| | R203 R204 | ERJ3GEYJ106 ERJ3GEYJ106 | 10M 10M | |
| | R204 | ERJ2GEJ222 | 2.2k | |
| | R211 | ERJ3GEYJ825 | 8.2M | |
| | R212 | ERJ3GEYJ825 | 8.2M | |
| | R213 | ERJ3GEYJ564 | 560k | |
| | R214 | ERJ3GEYJ564 | 560k | |
| | R221 | ERJ3GEYJ103 | 10k | |
| | R222 | ERJ3GEYJ102 | 1k | |
| | R224 | ERJ12YJ120 | 12 | |
| | R225 | ERJ12YJ270 | 27 | |
| | R226 | ERJ3GEYJ104 | 100k | |
| | R228 | ERJ3GEY0R00 | 0 | |
| | R232 | ERJ3GEY0R00 | 0 | |
| | R233 | ERJ3GEYJ820 | 82 | |
| | R234 | ERJ3GEYJ821 | 820 | |
| | R236 | ERJ3GEYJ103 | 10k | |
| | R241 | ERJ3GEY0R00 | 0 | |
| | R251 | PQ4R10XJ475 | 4.7M | S |
| | R252 | PQ4R10XJ184 | 180k | S |
| | R253 | PQ4R10XJ105 | 1M | S |
| | | PQ4R10XJ475 | 4.7M | S |
| | R257 | PQ4R10XJ184 | 180k | S |
| | R258 | PQ4R10XJ105 | 1M | S |
| | R261 R262 | ERJ2GEJ100 ERJ3GEYJ104 | 10 100k | |
| | | ERJ3GEYJ104 | 100k | |
| | R268 | ERJ2GE0R00 | 0 | |
| | R271 | ERJ3GEYJ683 | 68k | |
| | R272 | ERJ3GEYJ104 | 100k | |
| | R273 | ERJ3GEYJ103 | 10k | |
| | R274 | ERJ3GEYJ273 | 27k | |
| | R275 | ERJ3GEYJ223 | 22k | |
| | R276 | ERJ3GEYJ472 | 4.7k | |
| | R311 | ERJ3GEYJ121 | 120 | |
| | R312 | ERJ3GEYJ221 | 220 | |
| | R313 | ERJ3GEYJ221 | 220 | |
| | R321 | ERJ2GEJ181 | 180 | |
| | R322 | ERJ2GEJ181 | 180 | |
| | R332 | ERJ2GE0R00 | 0 | |
| | R337 | ERJ2GE0R00 | 0 | |
| | R342 | ERJ2GEJ222 | 2.2k | |
| | R371 | ERJ3GEYJ822 | 8.2k | |
| | R372 | ERJ3GEYJ152 | 1.5k | |
| | R373 | ERJ3GEYJ392 ERJ2GEJ472X | 3.9k | |
| | R374 R375 | ERJ2GEJ472X ERJ2GEJ223 | 4.7k 22k | |
| | R376 | ERJ2GEJ223 ERJ2GEJ471 | 470 | |
| | R376 | ERJ2GEJ471 ERJ2GEJ562X | 5.6k | |
| | R382 | ERJ2GEJ502X ERJ3GEYF133 | 13k | s |
| | R383 | ERJ3EKF5601 | 5.6k | |
| | R386 | ERJ2GEJ153 | 15k | |
| | R388 | ERJ2GEJ682 | 6.8k | |
| | R389 | ERJ2GEJ103 | 10k | |
| | R390 | ERJ3GEYJ4R7 | 4.7 | |
| | R412 | ERJ2GEJ222 | 2.2k | |
| | R413 | ERJ2GEJ222 | 2.2k | |
| | R414 | ERJ2GEJ472X | 4.7k | |
| | R415 | ERJ2GEJ472X | 4.7k | |
| | R416 | ERJ2GEJ101 | 100 | |
| | | | | |
| | R417 | ERJ2GEJ222 | 2.2k | |
| | R417 R418 | ERJ2GEJ222 ERJ2GEJ222 | 2.2k 2.2k | |

| Safety | | Part No. | Part Name & Description | Remarks |
|--------|--------------|----------------------------|-------------------------|---------|
| | No. | ERJ2GEJ101 | 100 | |
| | | ERJ2GEJ473 | 47k | |
| | R422 | ERJ2GEJ473 | 47k | |
| | | ERJ2GEJ222 | 2.2k | |
| | R427 | ERJ2GEJ222 | 2.2k | |
| | R428 | ERJ2GEJ222 | 2.2k | |
| | R446 | ERJ3GEYJ224 | 220k | |
| | R451 | ERJ2GEJ472X | 4.7k | |
| | R452 | ERJ2GEJ472X | 4.7k | |
| | R453 | ERJ2GEJ100 | 10 | |
| | R454 | ERJ2GEJ100 | 10 | |
| | R457 | ERJ2GEJ223 | 22k | |
| | R458 | ERJ2GEJ223 | 22k | |
| | R461 | ERJ3GEYJ330 | 33 | |
| | R503 | ERJ2GE0R00 | 0 | |
| | R505 | ERJ2GEJ103 | 10k | |
| | R506 | ERJ2GE0R00 | 0 | |
| | R507 | ERJ3GEYJ103 | 10k | |
| | R508 | ERJ2GEJ103 | 10k | |
| | R516 | ERJ2GEJ271 | 270 | |
| | R552 R553 | ERJ3GEYJ222 ERJ2GEJ222 | 2.2k 2.2k | |
| | R553 | ERJ2GEJ222 ERJ2GEJ104 | 2.2k 100k | |
| | R561 | ERJ2GEJ104 ERJ2GEJ101 | 100k 100 | |
| | R562 | ERJ2GEJ101 ERJ2GEJ101 | 100 | |
| | | ERJ2GEJ101 | 100 | |
| | R564 | ERJ2GEJ101 | 100 | |
| | R565 | ERJ2GEJ101 | 100 | |
| | R566 | ERJ2GEJ101 | 100 | |
| | R567 | ERJ2GEJ101 | 100 | |
| | R568 | ERJ2GEJ101 | 100 | |
| | R569 | ERJ2GEJ101 | 100 | |
| | R570 | ERJ2GEJ101 | 100 | |
| | R571 | ERJ2GEJ101 | 100 | |
| | R572 | ERJ2GEJ101 | 100 | |
| | R573 | ERJ2GEJ101 | 100 | |
| | R574 | ERJ2GEJ101 | 100 | |
| | R575 | ERJ2GEJ101 | 100 | |
| | R576 | ERJ2GEJ101 | 100 | |
| | R591 | ERJ3GEYJ101 | 100 | |
| | R592 | ERJ3GEYJ102 | 1k | |
| | R593 | ERJ3GEYJ102 ERJ3GEYJ102 | 1k | |
| | R596 R597 | ERJ3GEYJ102 ERJ3GEYJ103 | 1k 10k | |
| | R598 | | 10k | |
| | R601 | ERJ2GEJ104 | 100k | |
| | R602 | ERJ2GEJ104 | 100k | |
| | R603 | ERJ2GEJ104 | 100k | |
| | R604 | ERJ2GEJ104 | 100k | |
| | R613 | | 390 | |
| | R614 | ERJ3GEYJ391 | 390 | |
| | R616 | ERJ3GEYJ391 | 390 | |
| | R617 | ERJ3GEYJ391 | 390 | |
| | R618 | ERJ3GEYJ391 | 390 | |
| | R619 | ERJ2GEJ103 | 10k | |
| | R621 | ERJ3GEYJ101 | 100 | |
| | R622 | ERJ2GEJ222 | 2.2k | |
| | R641 | ERJ2GEJ103 | 10k | |
| | R642 | ERJ2GEJ103 | 10k | |
| | R703 | ERJ2GEJ104 | 100k | |
| ļ | R704 | ERJ3GEYJ102 | 1k | |
| | R705 | ERJ2GEJ473 | 47k | |
| | R706 | ERJ2GEJ473 | 47k | |
| | R721 | | 2.2k | |
| | R722 R723 | ERJ3GEYJ222 | 2.2k 2.2k | |
| | R724 | ERJ2GEJ222 ERJ2GEJ222 | 2.2k | |
| | R724 | ERJ2GEJ222 ERJ2GEOROO | 0 | |
| | R727 | ERJ2GEJR00 | 330 | |
| | R727 | ERJ2GEJ222 | 2.2k | |
| | R743 | ERJ3GEYJ6R8 | 6.8 | |
| | R764 | ERJ2GEJ561 | 560 | |
| | R765 | ERJ2GEJ473 | 47k | |
| ı | | ı | 1 | |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| 100 10000 | ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | 33321/KA-1GA333 | <u> </u> | |
|--|---|-----------------|-------------------------|---------|
| Safety | Ref. | Part No. | Part Name & Description | Remarks |
| | No. | | | |
| | R776 | ERJ2GEJ473 | 47k | |
| | R777 | ERJ2GEJ223 | 22k | |
| | R801 | ERJ3GEYJ181 | 180 | |
| | R803 | ERJ2GEJ561 | 560 | |
| | R804 | ERJ2GEJ561 | 560 | |
| | R806 | ERJ2GEJ331 | 330 | |
| | R807 | ERJ2GEJ102 | 1k | |
| | R808 | ERJ2GEJ561 | 560 | |
| | R809 | ERJ3GEYJ181 | 180 | |
| | R810 | ERJ2GEJ473 | 47k | |
| | | F1G1H3R3A562 | | |
| | | | | |
| | R812 | ECUE1H100DCQ | - | |
| | C123 | ERJ3GEYJ562 | 5.6k | _ |
| | | PFRT002 | 0k | S |
| | PO201 | PFRT002 | 0k | S |
| | | | (CAPACITORS) | |
| | C102 | F1K2J681A006 | 680p | |
| | C103 | F1K2J681A006 | 680p | |
| | C105 | ECUV1H103KBV | 0.01 | |
| | C121 | ECUE1A104KBQ | 0.1 | |
| | C122 | ECUV1H472KBV | 0.0047 | |
| | C124 | ECUV1H100DCV | 10p | |
| | C125 | F1K1C2250005 | 2.2 | |
| | C128 | PQCUV1A105KB | | |
| | C133 | F1K1C4750023 | | |
| | C141 | ECUV1C563KBV | | |
| — | C143 | ECJ0EB1A563K | | s |
| - | C151 | ECUV1C103KBV | | - |
| | C152 | ECUV1C103KBV | | |
| | C152 | F1K2J681A006 | | |
| | | | | |
| | C161 | ECUV1A105KBV | | |
| | C162 | ECUV1H221JCV | _ | |
| | C171 | ECUV1C563KBV | | |
| | C172 | ECUV1C104KBV | | |
| | C173 | EEE1CA100SR | 10 | |
| | C174 | ECUV1A105KBV | | |
| | C177 | ECUE1H102KBQ | 0.001 | |
| | C181 | F0C2E1050005 | 0.056 | |
| | C182 | F1K2J681A006 | 0.1 | |
| | C202 | F1K2J681A006 | 680p | |
| | C203 | F1K2J681A006 | 680p | |
| | C205 | ECUV1H103KBV | 0.01 | |
| | C222 | ECUV1H472KBV | 0.0047 | |
| | C224 | ECUV1H100DCV | 10p | |
| | C225 | F1K1C2250005 | 1 | |
| | C228 | PQCUV1A105KB | 1 | |
| | C233 | F1K1C4750023 | 10 | |
| | C237 | EEE1HA010SR | 1 | |
| | C241 | ECUE1C103KBQ | 0.01 | |
| | C242 | ECUE1C103KBQ | | |
| | C261 | ECUV1A105KBV | | |
| | C262 | ECUV1H221JCV | | |
| — | C264 | ECUE1H100DCQ | | |
| | C271 | ECUV1C563KBV | | |
| — | C271 | ECUV1C104KBV | | |
| — | C277 | ECUE1H102KBQ | | |
| - | C301 | F2G1E1010011 | | s |
| <u> </u> | C301 | ECUV1H101JCV | | _ |
| - | | | - | |
| <u> </u> | C303 | ECUV1H103KBV | | |
| <u> </u> | C322 | ECUV1A105KBV | | |
| | C331 | EEE0JA331P | 330 | |
| | C332 | ECUV1A105KBV | | |
| | C336 | EEE0JA331P | 330 | |
| | C337 | ECUV1A105KBV | | |
| | C501 | ECUE1A104KBQ | | |
| | C503 | ECUE1A104KBQ | | |
| | C504 | ECUE1A104KBQ | 0.1 | |
| | C507 | ECUE1A104KBQ | 0.1 | |
| | C508 | ECUE1A104KBQ | 0.1 | |
| | C509 | ECUE1A104KBQ | 0.1 | |
| | C511 | ECUE1H5R0CCQ | 5p | |
| | C512 | ECUE1H5R0CCQ | 5p | |
| | C521 | ECUE1H331KBQ | | |
| | | | - | i |

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|----------|--|---|---|---------|
| | C528 | ECUE1H331KBQ | 330n | |
| | C601 | ECUE1H101JCQ | | |
| | C603 | ECUE1H101JCQ | | |
| | C604 | ECUE1H101JCQ | • | |
| | C611 | ECUE1A104KBQ | • | |
| | C612 | ECUE1A104KBQ | | |
| | C631 | ECUE1A104KBQ | | |
| | C802 | ECUE1H7R0CCQ | | |
| | C807 | ECUE1H100DCQ | | |
| | C808 | ECUE1H100DCQ | | |
| | C815 | ECUE1H3R0CCQ | _ | |
| | C816 | PQCUV0J475MB | | |
| | C817 | ECUE1H100DCQ | | |
| | C106 | ECUV1A224KBV | | |
| | C113 | ECUV1C104KBV | | |
| | C114 | ECUV1C104KBV | | |
| | C115 | ECUE1H102KBQ | | |
| | C113 | EEE0JA331P | 330 | |
| | | ECUV1H472KBV | | |
| | C127 | | | |
| <u> </u> | C131 | ECUE1H100DCQ | | |
| <u> </u> | C156 | ECUV1C103KBV ECUV1C103KBV | | |
| <u> </u> | C157 | F1K2J681A006 | | |
| <u> </u> | C158 | | | |
| <u> </u> | C163 | ECUE1H100DCQ | - | |
| <u> </u> | C164 | ECUE1H100DCQ | | |
| <u> </u> | C165 | ECUV1H221JCV | | |
| <u> </u> | C166 | ECUE1H102KBQ F1K2J681A006 | | |
| | C183 | | | |
| | C186 | ECUV1C563KBV | | |
| | C187 | F2G1H4R70017 | | S |
| | C206 | ECUV1A224KBV | | |
| | C213 | ECUV1C104KBV | | |
| | C214 | ECUV1C104KBV | | |
| | C215 | ECUE1H102KBQ | | |
| | C221 | EEE1CA100SR | 10 | |
| | C226 | EEE0JA331P | 330 | |
| | C227 | ECUV1H472KBV | | |
| | C231 | ECUE1H100DCQ | | |
| | C243 | EEE1HA010SR | 1 | |
| | C246 | EEE1CA100SR | 10 | |
| | C247 | ECUE1C103KBQ | | |
| | C248 | ECUE1C103KBQ | | |
| | C251 | ECUV1C103KBV | | |
| | C252 | ECUV1C103KBV | | |
| | C253 | F1K2J681A006 | • | |
| | C256 | ECUV1C103KBV | | |
| | C257 | ECUV1C103KBV | | |
| <u> </u> | C258 | F1K2J681A006 | | Ī |
| | C263 | ECUE1H100DCQ | | |
| | | | | |
| | C265 | ECUV1H221JCV | 220p | |
| | C266 | ECUV1H221JCV ECUE1H102KBQ | 220p 0.001 | |
| | C266 C311 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV | 220p 0.001 0.1 | |
| | C266 C311 C312 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV | 220p 0.001 0.1 | |
| | C266 C311 C312 C313 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV | 220p 0.001 0.1 1 | |
| | C266 C311 C312 C313 C314 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV | 220p 0.001 0.1 1 100p | |
| | C266 C311 C312 C313 C314 C315 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 | 220p 0.001 0.1 1 100p 1 | |
| | C266 C311 C312 C313 C314 C315 C321 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 EEE0JA331P | 220p 0.001 0.1 1 100p 1 330 330 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 EEE0JA331P EEE0JA331P | 220p 0.001 0.1 1 100p 1 330 330 330 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 EEE0JA331P EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 330 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 EEE0JA331P EEE0JA331P ECUV1A105KBV EEE1CA100SR | 220p 0.001 0.1 1 100p 1 330 330 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1H101JCV ECUV1A105KBV F2G0J3310025 EEE0JA331P EEE0JA331P ECUV1A105KBV EEE1CA100SR ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECEUJA331P ECUV1A105KBV EEE1CA105KBV ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P EEE0JA331P ECUV1A105KBV EEE1CA100SR ECUV1A105KBV ECUV1C104KBV ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 10 1 330 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV EEE1CA100SR ECUV1A105KBV ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 10 1 330 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 330 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 10 1 0.1 1 330 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 C402 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 10 1 10 1 0.1 1 330 1 1 0.01 1 1 0.001 680p | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 C402 C403 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 1 10 1 1 1 1 10 1 1 1 1 1 1 1 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 C402 C403 C404 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 330 1 10 1 1 10 1 1 0.1 1 330 1 1 1 0.001 680p 680p 0.001 | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 C402 C403 C404 C411 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 330 1 10 1 10 1 1 0.1 1 1 0.01 1 1 0.001 680p 680p 0.001 330p | |
| | C266 C311 C312 C313 C314 C315 C321 C326 C327 C341 C342 C373 C382 C386 C387 C388 C401 C402 C403 C404 | ECUV1H221JCV ECUE1H102KBQ ECUV1C104KBV ECUV1A105KBV ECUV1A105KBV ECUV1A105KBV F2G0J3310025 EEE0JA331P ECUV1A105KBV | 220p 0.001 0.1 1 100p 1 330 330 330 1 10 1 10 1 10 1 | |

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|--------------|------------------------------|-------------------------|---------|
| | C414 | ECUE1H331KBQ | 330p | |
| | C415 | ECUE1H331KBQ | 330p | |
| | C416 | PQCUV0J475MB | | |
| | C418 | ECUE1H101JCQ | | |
| | C419 | ECUE1H100DCQ | _ | |
| | C420 C421 | ECUE1H100DCQ ECUE1A104KBQ | _ | |
| | C421 | ECUEIAI04KBQ ECUE0J105KBQ | | |
| | C426 | ECUE1A104KBQ | | |
| | C427 | ECUE1A104KBQ | | |
| | C431 | ECUE1A104KBQ | 0.1 | |
| | C446 | ECUV1A105KBV | 1 | |
| | C451 | F1K1C4750023 | 4.7 | |
| | C452 | F1K1C4750023 | 4.7 | |
| | C453 | ECUE1C183KBQ | 0.018 | |
| | C454 | ECUV1A105KBV | | |
| | C457 | ECUV1A105KBV | | |
| | C458 | ECUE1H100DCQ | _ | |
| | C461 | | 100 | |
| | C502 | ECUE1A104KBQ | | |
| | C505 | ECUE1A104KBQ ECUE1H331KBQ | | |
| | C518 | ECUE1A104KBQ | _ | |
| | C541 | ECUE1A104KBQ | | |
| | C542 | ECUV1H103KBV | | |
| | C543 | ECUE1A224KBQ | | |
| | C551 | ECUE1A104KBQ | 0.1 | |
| | C561 | ECUE1A104KBQ | 0.1 | |
| | C562 | ECUE1H101JCQ | 100p | |
| | C563 | ECUE1H101JCQ | 100p | |
| | C602 | ECUE1H101JCQ | = | |
| | C641 | ECUE1A104KBQ | | |
| | C701 | ECUE1A104KBQ | | |
| | C702 | ECUE1H100DCQ | | |
| | C703 | ECUE1A104KBQ ECUE1H102KBQ | | |
| | C705 | ECUE1A104KBQ | | |
| | C706 | ECUE1A104KBQ | | |
| | C707 | ECUE1A104KBQ | | |
| | C708 | ECUE1A104KBQ | 0.1 | |
| | C721 | ECUE1H102KBQ | 0.001 | |
| | C723 | ECUE1A104KBQ | | |
| | C724 | ECUE1A104KBQ | 0.1 | |
| | C726 | ECUE1A104KBQ | | |
| | C727 | ECST0JY106 | 10 | S |
| | C728 | ECUE1A104KBQ | | |
| | C741 | ECUE1H100DCQ | _ | |
| | C742 | ECUE1H100DCQ | 10p | |
| | C743 | EEE0JA101WR ECUE0J105KBQ | | |
| | C747 | ECUE1H331KBQ | | |
| | C748 | ECUE1H331KBQ | | |
| | C761 | ECUE1A104KBQ | - | |
| | C765 | ECUE1A104KBQ | | |
| | C776 | ECUE1H222KBQ | 0.0022 | |
| | C803 | ECUE1H7R0CCQ | 7p | |
| | C814 | ECUE1H100DCQ | 10p | |
| | C819 | ECUE1H100DCQ | | |
| | C821 | ECUE1H220JCQ | _ | |
| | C824 | ECUE1H220JCQ | _ | |
| | C831 | ECUE1H151JCQ | | |
| | C832 | ECUE1H102KBQ | (OTHERS) | |
| | IC801 | PQLP10293Z | RF UNIT | |
| | MIC1 | L0CBAB000052 | | |
| | E1 | | ANTENNA | |
| | E2 | | PARALLEL LEADWIRE | |
| | F301 | K5H302Y00003 | | |
| | R515 | J0JCC0000275 | | |
| | X501 | ној103500020 | CRYSTAL OSCILLATOR (*1) | |
| | RL185 | PSSLG6K2FYZ | RELAY | s |
| | | | | |

15.5.1.3. Operational P.C.Board parts

| Safety | | Part No. | Part Name & Description | Remarks |
|--------|--------|--------------|-----------------------------------|---------|
| | No. | | | |
| | PCB2 | PNLP2083Z | OPERATIONAL P.C.BOARD ASS'Y (RTL) | |
| | | | (DIODES) | |
| | D101 | MA21D3400L | DIODE(SI) | |
| | | LNJ826W83RA | DIODE(SI) | |
| | | | . , , | |
| | LED906 | LNJ826W83RA | DIODE(SI) | |
| | | | (RESISTORS) | |
| | R55 | ERJ3GEY0R00 | 0 | |
| | R56 | ERJ3GEY0R00 | 0 | |
| | R57 | ERJ3GEY0R00 | 0 | |
| | R58 | ERJ3GEY0R00 | 0 | |
| | R60 | ERJ3GEYJ105 | 1M | |
| | | | (CAPACITORS) | |
| | C103 | ECUV1H101JCV | 100p | |
| | C104 | ECUV1H101JCV | 100p | |
| | C105 | ECUV1H101JCV | 100p | |
| | C173 | ECUV1C105KBV | 1 | |
| | C174 | ECUV1C105KBV | 1 | |
| | C175 | ECUV1C105KBV | 1 | |
| | C176 | ECUV1C105KBV | 1 | |
| | C177 | ECUV1C105KBV | 1 | |
| | C178 | ECUV1C105KBV | 1 | |
| | C179 | ECUV1C105KBV | 1 | |
| | C180 | ECUV1C105KBV | 1 | |
| | C181 | ECUV1C105KBV | 1 | |
| | C184 | PQCUV0J106KB | 10 | |
| | | ~ | (OTHERS) | |
| | E3 | L5DZBYY00015 | LIQUID CRYSTAL DISPLAY | |
| | E4 | PNHX1080Z | COVER, LCD SHEET | |
| | E5 | PNHX1124Z | COVER, DIFFUSION SHEET | |
| | E6 | PNJE1014Z | LEAD WIRE, FPC | |
| | E7 | | LED | |
| | E8 | PNHR1065Z | LCD PLATE | PMMA-HE |
| | | 1 | | |

15.5.2. Portable

15.5.2.1. Cabinet and Electrical Parts

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|------|--------------|-------------------------------------|---------|
| | 101 | PNGP1002X1 | PANEL | AS-HB |
| | 102 | PNHS1002Z | TAPE, DOUBLE SIDED | |
| | 103 | PNKM1052Z1 | CABINET BODY | PS-HB |
| | 104 | PNHR1005Z | OPTIC CONDUCTIVE PARTS, LED LENS | PS-HB |
| | 105 | PQHS10722Y | SPACER, LCD | |
| | 106 | PNHS1001Z | COVER, SP NET | |
| | 107 | L0AD02A00043 | RECEIVER | |
| | 108 | PQHG10756Z | RUBBER PARTS, RECEIVER | |
| | 109 | PNBC1008Y2 | BUTTON, TALK | ABS-HB |
| | 110 | PNBC1009Y2 | BUTTON, OFF | ABS-HB |
| | 111 | PNBC1010Y2 | BUTTON, SP | ABS-HB |
| | 112 | PNBC1011Y2 | BUTTON, PAUSE | ABS-HB |
| | 113 | PNBC1003X4 | BUTTON, NAVIGATOR | ABS-HB |
| | 114 | PNBX1027Z1 | KEYBOARD SWITCH | PMMA-HB |
| | 115 | PNJK1031Z | RUBBER SWITCH | |
| | 116 | PNJT1002Z | CHARGE TERMINAL (R) | |
| | 117 | PNJT1001Z | CHARGE TERMINAL (L) | |
| | 118 | PQHR11313Z | GUIDE, SPEAKER | ABS-HB |
| | 119 | PQHG10729Z | RUBBER PARTS, SPEAKER | |
| | 120 | L0AD02A00026 | SPEAKER | |
| | 121 | PQHS10622Z | SPACER, NET | |
| | 122 | PNLA1005Z | ANTENNA | |
| | 123 | PNKE1002Z2 | COVER, E/P | |
| | 124 | PQJC10056X | BATTERY TERMINAL | |
| | 125 | PNKF1006Z1 | CABINET COVER | ABS-HB |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|------|--------------|-------------------------|---------|
| | No. | | | |
| | 126 | PNQT1230Y | LABEL, BATTERY | |
| | 127 | PQHS10561Y | SPACER, BATTERY COVER | |
| | 128 | PNKK1001Z2 | LCD, BETTERY | ABS-HB |
| | 129 | PNGT1490Z | NAME PLATE | |
| | 130 | PNYNTGA430BR | BATTERY COVER ASS'Y | |
| | 131 | PNHX1036Z | COVER, LCD SHEET | |

15.5.2.2. Main P.C.Board Parts

Note:

(*1) When replacing IC1, IC3 or X1, data needs to be written to them with PNZZTG9391T. Refer to **Portable** (P.75) of **Things to Do after Replacing IC or X'tal** (P.74).

(*2) Flash type of BBIC needs software downloading. Refer to **Portable** (P.75) of **Things to Do after Replacing IC or X'tal** (P.74).

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|--------------|-----------------------------|---------|
| | PCB100 | PNWPTGA939TR | MAIN P.C.BOARD ASS'Y (RTL) | |
| | | | (ICs) | |
| | IC1 | C1CB00002906 | IC (BBIC (FLASH)) (*1) (*2) | |
| | IC3 | PNWITGA939TR | IC (EEPROM) (*1) | |
| | IC801 | C1CB00001842 | | |
| | | | (TRANSISTORS) | |
| | Q2 | B1ADGE000004 | TRANSISTOR (SI) | |
| | Q4 | B1ADGE000004 | TRANSISTOR (SI) | |
| | Q7 | UN9219J | TRANSISTOR (SI) | S |
| | Q9 | 2SC6054JSL | TRANSISTOR (SI) | S |
| | Q13 | 2SD1819A | TRANSISTOR (SI) | |
| | Q14 | 2SD1819A | TRANSISTOR(SI) | |
| | | | (DIODES) | |
| | D1 | B0JCMC000006 | DIODE(SI) | |
| | D5 | 188355 | DIODE(SI) | S |
| | D7 | B0JCME000035 | DIODE(SI) | |
| | D21 | MA8043M | DIODE(SI) | S |
| | D22 | MA8043M | DIODE(SI) | S |
| | D801 | MA27P1200L | DIODE(SI) | |
| | D802 | MA27P1200L | DIODE(SI) | |
| | DA1 | B0DDCL00001 | DIODE(SI) | |
| | LED2 | B3ACB0000216 | DIODE(SI) | |
| | LED3 | B3ACB0000216 | DIODE(SI) | |
| | | | (LEDS) | |
| | LED5 | B3ACB0000216 | LED | |
| | LED6 | B3ACB0000216 | LED | |
| | LED12 | B3ACB0000216 | LED | |
| | | | (JACK) | |
| | CN4 | K2HD103D0001 | JACK | |
| | | | (COILS) | |
| | L4 | G1C100MA0072 | | |
| | L5 | G1C100MA0072 | COIL | |
| | L805 | PQLQR4F121ST | COIL | S |
| | C812 | ELJRF3N3ZFB | COIL | |
| | F1 | PQLQR2M5N6K | COIL | S |
| | | | (IC FILTERS) | |
| | L9 | J0JCC0000287 | | |
| | L72 | J0JCC0000276 | | |
| | R308 | J0JCC0000286 | | |
| | | | (VARISTORS) | |
| | D8 | D4ED1270A014 | | |
| | | D4ZZ00000032 | | |
| | D14 | D4ZZ00000032 | | |
| | | | (RESISTORS) | |
| | R2 | ERJ2GEJ392 | 3.9k | |
| | R6 | ERJ2GEJ102 | 1k | |
| | R7 | ERJ2GEJ122 | 1.2k | |
| | R8 | ERJ2GEJ101 | 100 | |
| | R12 | ERJ2GE0R00 | 0 | |
| | R15 | ERJ2GE0R00 | 0 | |
| | R16 | ERJ2GE0R00 | 0 | |
| | R20 | ERJ2GEJ100 | 10 | |
| | | | | |

| Safety | | Part No. | Part Name & Description | Remarks |
|----------|---|--|--|----------|
| | No. R22 | ERJ2GEJ332 | 3.3k | |
| | R23 | ERJ2GEJ332 ERJ2GEJ102 | 1k | |
| | | | | |
| | R25 | ERJ2GEJ222 | 2.2k 820 | |
| | R27 R28 | ERJ3GEYJ821 ERJ2GEJ821 | 820 | |
| | R28 | ERJ2GEJ821 ERJ2GEJ102 | 1k | |
| | | ERJ2GEJ102 ERJ2GEJ104 | 100k | |
| | R32 | | | |
| | R34 | ERJ2GEJ104 | 100k | |
| | R40 | ERJ2GEJ103 | 10k | |
| | R41 | ERJ2GEJ472X | 4.7k | |
| | R42 | ERJ2GEJ103 | 10k | |
| | R45 | ERJ6RSJR10V | 0.1 | |
| | R46 | ERJ2GE0R00 | 0 | |
| | R50 | ERJ2GEJ332 | 3.3k | |
| | R51 | ERJ2GEJ471 | 470 | |
| | R52 | ERJ2GEJ221 | 220 | |
| | R53 | ERJ2GEJ332 | 3.3k | |
| | R54 | ERJ2GEJ103 | 10k | |
| | R63 | ERJ2GEJ101 | 100 | |
| | R64 | ERJ2GEJ103 | 10k | |
| | R66 | ERJ2GEJ102 | 1k | |
| | R71 | ERJ3GEYJ181 | 180 | |
| | R72 | ERJ2GE0R00 | 0 | 1 |
| | R106 | ERJ2GE0R00 | 0 | İ |
| | R107 | ERJ2GEJ221 | 220 | |
| | R108 | ERJ2GEJ221 | 220 | |
| | R109 | ERJ2GE0R00 | 0 | |
| | R148 | ERJ3GEYJ273 | 27k | |
| | R181 | ERJ2GE0R00 | 0 | |
| | R203 | D0GA563ZA006 | | |
| | R215 | ERJ2GE0R00 | 0 | |
| | R222 | ERJ2GE0R00 | 0 | |
| | R233 | ERJ2GEJ102 | 1k | |
| | R234 | ERJ2GEJ102 | 1k | |
| | R235 | ERJ2GEJ102 | 1k | |
| | | | | |
| | R238 | ERJ2GEJ102 | 1k | |
| | R244 | ERJ2GE0R00 | 0 | |
| | R248 | ERJ2GE0R00 | 0 | |
| | R301 | ERJ2GEJ221 | 220 | |
| | R302 | ERJ2GEJ221 | 220 | |
| | R304 | ERJ2GEJ221 | 220 | |
| | R305 | ERJ2GEJ221 | 220 | |
| | R306 | ERJ2GEJ101 | 100 | |
| | R340 | ERJ2GEJ222 | 2.2k | |
| | R341 | ERJ2GEJ473 | 47k | |
| | R343 | ERJ2GEJ105X | 1M | |
| | R344 | ERJ2GEJ224 | 220k | |
| | R345 | ERJ2GEJ104 | 100k | |
| | R801 | ERJ2GEJ182 | 1.8k | 1 |
| | R802 | F1G1HR50A480 | 0.5p | |
| | R803 | ERJ2GEJ102 | 1k | 1 |
| | R804 | ERJ2GEJ102 | 1k | |
| | R805 | ERJ2GEJ470 | 47 | |
| | R806 | ERJ2GEJ221 | 220 | † |
| | | | | † |
| i l | R807 | ERJ2GEJ221 | 220 | |
| | R807 | ERJ2GEJ221 D1H433220001 | | |
| | RA4 | D1H433220001 | 3.3k | |
| | RA4 RA61 | D1H433220001 D1H410220001 | 3.3k 1k | |
| | RA4 RA61 L10 | D1H433220001 D1H410220001 ERJ2GEJ330 | 3.3k 1k 33 | |
| | RA4 RA61 L10 L11 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 | 3.3k 1k 33 | |
| | RA4 RA61 L10 L11 L71 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 ERJ2GE0R00 | 3.3k 1k 33 33 | |
| | RA4 RA61 L10 L11 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 | 3.3k 1k 33 33 0 | |
| | RA4 RA61 L10 L11 L71 L74 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 ERJ2GE0R00 ERJ2GEJ100 | 3.3k 1k 33 33 0 10 (CAPACITORS) | |
| | RA4 RA61 L10 L11 L71 L74 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 | |
| | RA4 RA61 L10 L11 L71 L74 C1 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P | 3.3k 1k 33 30 0 10 (CAPACITORS) 220 330 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEJ330 ERJ2GEORO0 ERJ2GEJ100 EEEE0JA221WP EEE0JA331P ECUV1A105KBV | 3.3k 1k 33 30 0 10 (CAPACITORS) 220 330 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ | 3.3k 1k 33 30 0 10 (CAPACITORS) 220 330 1 0.1 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 C13 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ PQCUV0J106KB | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 C13 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ PQCUV0J106KB | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 C13 C14 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEOR00 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ PQCUV0J106KB ECUE1A104KBQ ECUE1C103KBQ | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 10 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 C13 C14 C16 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEGU330 ERJ2GEJ100 ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ PQCUV0J106KB ECUE1A104KBQ PQCUV0J106KB | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 10 0.1 0.01 | |
| | RA4 RA61 L10 L11 L71 L74 C1 C2 C3 C11 C12 C13 C14 C16 C33 | D1H433220001 D1H410220001 ERJ2GEJ330 ERJ2GEGOROO ERJ2GEJ100 EEE0JA221WP EEE0JA331P ECUV1A105KBV ECUE1A104KBQ PQCUV0J106KB ECUE1A104KBQ PQCUV0J106KB ECUE1C103KBQ PQCUV0J106KB | 3.3k 1k 33 33 0 10 (CAPACITORS) 220 330 1 0.1 10 0.1 10 0.1 0.01 10 0.1 10 | |

| Safety | | Part No. | Part Name & Description | Remarks |
|--------|--------------|------------------------------|-------------------------|--|
| | No. | ECUE1A104KBQ | 0 1 | |
| | C45 | ECUE1A104KBQ | | |
| | C46 | ECUE1H100DCQ | | |
| | C47 | ECUV1A105KBV | _ | |
| | C48 | ECUV1A225KB | 2.2 | |
| | C49 | ECUV1A105KBV | 1 | |
| | C50 | ECUV1A105KBV | 1 | |
| | C51 | ECUV1A105KBV | 1 | |
| | C52 | PQCUV0J106KB | 10 | |
| | C53 | PQCUV0J106KB | 10 | |
| | C70 | ECUE1H100DCQ | - | |
| | C71 | ECUE1H100DCQ | _ | |
| | C72 | ECUE1H100DCQ | _ | |
| | C73 | ECUE1H100DCQ | _ | |
| | C82 | ECUE1H471KBQ | _ | |
| | C83 | ECUE1H100DCQ | _ | |
| | C86 | PQCUV0J106KB | | |
| | C96 | ECUE1H100DCQ ECUE1H100DCQ | _ | |
| | C103 | ECUE1H100DCQ | - | |
| | C104 | ECUE1H101JCQ | _ | |
| | C105 | ECUE1H101JCQ | _ | |
| | C110 | ECUE1H102KBQ | = | |
| | C117 | ECUE1H100DCQ | | |
| | C118 | ECUE1H100DCQ | _ | |
| | C122 | F1G1H1R8A480 | - | |
| | C124 | ECUE1H100DCQ | 10p | |
| | C125 | ECUE1H100DCQ | 10p | |
| | C127 | ECUE1H102KBQ | 0.001 | |
| | C147 | ECUV1A105KBV | 1 | |
| | C152 | ECUE1H102KBQ | | |
| | C170 | ECUE1H100DCQ | _ | |
| | C171 | ECUV1H100DCV | - | |
| | C172 | ECUV1C104KBV | | |
| | C173 | ECUV1C105KBV | | |
| | C174 | ECUV1C105KBV | | |
| | C175 | ECUV1C105KBV | | |
| | C176 | ECUV1C105KBV ECUV1C474KBV | | |
| | C177 | ECUVIC474KBV ECUV1C474KBV | | |
| | C178 | ECUV1C474KBV | | |
| | C180 | ECUV1C474KBV | | |
| | C181 | ECUV1C474KBV | | |
| | C182 | F1G1H2R7A480 | | |
| | C183 | F1H0J4750002 | - | |
| | C184 | ECUE1H100DCQ | 10p | |
| | C185 | ECUE1H102KBQ | _ | |
| | C186 | ECUE1H101JCQ | | |
| | C187 | ECUE1H101JCQ | 100p | |
| | C188 | ECUE0J105KBQ | 1 | |
| | C340 | F1J0J2260004 | 22 | |
| | C802 | F1G1H2R4A480 | _ | |
| | C803 | F1G1H1R8A480 | _ | |
| | C804 | F1G1H2R4A480 | 2.4p | |
| | C807 | F1G1H2R2A480 | - | |
| | C808 | ECUE1A104KBQ | | |
| | C809 | ECUE1H100DCQ | _ | 1 |
| | C810 | F1G1H2R7A480 | | - |
| | C811 | ECUE1H100DCQ | _ | - |
| | C813 | ECUE1H1R0BCQ | | |
| | C814 C815 | ECUE1H332KBQ F1G1H1R2A480 | | 1 |
| | C815 | ECUE1H100DCQ | | 1 |
| | C820 | F1G1HR50A480 | _ | - |
| | C820 | ECUE1H101JCQ | = | - |
| | C825 | ECUE1H1013CQ ECUE1H100DCQ | _ | |
| | C825 | F1G1H2R2A480 | _ | - |
| | C832 | F1G1H7R0A480 | _ | 1 |
| | C834 | F1G1HR75A480 | | 1 |
| | C840 | F1G1H1R8A480 | | <u> </u> |
| | L804 | F1G1H1R2A480 | _ | |
| | L122 | F1G1H1R8A480 | | |
| | | | | |

| - | | | | |
|--------|--------|--------------|-----------------------------|---------|
| Safety | Ref. | Part No. | Part Name & Description | Remarks |
| | No. | | | |
| | MIC100 | L0CBAY000016 | MICROPHONE | |
| | E101 | L5DZBYY00013 | LIQUID CRYSTAL DISPLAY (*3) | |
| | E102 | PQHR11279Z | TRANSPARENT PLATE | PMMA-HB |
| | E103 | PNHR1006Z | GUIDE, LCD | ABS-HB |
| | E104 | PNHX1004Z | LCD COVER SHEET | |
| | E105 | PQJE10179V | LEAD WIRE, FPC | |
| | E106 | B3AFB0000211 | LED | |
| | E107 | PQWE10050Z | BATTERY TERMINAL | |
| | E108 | PNMC1003Z | MAGNETICSHIELD, CASE | |
| | X1 | ној103500033 | CRYSTAL OSCILLATOR (*1) | |

15.5.3. Charger Unit

15.5.3.1. Cabinet and Electrical Parts

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|-------|------------|------------------------------------|---------|
| | No. | | | |
| | 200 | PNLC1001YT | CHARGER UNIT (RTL) | |
| | 200-1 | PNKM1015Y2 | CABINET BODY | PS-HB |
| | 200-2 | PNJT1010Z | CHARGE TERMINAL | |
| | 200-3 | PNKF1012Z1 | CABINET COVER | PS-HB |
| | 200-4 | PQHA10023Z | RUBBER PARTS, FOOT CUSHION | |
| | 200-5 | PNGT1728Z | NAME PLATE (for KX-TG9391/ 92T) | |
| | 200-5 | PNGT1044Y | NAME PLATE (for KX- TGA939T) | |

15.5.3.2. Main P.C.Board Parts

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|--------|--------------|----------------------------|---------|
| | No. | | | |
| | PCB200 | PQWPTGA721CH | MAIN P.C.BOARD ASS'Y (RTL) | |
| | | | (DIODE) | |
| | D1 | B0JAME000095 | DIODE(SI) | |
| | | | (JACK) | |
| | J1 | K2ECYB000001 | JACK | S |
| | | | (RESISTOR) | |
| | R1 | ERG2SJ100E | 10 | |
| | | | (FUSE) | |
| | F1 | K5H302Y00003 | FUSE | |

15.5.4. Accessories and Packing Materials Note:

(*1) You can download and refer to the Operating Instructions (Instruction book) on TSN Server.

15.5.4.1. KX-TG9391T

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|-------------|-------------------------------------|---------|
| ⚠ | A1 | PQLV207T | AC ADAPTOR (for Base Unit) | |
| ⚠ | A2 | PQLV209T | AC ADAPTOR (for Charger Unit) | |
| | A3 | PQJA10075Z | CORD, TELEPHONE (for Line 1) | |
| | A4 | PQJA10088Z | CORD, TELEPHONE (for Line 2) | |
| | A 5 | PQJA212V | CORD, HANDSET | |
| | A 6 | PNKE1004Z1 | HANGER, BELT CLIP | ABS-HB |
| | A7 | PNQX1454Z | INSTRUCTION BOOK (*1) | |
| | A8 | PNQW1340Z | LEAFLET, QUICK GUIDE (for English) | |
| | A9 | PNQW1341Z | LEAFLET, QUICK GUIDE (for Spanish) | |
| | A10 | PNLXP1001Z | HANDSET | |
| | P1 | РОРН89Ұ | PROTECTION COVER (for Base Unit) | |
| | P2 | XZB08X25B02 | PROTECTION COVER (for Portable) | |
| | P3 | XZB13X19C03 | PROTECTION COVER (for Charger Unit) | |

KX-TG9391T/KX-TG9392T/KX-TGA939T

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|-------------|----------------------------|---------|
| | P4 | PNPK1512Z | GIFT BOX | |
| | P5 | PNPD1148Z | CUSHION | |
| | P6 | PQXDDS400-8 | MAGNET ELECTRIC TRANSDUCER | |

| Safety | Ref. | Part No. | Part Name & Description Remarks |
|--------|------|------------|---------------------------------|
| | | PQZZ430PRB | RUBBER OF SOLDERING IRON (*2) |

15.5.4.2. KX-TG9392T

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|-------------|-------------------------------------|---------|
| Δ | A101 | PQLV207T | AC ADAPTOR (for Base Unit) | |
| Δ | A102 | PQLV209T | AC ADAPTOR (for Charger Unit) | |
| | A103 | PQJA10075Z | CORD, TELEPHONE (for Line 1) | |
| | A104 | PQJA10088Z | CORD, TELEPHONE (for Line 2) | |
| | A105 | PQJA212V | CORD, HANDSET | |
| | A106 | PNKE1004Z1 | HANGER, BELT CLIP | ABS-HB |
| | A107 | PNQX1454Z | INSTRUCTION BOOK (*1) | |
| | A108 | PNQW1340Z | LEAFLET, QUICK GUIDE (for English) | |
| | A109 | PNQW1341Z | LEAFLET, QUICK GUIDE (for Spanish) | |
| | A110 | PNLXP1001Z | HANDSET | |
| | P101 | РОРН89У | PROTECTION COVER (for Base Unit) | |
| | P102 | XZB08X25B02 | PROTECTION COVER (for Portable) | |
| | P103 | XZB13X19C03 | PROTECTION COVER (for Charger Unit) | |
| | P104 | PNPK1836Z | GIFT BOX | |
| | P105 | PNPD1148Z | CUSHION | |
| | P106 | PQXDDS400-8 | MAGNET ELECTRIC TRANS- DUCER | |

15.5.4.3. KX-TGA939T

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|-------------|-------------------------------------|---------|
| Δ | A201 | PQLV209T | AC ADAPTOR | |
| | A202 | PNKE1004Z1 | HANGER, BELT CLIP | ABS-HB |
| | A203 | PNQX1455Z | INSTRUCTION BOOK (*1) | |
| | A204 | PQQW15385Z | LEAFLET | |
| | P201 | XZB13X19C03 | PROTECTION COVER (for Charger Unit) | |
| | P202 | XZB08X25B02 | PROTECTION COVER (for Portable) | |
| | P203 | PNPK1513Z | GIFT BOX | |
| | P204 | PQXDDS400-8 | MAGNET ELECTRIC TRANS- DUCER | |

15.5.5. Screws

| Safety | Ref. No. | Part No. | Part Name & Description | Remarks |
|--------|-------------|------------|-------------------------|---------|
| | A | XTB26+8GFJ | TAPPING SCREW | |
| | В | XTB2+8GFJ | TAPPING SCREW | |

15.5.6. Fixtures and Tools

Note:

- (*1) See The Setting Method of JIG (Base Unit) (P.67), and The Setting Method of JIG (Portable) (P.71).
- (*2) When replacing the Base unit and Portable LCD, See ${\bf Assembly\ Instructions}$ (P.65) .

| Safety | Ref. | Part No. | Part Name & Description | Remarks |
|--------|------|-------------|----------------------------|---------|
| | No. | | | |
| | | PQZZ1CD300E | JIG CABLE (*1) | |
| | | PNZZTG9391T | BATCH FILE CD-ROM (*1) | |
| | | PQZZ430PIR | TIP OF SOLDERING IRON (*2) | |

O KXTG9391T KXTG9392T KXTGA939T