

# Service Manual

Plasma Television

Model No. **TH-P58V10P**  
**TH-P58V10R**

GPF12DA Chassis

*Simplified*








Please file and use this manual together with the service manual for Model No. TH-P58V10M, ORDER NO. ITD0909099CE.

## WARNING



This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

## 1 Different points

### 1.1. Mechanical Replacement Parts List

Ref. No.	Parts No.		Parts name & Description	Remarks
	TH-P58V10M	TH-P58V10P/R		
1	K2CT3YY00016	<b>K2CT3YY00017</b>	AC CORD	P 
1	K2CT3YY00016	<b>K2CN3YY00004</b>	AC CORD	R 
30	TPCC69401	<b>TPCC69403</b>	CARTON BOX TOP	P 
30	TPCC69401	<b>TPCC69402</b>	CARTON BOX TOP	R 
45	-----	<b>TQBC2468</b>	INSTRUCTION BOOK (PERSIAN)	R 
51	TTUA2240	<b>TTUA2249</b>	REAR COVER	P 
51	TTUA2240	<b>TTUA2248</b>	REAR COVER	R 

### 1.2. Electrical Replacement Parts List

Ref. No.	Parts No.		Parts name & Description	Remarks
	TH-P58V10M	TH-P58V10P/R		
PCB	TXN/A1DRUM	<b>TXN/A1DRUQ</b>	CIRCUIT BOARD A	(RTL) P 
PCB	TXN/A1DRUM	<b>TXN/A1DRUM</b>	CIRCUIT BOARD A	(RTL) R 
IC8502	TVRQ646AB	<b>TVRQ647AB</b>	IC	P
IC8502	TVRQ646AB	<b>TVRQ646AB</b>	IC	R

**Panasonic®**

© Panasonic Corporation 2009.  
Unauthorized copying and distribution is a violation of law.