




5.2 REPLACEMENT PARTS LIST FOR ES8066

[TOP](#) [PREVIOUS](#) [NEXT](#)

NOTE:

*A= available as an optional accessory

*B= only available as set

*C= available individually

Ref. No.	Part No.	Part Name& Description	Remarks		Per Unit
1	WES881X7158	PROTECTIVE CAP			1
2	WES9075P	OUTER FOIL			1
3	WES8066K0048	OUTER FOIL FRAME			1
4	WES9070P	INNER BLADE	*B		2
5	WES882L9709	SCREW	*C	SUS M7/M3*8	2
6	WES8068L0207	RETAINING PLATE			1
7	WES8003L0327	WATER-PROOF RUBBER			1
8	WES8066K0008	BLADE MOUNTING BASE			1
9	WES8068K3267	FOIL FRAME RELEASE BUTTON	*C		2
10	WES3001L0177	SPRING FOR RELEASE BUTTON	*C		2
11	WES8066K3161	HOUSING			1
12	WES8068K3207	SWITCH HANDLE			1
13	WES8068N0367	LOCK BUTTON			1
14	WES8066K3968	SWITCH PANEL			1
15	WES8068K1507	TRIMMER			1
16	WES8066K3848	BOTTOM COVER			1
17	WES762L6007	SCREW	*C		2
18	WES8068L1077	TRIMMER DRIVING BAR B			1
19	WES8068L1087	TRIMMER DRIVING BAR A			1
20	WES8066L4308	LINEAR MOTOR ASSEMBLY			1
21	WES8068L1007	LINEAR MOTOR			1
22	WES8066L2128	MODULE			1
23	WES8068L0777	CHASSIS			1
24	WES882L2508	RECHARGEABLE BATTERY		NI-MH	1
25	WES8066K3041	BODY BLOCK			1
26	WES8066H7666	CHARGING ADAPTOR		O PLUG	1
27	WES663H7667	WALL MOUNTING HOLDER			1
28	WES8068H7007	SOFT CASE			1
29	WES861B7057	CLEANING BRUSH			1
-	WES8066K8013	INDIVIDUAL BOX			1
-	WES8066K8111	OPERATING INSTRUCTIONS			1

@

[TOP](#) [PREVIOUS](#) [NEXT](#)