# Service Manual

**Hair Styler** 

Model No. EH-KA11

Qatar





Please file and use this manual together with the service manual for Model No. EH-KA11, Order No.PEWT0909A80CE.

### **⚠ WARNING**

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

#### IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  $\triangle$  in the Schematic Diagrams, Circuit Board Diagrams, Exploded Views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacturer's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.

## TABLE OF CONTENTS

PAG	ìΕ
1 Exploded View and Replacement Parts List	2
1.1. Exploded View	2
1.2. Replacement Parts List	3


PAGE

# **Panasonic**

© Panasonic Corporation 2013 Unauthorized copying and distribution is a violation of law.

# 1 Exploded View and Replacement Parts List

## 1.1. Exploded View



\* All parts are supplied from PMFTH-AP through PLAP.

## 1.2. Replacement Parts List

Safety	Ref.No.	Part No.	Part Name & Descriptions	Quantity	Remarks
	1	EHKA11HS69WW	HOUSING AB (WHITE)	1	
	2	EHKA11FTWBW	FILTER (WHITE)	1	
	3	EHKA11FRHW	FIXING RING (GRAY)	1	
	4	EHKA11CTBW	CONNECTOR COVER B ASS'Y B/K	1	
	5	EHKA11CTAW	CONNECTOR COVER A (NATURAL)	1	
	6	EHKA11PCHS3W	POWER CORD (GRAY)	1	S3-PLUG
	7	EHKA11AIRTW	AIR INLET RING (NATURAL)	1	
	8	EHKA11MB2W	MOTOR ASS'Y B/K	1	
	9	EHKA11MSW	MAIN SWITCH	1	
	10	EHKA11ITBW	INSULATION TUBE SET	1	(4PCS./PACK)
	11	EHKA11ASPNW	ARM SWITCH PLATE (L/PINK)	1	
	12	EHKA11HB2W	HEATER B/K ASS'Y	1	
	13	EHKA11RFBW	RECTIFIER ASS'Y BLOCK	1	
	14	EHKA11CSHW	COIL SPRING (GRAY)	1	
	15	EHKA11PBWW	PUSH BUTTON (PURPLE)	1	
	16	EHKA11MSPWW	SWITCH PLATE (L/BLUE)	1	
	17	EHKA11T2604W	TAPPING SCREW(TORQUE) 2.6X4	2	*1
	18	EHKA11ESW	ESCUTCHEON	1	
	19	EHKA11HTWW	BLOW BRUSH ASS'Y (WHITE)	1	
		EHKA1169501W	INDIVIDUAL PACKAGE	1	
		EHKA1169503W	INSTRUCTION BOOKLET	1	
		EHKA11S09W	FILLER FOR PACKAGE	1	

Remarks:\*1 Individual Available