


# Service Manual

AC/Rechargeable Beard/Hair Trimmer

Model No. **ER2031K**  
**ER2051K**

*Supplement*

## Middle East




Please file and use this manual together with the service manual for Model No. ER2031 and ER2051, Order No. SD0705M38CE.

### WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

### IMPORTANT SAFETY NOTICE

There are special components used in this equipment which are important for safety. These parts are marked by  in the Schematic Diagrams, Circuit Board Diagrams, Exploded views and Replacement Parts List. It is essential that these critical parts should be replaced with manufacture's specified parts to prevent shock, fire or other hazards. Do not modify the original design without permission of manufacturer.









## TABLE OF CONTENTS

	Page
1 DETAILS OF CHANGE	2
2 REPLACEMENT PARTS LIST	3

# Panasonic

© Panasonic Corporation, 2013.  
All rights reserved. Unauthorized copying  
and distribution is a violation of law.

# 1 DETAILS OF CHANGE

	OLD	NEW
	AC Cord Type ER2031 / ER2051	Adaptor Type ER2031K / ER2051K
1. Cord type change AC Cord => Adaptor cord		
2. Appearance change Main unit: Shape of bottom side where the connector plugs into. Cord: Shape of connector	 	 
3. Inside of part change Motor, Module assembly etc.		

## 2 REPLACEMENT PARTS LIST

### 2.1 ER2031K

Ref.No.	Part No.	Part Name & Descriptions	Quantity	Remarks
4	WER2031K3059	HOUSING A	1	
5	WER2031K3069	HOUSING B	1	
11	WER203L3579	SWITCH TERMINAL PLATE	1	
14	WER2031L1008	MOTOR	1	
15	WER2031L2509	RECHARGEABLE BATTERY	1	Ni-Mh TYPE
16	WER2031L2109	MODULE	1	
18	WERGB50K7P63	ADAPTOR	1	C-2 PLUG
18	WERGB50K7P75	ADAPTOR	1	BF-3 PLUG, only for Saudi Arabia
18	WERGB50K7P70	ADAPTOR	1	BF-3 PLUG, only for UAE
21	WER2031K7008	SOFT CASE	1	
-	WER2031K8009	INDIVIDUAL BOX	1	
-	WER2031K8000	INDIVIDUAL BOX	1	only for Saudi Arabia
-	WER2031K8001	INDIVIDUAL BOX	1	only for UAE
-	WER2031K8109	OPERATING INSTRUCTIONS	1	

### 2.2 ER2051K

Ref.No.	Part No.	Part Name & Descriptions	Quantity	Remarks
4	WER2051K3059	HOUSING A	1	
5	WER2051K3069	HOUSING B	1	
11	WER203L3579	SWITCH TERMINAL PLATE	1	
14	WER2031L1008	MOTOR	1	
15	WER2051L2501	RECHARGEABLE BATTERY	1	Ni-Mh TYPE
16	WER2051L2109	MODULE	1	
18	WERGB50K7P63	ADAPTOR	1	C-2 PLUG
18	WERGB50K7P75	ADAPTOR	1	BF-3 PLUG, only for Saudi Arabia
18	WERGB50K7P70	ADAPTOR	1	BF-3 PLUG, only for UAE
21	WER2031K7008	SOFT CASE	1	
-	WER2051K8009	INDIVIDUAL BOX	1	only for UAE
-	WER2051K8000	INDIVIDUAL BOX	1	
-	WER2031K8109	OPERATING INSTRUCTIONS	1	