

Service Manual

Telephone Equipment

Supplement

Model No.

**KX-TG6841B/KX-TG6842B/
 KX-TG6843B/KX-TG6844B/
 KX-TG6845B/KX-TG6873B/
 KX-TG6842CB/KX-TG6843CB/
 KX-TG6841BXB/KX-TG6841MEB/
 KX-TG7841S/KX-TG7842S/
 KX-TG7843S/KX-TG7844S/
 KX-TG7845S/KX-TG365SK/
 KX-TG7871S/KX-TG7872S/
 KX-TG7873S/KX-TG7874S/
 KX-TG7875S/KX-TG385SK/
 KX-TG395CSK/KX-TG7872CS/
 KX-TG7873CS/KX-TG7872AZS/
 KX-TG7873AZS/KX-TG7892AZS/
 KX-TG7893AZS/KX-TG7841MES/
 KX-TGA680B/KX-TGA680S/
 KX-TGA680CB/KX-TGA680CS/
 KX-TGA680AZS/KX-TGA680MES**

Digital Cordless Answering System
 Link-to-Cell Cellular Convergence
 Solution

Digital Cordless Telephone with Link-to-
 Cell System

B: Black Version

S: Silver Version

Please use this manual with the original service manual mentioned on the next page.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Panasonic®

© Panasonic System Networks Co., Ltd. 2015
 Unauthorized copying and distribution is a violation
 of law.









1 ORIGINAL SERVICE MANUAL INFORMATION

Model No. on S/M	Destinations	Order No. of S/M	Suffix Code	
			Base Unit	Handset
KX-TG6841B/KX-TG6842B/KX-TG6843B/KX-TG6844B/KX-TG6845B/ KX-TGA680B/KX-TGA20B	U.S.A.	KM41302656CE	---	---
KX-TG6842CB/KX-TG6843CB/KX-TGA680CB	Canada	KM41301652CE	---	---
KX-TG6841BxB/KX-TGA680BxB	Middle Near East and Asia	KM41307722CE	---	---
KX-TG6841MEB/KX-TGA680MEB/KX-TGA680MES	Mexico	KM41310761CE	---	---
KX-TG7841S/KX-TG7842S/KX-TG7843S/KX-TG7844S/KX-TG7845S/ KX-TG365SK/KX-TG7871S/KX-TG7872S/KX-TG7873S/KX- TG7874S/KX-TG7875S/KX-TG385SK/KX-TGA680S/KX-TGA20B	U.S.A.	KM41302655CE	---	---
KX-TG395CSK/KX-TG7872CS/KX-TG7873CS/KX-TGA680CS/KX- TGA20B	Canada	KM41302660CE	---	---
KX-TG7872AZS/KX-TG7873AZS/KX-TGA680AZS	Australia and New Zealand	KM41303668CE	---	---
KX-TG7892AZS/KX-TG7893AZS/KX-TGA680AZS/KX-TGA20AZ	Australia and New Zealand	KM41311775CE	---	---
KX-TG7841MES/KX-TGA680MES	Mexico	KM41310765CE	---	---

2 REPLACEMENT PARTS LIST

2.1. REFERENCE CHART

Reason for Change	
*The following items (1-8) indicate the reason for change. See the "Notes" column for each part in ORIGINAL AND NEW PARTS COMPARISON LISTS .	
1. Improve performance	Remarks: *c: To share the parts with other models
2. Change of material or dimension	
3. To meet approved specification	
4. Standardization	
5. Addition	
6. Deletion	
7. Correction	
8. Other	

Interchangeability Code		
**The following items (V-Z) indicate the Interchangeability. See the "Notes" column for each part in ORIGINAL AND NEW PARTS COMPARISON LISTS .		
V	Original  Early (before change) New  Late (after change)	Original or new parts may be used in early or late production sets. Use original parts until exhausted, then stock new parts.
W	Original  Early (before change) New  Late (after change)	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.
X	Original  Early (before change) New  Late (after change)	New parts only may be used in early or late production sets. Stock new parts.
Y	Original  Early (before change) New  Late (after change)	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.
Z	Other	

Note:

Alphabets in the "Remarks" column in the following lists correspond to the alphabets in the "Remarks" in REFERENCE CHART.

2.2. ORIGINAL AND NEW PARTS COMPARISON LISTS

Ref. No.	Part No.		Part Name & Description	Pcs/ Set	Remarks	Notes	Time of Change (Suffix)
	Original (Old)	New					
Cabinet and Electrical Parts (Handset)							
115, 118	PNHS1466Z	PNHS1691Z	SPACER, BATTERY	1	*c	8 V	---

For KX-TG6842CB, KX-TG6843CB, KX-TGA680CB, KX-TG395CSK, KX-TG7872CS, KX-TG7873CS, KX-TGA680CS

Ref. No.	Part No.		Part Name & Description	Pcs/ Set	Remarks	Notes	Time of Change (Suffix)
	Original (Old)	New					
Replacement Parts List							
A9, A10	PNHS1466Z	PNHS1691Z	SPACER, BATTERY	1	*c	8 V	---