

Service Manual

Telephone Equipment

Supplement

Model No.

KX-TGF310EXM/KX-TGF320EXM/
 KX-TGF320EM/KX-TGF340B/
 KX-TGF342B/KX-TGF343B/
 KX-TGF344B/KX-TGF345B/
 KX-TGF372S/KX-TGF373S
 KX-TGF374S/KX-TGF375S/
 KX-TG585SK/KX-TGF350N/
 KX-TGF352N/KX-TGF353N/
 KX-TG572SK/KX-TGF380M/
 KX-TGF382M/KX-TGF383M/
 KX-TGF342CB/KX-TGF343CB/
 KX-TGF350CM/KX-TGF350CN/
 KX-TGF352CN/KX-TG132CSK/
 KX-TG133CSK/KX-TGFA30B/
 KX-TGFA30N/KX-TGFA30M/
 KX-TGFA30S/KX-TGFA30CB/
 KX-TGFA30CN/KX-TGFA30CM/
 KX-TGFA30EM/KX-TGFA30EXM

Digital Corded/Cordless Phone

Digital Corded/Cordless Answering
 System

Digital Corded/Cordless Phone with
 Link-to-Cell

Digital Cordless Answering System

Link-to-Cell Bluetooth Convergence
 Solution

B: Black Vesion

M: Metallic Black Version

N: Champagne Gold Version

Please use this manual with the original service manual mentioned on the next page.

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.

Panasonic[®]

© Panasonic System Networks Co., Ltd. 2015
 Unauthorized copying and distribution is a violation
 of law.









1 ORIGINAL SERVICE MANUAL INFORMATION

Model No. on S/M	Destinations	Order No. of S/M	Suffix Code	
			Base Unit	Handset
KX-TGF310EXM/KX-TGF320EXM/KX-TGFA30EXM	Spain, Greece and Italy	KM41504914CE	---	---
KX-TGF320EM/KX-TGFA30EM	UK and Ireland	KM41503910CE	---	---
KX-TGF340B/KX-TGF342B/KX-TGF343B/KX-TGF344B/KX-TGF345B/KX-TGF372S/KX-TGF373S/KX-TGF374S/KX-TGF375S/KX-TG585SK/KX-TGFA30B/KX-TGFA30S/KX-TGFA30M	U.S.A.	KM41501897CE	---	---
KX-TGF342CB/KX-TGF343CB/KX-TGFA30CB	Canada	KM41502903CE	---	---
KX-TGF350N/KX-TGF352N/KX-TGF353N/KX-TG572SK/KX-TGF380M/KX-TGF382M/KX-TGF383M/KX-TGFA30N/KX-TGFA30M	U.S.A.	KM41501899CE	---	---
KX-TGF350CM/KX-TGF350CN/KX-TGF352CM/KX-TGF352CN/KX-TG132CSK/KX-TG133CSK/KX-TGFA30CN/KX-TGFA30CM	Canada	KM41502900CE	---	---

2 REPLACEMENT PARTS LIST

2.1. REFERENCE CHART

Reason for Change	
*The following items (1-8) indicate the reason for change. See the "Notes" column for each part in ORIGINAL AND NEW PARTS COMPARISON LISTS.	
1. Improve performance	Remarks: *c: To share the parts with other models
2. Change of material or dimension	
3. To meet approved specification	
4. Standardization	
5. Addition	
6. Deletion	
7. Correction	
8. Other	

Interchangeability Code		
**The following items (V-Z) indicate the Interchangeability. See the "Notes" column for each part in ORIGINAL AND NEW PARTS COMPARISON LISTS.		
V	Original  Early (before change) New  Late (after change)	Original or new parts may be used in early or late production sets. Use original parts until exhausted, then stock new parts.
W	Original  Early (before change) New  Late (after change)	Original parts may be used in early production sets only. New parts may be used in early or late production sets. Use original parts where possible, then stock new parts.
X	Original  Early (before change) New  Late (after change)	New parts only may be used in early or late production sets. Stock new parts.
Y	Original  Early (before change) New  Late (after change)	Original parts may be used in early production sets only. New parts may be used in late production sets only. Stock both original and new parts.
Z	Other	

Note:

Alphabets in the "Remarks" column in the following lists correspond to the alphabets in the "Remarks" in REFERENCE CHART.

2.2. ORIGINAL AND NEW PARTS COMPARISON LISTS

Ref. No.	Part No.		Part Name & Description	Pcs/ Set	Remarks	Notes	Time of Change (Suffix)
	Original (Old)	New					
Cabinet and Electrical Parts (Handset)							
115	PNHS1466Z	PNHS1691Z	SPACER, BATTERY	1	*c	8	V

For KX-TGF342CB, KX-TGF343CB, KX-TGFA30CB, KX-TGF350CN, KX-TGF352CN, KX-TG132CSK, KX-TGFA30CN

Ref. No.	Part No.		Part Name & Description	Pcs/ Set	Remarks	Notes	Time of Change (Suffix)
	Original (Old)	New					
Replacement Parts List							
A8, A11	PNHS1466Z	PNHS1691Z	SPACER	1	*c	8	V